

DIGITAL **PROJECTION**

A Delta Associate Company

Titan Laser Series 4K-UHD & WUXGA Models



Super High Brightness Digital Video Projector
Important Information

Digital Projection

Digital Projection Limited

Greenside Way, Middleton
Manchester M24 1XX, UK

Registered in England No. 2207264

Registered Office: as above

Tel (+44) 161 947 3300

Fax (+44) 161 684 7674

enquiries@digitalprojection.co.uk

service@digitalprojection.co.uk

www.digitalprojection.co.uk

Digital Projection Inc.

55 Chastain Road, Suite 115
Kennesaw, GA 30144, USA

Tel (+1) 770 420 1350

Fax (+1) 770 420 1360

powerinfo@digitalprojection.com

www.digitalprojection.com

Digital Projection Japan

〒105-0012 東京都港区芝大門2-1-14

2-1-14 Shibadaimon, Minato-ku,
Tokyo, Japan 105-0012

japan@digitalprojection.co.uk

www.digitalprojection.com/jp

Digital Projection Korea

1511, Byucksan Digital Valley 6-cha,
Gasan-dong, Geumcheon-gu,
Seoul, Korea

Tel +82 2 515 5303 #1417

Korea@digitalprojection.co.uk

Digital Projection India

india@digitalprojection.co.uk

Digital Projection China

中国 北京市 朝阳区 芍药居北里101号
世奥国际中心A座2301室(100029)

Rm A2301

ShaoYaoJu 101 North Lane

Shi Ao International Center

Chaoyang District

Beijing 100029, PR CHINA

Tel (+86) 10 84888566

Fax (+86) 10 84888566-805

techsupport@dp-china.com.cn

www.dp-china.com.cn

Digital Projection Asia

16 New Industrial Road
#02-10 Hudson Technocentre
Singapore 536204

Tel (+65) 6284-1138

Fax (+65) 6284-1238

www.digitalprojectionasia.com

Digital Projection Taiwan

186 Ruey Kuang Rd, Neihu District,
Taipei, 114 Taiwan

Tel +886-8797-2088 x8854

Taiwan@digitalprojection.co.uk

Digital Projection FZE

Unit B4, Light Industrial Units 4,
Silicon Oasis, Dubai, UAE

Tel +971 43300800

enquiries@digitalprojection.co.uk

www.digitalprojection.com

Super High Brightness Digital Video Projector

Important Information

Contents

Symbols used in the User Manual	4
Electrical and physical specifications	4
Laser precautions	5
Product labels	6
<i>Manufacturers ID Label and Explanatory Label</i>	6
<i>Hazard Warning Symbol and Aperture Label</i>	8
<i>Mains Information</i>	8
<i>Maintenance Warning</i>	8
<i>Stacking and Eyebolt Usage Notices</i>	8
<i>Eyebolt Usage Notice</i>	8
<i>Label locations</i>	9
Location of laser aperture	10
Interlock switches	10
General precautions	11
Installation precautions	12
Light hazard warning	13
<i>Light hazard distances</i>	13
Operation and configuration precautions	14
Compliance with international standards	14
<i>RF Interference</i>	14
<i>Noise</i>	14
<i>European Waste Electrical and Electronic Equipment (WEEE) Directive</i>	14
Whats in the Box?	15
Basic Operation Instructions	16
<i>Positioning the screen and projector</i>	16
<i>Stacking and rigging</i>	17
<i>Inserting a new lens</i>	20
<i>Removing the lens</i>	21
<i>Fitting a lens hood</i>	21
<i>Connecting the power supply</i>	23
<i>Switching the projector on</i>	24
<i>Switching the projector off</i>	24
<i>Selecting an input signal</i>	25
<i>Selecting a test pattern</i>	25
<i>Adjusting the lens</i>	26
<i>Adjusting the image</i>	26
Control Panel Reference	27
Remote Control Reference	29

Full information about operating, connecting and setting up the projector can be found in the User Manual, located on the CD.

Symbols used in the User Manual



LASER WARNING: this symbol indicates that there is a potential hazard of eye exposure to laser radiation unless the instructions are closely followed.



ELECTRICAL WARNING: this symbol indicates that there is a danger of electrical shock unless the instructions are closely followed.



WARNING: this symbol indicates that there is a danger of physical injury to yourself and/or damage to the equipment unless the instructions are closely followed.



NOTE: this symbol indicates that there is some important information that you should read.

Electrical and physical specifications

	Titan Laser 37000 WU Titan Laser 33000 4K-UHD	Titan Laser 29000 WU Titan Laser 26000 4K-UHD
Mains Voltage	200 - 240 VAC 17 A 50/60 Hz	200-240 VAC 15.5A 50/60Hz
Operating Temperature	0°C to 40°C	0°C to 40°C
Storage Temperature	-20°C to 60°C	-20°C to 60°C
Operating Humidity	20% to 90% non-condensing	20% to 90% non-condensing
Weight	100 kg (220.5 lb) without lens	100 kg (220.5 lb) without lens
Power Consumption	3400 W at 200 VAC 1145 W at 110 VAC	3100 W at 200 VAC 1145 W at 110 VAC
Thermal Dissipation	11604 BTU/hr at 200 VAC 3906 BTU/hr at 110 VAC	10577 BTU/hr at 200 VAC 3906 BTU/hr at 110 VAC



Specifications are subject to change without notice.



110V operation is only available on the USA model. Light output power is reduced to approx 30% when operating on 110V.

Laser precautions



CLASS 3R LASER PRODUCT

This Laser Product is designated as Class 3R during all procedures of operation.

LASER LIGHT - AVOID DIRECT EYE EXPOSURE.

Do not point laser or allow laser light to be directed or reflected toward other people or reflective objects.

Direct or scattered light can be hazardous to eyes and skin.

There is a potential hazard of eye exposure to laser radiation if the included instructions are not followed.

Caution – use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Non-laser emission. There remains non-laser emission from the projection lens. This portion of emission has been tested per IEC/EN 62471 to be Risk Group 3.


When long zoom lens (throw ratio 4.16~6.96:1) is used, the lens cap must be installed before the laser is turned on.

	Titan Laser 37000 WU	Titan Laser 29000 WU
	Titan Laser 33000 4K-UHD	Titan Laser 26000 4K-UHD
Laser Parameters:		
Wavelength	450 nm - 460 nm	450 nm - 460 nm
Laser Power for classification	333.5 mW	333.5 mW
Total internal power	> 100 W	> 100 W
Apparent Source Size	> 100 mm at lens stop	> 100 mm at lens stop
Divergence	100 miliRadian	100 miliRadian

Product labels


Manufacturers ID Label and Explanatory Label

EU



Titan User Guides
Follow link for Projector Documentation
Suivre le lien pour accéder à la documentation du projecteur
Produktdokumentation finden Sie unter dem Link
この二次元コードをスマートフォンでプロジェクターのデータを取得してください
請扫描条码取得投影机文件
프록젝터 설명서를 보려면 링크를 클릭하십시오

WJ XXXXX
32646380



DIGITAL PROJECTION


Model / Modèle
型号/型號

Part No. / Numéro de pièce
零部件号/零部件號

Serial No. / Numéro de série
序号/序號

Power / Puissance
电源/電壓

Titan Laser 37000 WU
119-704



200-240VAC 50/60Hz 17A
(Not for China / 非中國使用 / 非中國使用)

電源: 200-230VAC 50/60Hz 17A
Only for China/仅中国/僅中國

警告: 此为A类电子产品, 在生活环境中, 该产品可能造成无线电干扰。在这种情况下, 可能需要用户对于采取切实可行措施。
警告使用者: 這是早期的發光產品, 在居住的環境中使用時, 可能會造成射频干擾。在這種情況下, 使用者需要採取某些適當的對策。

WARNING
Isolate mains before removing cover.
ATTENTION
Isoler les conductes avant d'enlever le couvercle.
注意/注意 打开前请先切断主电源/打開前请先切断主电源


To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.
Pour réduire le risque d'incendie ou d'électrocution, n'exposez pas cet équipement à la pluie ou à l'humidité.
請勿將投影机置于雨中或潮濕環境中以降低起火或電氣風險。
請勿將投影机放在雨中或潮濕環境中以降低起火或電壓的風險。

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-3(A)/NMB-3(A)

PS E 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

19 16282(PART 1) 2101M
REC 60825-12005



www.bis.gov.in

Complies with 21 CFR 1040.10 Laser Radiation
Avoid direct eye exposure
Class 3R Laser product
Wave length: 450-460nm
Max output: 330mW
Dated June 24, 2007
Class 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

Laser Radiation
Evitez d'exposer directement les yeux
Produit Laser de classe 3R
Longueur d'onde: 450-460nm
Puissance maximale: 330mW
Date: 24 juin 2007
Classe 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

警告: 激光辐射
請勿直接照射眼睛
Class 3R Laser product
波長: 450-460nm
最大輸出: 330mW
日期: 2007年6月24日
Class 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

雷射雷射
請勿直接照射眼睛
Class 3R Laser product
波長: 450-460nm
最大輸出: 330mW
日期: 2007年6月24日
Class 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

Risk Group 3
Attention!
Do not look into the beam.
No direct eye exposure to the beam is permitted.
RG3 IEC EN 62471-1:2015
Hazard Distance: Refer to Manual

Groupe de Risque 3
Attention!
Ne pas regarder dans le faisceau.
Pas d'exposition directe des yeux au faisceau est autorisée.
RG3 IEC EN 62471-1:2015
Distance de danger: Se reporter au manuel


Name of Product: DLP Projector
Nom du produit: DLP Projecteur
产品名称: 数字投影机
產品名稱: 數位投影機

Digital Projection Limited
英國 倫敦 住有限公司
英國 倫敦 住有限公司

Greenside Way, Middleton Manchester, UK M24 1XX
英國 曼徹斯特 格林賽得路
英國 曼徹斯特 格林賽得路


Made in China
Fabriqué en Chine
中國製造
中國製造

China:



Titan User Guides
Follow link for Projector Documentation
Suivre le lien pour accéder à la documentation du projecteur
Produktdokumentation finden Sie unter dem Link
この二次元コードをスマートフォンでプロジェクターのデータを取得してください
請扫描条码取得投影机文件
프록젝터 설명서를 보려면 링크를 클릭하십시오

WJ XXXXX
32646380



DIGITAL PROJECTION


Model / Modèle
型号/型號

Part No. / Numéro de pièce
零部件号/零部件號

Serial No. / Numéro de série
序号/序號

Power / Puissance
电源/電壓

Titan Laser 37000 WU
119-727



200-240VAC 50/60Hz 17A
(Not for China / 非中國使用 / 非中國使用)

電源: 200-230VAC 50/60Hz 17A
Only for China/仅中国/僅中國

警告: 此为A类电子产品, 在生活环境中, 该产品可能造成无线电干扰。在这种情况下, 可能需要用户对于采取切实可行措施。
警告使用者: 這是早期的發光產品, 在居住的環境中使用時, 可能會造成射频干擾。在這種情況下, 使用者需要採取某些適當的對策。

WARNING
Isolate mains before removing cover.
ATTENTION
Isoler les conductes avant d'enlever le couvercle.
注意/注意 打开前请先切断主电源/打開前请先切断主电源

To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.
Pour réduire le risque d'incendie ou d'électrocution, n'exposez pas cet équipement à la pluie ou à l'humidité.
請勿將投影机置于雨中或潮濕環境中以降低起火或電氣風險。
請勿將投影机放在雨中或潮濕環境中以降低起火或電壓的風險。

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-3(A)/NMB-3(A)

PS E 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

Complies with 21 CFR 1040.10 Laser Radiation
Avoid direct eye exposure
Class 3R Laser product
Wave length: 450-460nm
Max output: 330mW
Dated June 24, 2007
Class 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

Laser Radiation
Evitez d'exposer directement les yeux
Produit Laser de classe 3R
Longueur d'onde: 450-460nm
Puissance maximale: 330mW
Date: 24 juin 2007
Classe 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

警告: 激光辐射
請勿直接照射眼睛
Class 3R Laser product
波長: 450-460nm
最大輸出: 330mW
日期: 2007年6月24日
Class 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

Laser Radiation
Evitez d'exposer directement les yeux
Produit Laser de classe 3R
Longueur d'onde: 450-460nm
Puissance maximale: 330mW
Date: 24 juin 2007
Classe 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

雷射雷射
請勿直接照射眼睛
Class 3R Laser product
波長: 450-460nm
最大輸出: 330mW
日期: 2007年6月24日
Class 1 Laser Product
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006

Risk Group 3
Attention!
Do not look into the beam.
No direct eye exposure to the beam is permitted.
RG3 IEC EN 62471-1:2015
Hazard Distance: Refer to Manual

Groupe de Risque 3
Attention!
Ne pas regarder dans le faisceau.
Pas d'exposition directe des yeux au faisceau est autorisée.
RG3 IEC EN 62471-1:2015
Distance de danger: Se reporter au manuel


Name of Product: DLP Projector
Nom du produit: DLP Projecteur
产品名称: 数字投影机
產品名稱: 數位投影機

Digital Projection Limited
英國 倫敦 住有限公司
英國 倫敦 住有限公司




Greenside Way, Middleton Manchester, UK M24 1XX
英國 曼徹斯特 格林賽得路
英國 曼徹斯特 格林賽得路

Made in China
Fabriqué en Chine
中國製造
中國製造

USA:




Titan User Guides
Follow link for Projector Documentation
Suivre le lien pour accéder à la documentation du projecteur
Prod&A documentation finden Sie unter dem Link
このマニュアルをコードをスキャンしてプロジェクトのデータを取得してください
請掃描條碼取得投影機檔的文件
프로젝터 설명서를 보려면 링크를 방문하십시오




Reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.
Pour réduire le risque d'incendie ou d'électrocution, n'exposez pas cet équipement à la pluie ou à l'humidité.
請將投影機放置在干燥清潔環境中以避免起火或電擊的風險
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.
CAN ICES-3(A)/NMB-3(A)
警告使用者：這是中期的貨試產品。在居住的環境中使用時，可能會造成頻干擾。在這種情況下，使用者會需要採取某些適當的對策。

Model / Modèle
型號
Part No. / Numéro de pièce
零件編號
Serial No. / Numéro de série
序號
Power / Puissance


Titan Laser 37000 WU
119-725B




100-130V / 200-240Vac,50/60Hz 17A
(Not for Taiwan / 非台灣地區使用)




輸入電壓: 200-240V ~ 50/60Hz 17A
(台灣使用)




Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser notice No.50.
Dated June 24, 2007
Class 1 Laser Product
IEC/EN 60825-1:2007
Hazard Distance: Refer to Manual




Laser Radiation
Avoid direct eye exposure
Class 3R Laser product
Wave length: 450-460nm
Max output: 330mW
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006




Rayonnement Laser
Evitez d'exposer directement les yeux
Produit Laser de classe 3R
Longueur d'onde: 450-460nm
Sortie maximale: 330mW
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006




雷射輻射
請勿直接照射
3R級雷射產品
波長: 450-460nm
最大輸出: 330mW
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006




雷射輻射
請勿直接照射
3R級雷射產品
波長: 450-460nm
最大輸出: 330mW
IEC/EN 60825-1:2007
IEC/EN 62471-1:2006



Risk Group 3
Warning!
Do not look into the beam.
No direct eye exposure to the beam is permitted.
RG3 IEC EN 62471-5:2015
Hazard Distance: Refer to Manual



Groupe de Risque 3
Attention!
Ne pas regarder dans le faisceau.
Pas d'exposition directe des yeux au faisceau est autorisée.
RG3 IEC EN 62471-5:2015
Distance de danger: voir le manuel



Not for household use

Digital Projection Limited
英國 愛爾斯 怡林得路













Greenside Way, Middleton Manchester, UK M24 1XX

Made in China
Fabriqué en Chine
中國製造

Name of Product: DLP Projector
Nom du produit: DLP Projecteur
產品名稱: 數位投影機


This includes the following information:

Product Identification

EU:	<div>Titan Laser 37000 WU 119-704</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 33000 4K-UHD 119-705</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 29000 WU 119-837</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 26000 4K-UHD 119-838</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>
China:	<div>Titan Laser 37000 WU 119-727</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 33000 4K-UHD 119-728</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 29000 WU 119-842</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 26000 4K-UHD 119-842</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>
USA:	<div>Titan Laser 37000 WU 119-725B</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 33000 4K-UHD 119-726B</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 2900 WU 119-839B</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>	<div>Titan Laser 26000 4K-UHD 119-840B</div> <div><div>100-130V / 200-240Vac,50/60Hz 17A</div></div>


Serial Number

Titan Laser 33000 4K-UHD
119-705




100-130V / 200-240Vac,50/60Hz 17A


Certification Statement




Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser notice No.50.
Dated June 24, 2007
Class 1 Laser Product
IEC/EN 60825-1:2014




Laser Radiation
Avoid direct eye exposure
Class 3R Laser product
Wave length: 450-460nm
Max output: 330mW
IEC/EN 60825-1:2007



Rayonnement Laser
Evitez d'exposer directement les yeux
Produit Laser de classe 3R
Longueur d'onde: 450-460nm
Sortie maximale: 330mW
IEC/EN 60825-1:2007
Produit laser de classe 1
IEC / EN 60825-1: 2014



雷射輻射
請勿直接照射
3R級雷射產品
波長: 450-460nm
最大輸出: 330mW
IEC/EN 60825-1:2007
第一次雷射產品
IEC / EN 60825-1: 2014



雷射輻射
請勿直接照射
3R級雷射產品
波長: 450-460nm
最大輸出: 330mW
IEC / EN 60825-1: 2007
第一次雷射產品
IEC / EN 60825-1: 2014

Rev B January 2019

Page 7

Risk Statement



Risk Group 3
Warning!
Do not look into the beam.
No direct eye exposure to the beam is permitted.
RG3 IEC EN 62471-5:2015
Hazard Distance : Refer to Manual

Groupe de Risque 3
Attention!
Ne pas regarder dans le faisceau.
Pas d'exposition directe des yeux au faisceau est autorisée.
RG3 IEC EN 62471-5:2015
Distance de danger : Se reporter au manuel

Hazard Warning Symbol and Aperture Label



LASER APERTURE レーザ開口
LASER OFFENUNG 레이저 개구부
OUVERTURE LASER 激光辐射之孔径
AΠΕΡΤΥΡΑ ΛΑΣΕΡΑ 雷射輻射之孔徑

Mains Information

Note : Input voltage limited: 200-240V~

注意：輸入電壓僅限 200-230V~

注意：輸入電壓僅限 200-240V~



Maintenance Warning

WARNING
ISOLATE MAINS BEFORE REMOVING COVER


注意 打開前先切斷主電源

注意 打開前先切斷主電源



Stacking and Eyebolt Usage Notices

Follow the arrow direction to remove the four feet of the upper machine before stacking.




堆疊機台前請先按箭頭指示方向取下上面機台的四個腳座

堆疊機台前請先按箭頭指示方向取下上面機台的四個腳座



Eyebolt Usage Notice



Please refer to manual for more detail information.

請參閱手冊以取得更多的相關信息。

請參閱手冊以取得更多的相關信息。

Caution: lifting angle must > 45°

注意：吊掛時，角度需 > 45°

注意：吊掛時，角度需 > 45°

You can lift the projector by using the eyebolts attached to 4 locations on the same plane temporarily.

Caution:

- Eyebolts should only be used for one projector.
- Eyebolts can't use for fix the projector for long time.
- A single line is required for one eyebolt.

可暫時使用投影機上的4個相同平面上的吊環來將投影機吊至高處。

警告:


- 使用吊環吊掛投影機時，僅適用於吊掛單台投影機。
- 不可長時間使用吊環或是使用吊環來固定投影機於天花板上。
- 吊掛時，每個吊環請使用單獨的一條線材。

可暫時使用投影機上的4個相同平面上的吊環來將投影機吊至高處。

警告:


- 使用吊環吊掛投影機時，僅適用於吊掛單台投影機。
- 不可長時間使用吊環或是使用吊環來固定投影機於天花板上。
- 吊掛時，每個吊環請使用單獨的一條線材。

Label locations



Location of laser aperture


The laser aperture **1** is located as indicated below.



Interlock switches

Interlock switches installed at the main frame, inside the cover, will power-off the system individually when activated.

- 1** Will be activated when the top cover is removed.
- 2** Will be activated when the projection lens is removed.



General precautions



The unit is never to be operated if the unit is defective or the cover or seal is damaged.

No maintenance allowed by end user.

Do not open the cabinet. There are no user serviceable parts inside.

No service is allowed except by authorized personnel.

Use only the power cable provided.

Ensure that the power outlet includes a Ground connection, as this equipment **MUST** be earthed.

Take care to prevent small objects such as paper or wire from falling into the projector. If this does happen, switch off immediately, and have the objects removed by authorised service personnel.

Do not expose the projector to rain or moisture, and do not place any liquids on top of the projector.

Unplug before cleaning, and use a damp, not wet, cloth.

Do not touch the power plug with wet hands.

Do not touch the power plug during a thunder storm.

Handle the power cable carefully and avoid sharp bends. Do not use a damaged power cable.



Do not touch the ventilation outlets, as they will become hot in use.

Do not cover or obstruct the ventilation outlets or inlets.

Do not cover the lens whilst the projector is switched on. This could cause a fire

Always allow the projector to cool for 5 minutes before disconnecting the power or moving the projector.

Never use strong detergents or solvents such as alcohol or thinners to clean the projector and lens.

Do not use the carry handles to mount or hang the projector.

Installation precautions



Connect the LAN cable only to a computer LAN connection. Other similar connectors may have a dangerously high voltage source.

The projector must be installed only by suitably qualified personnel, in accordance with local building codes.

The projector should be installed as close to the power outlet as possible.

The power connection should be easily accessible, so that it can be disconnected in an emergency.

Ensure that there is at least 50cm (19.7in) of space between the ventilation outlets and any wall, and 30cm (11.8in) on all other sides.

Do not install the projector close to anything that might be affected by its operational heat, for instance, polystyrene ceiling tiles, curtains etc.

Place the projector in a dry area away from sources of dust, moisture, steam, smoke, sunlight or heat.

The projector is heavy. Use safe handling techniques when lifting the projector.

Do not drop or knock the projector.

Before installation, make sure that the surface, ceiling or rigging that is to support the projector is capable of supporting the combined weight of the projector and lens.


When stacking projectors, the stack **MUST** be vertical, to ensure that the stresses are distributed to all four chassis corners.

Do not stack more than 2 projectors.

Do not place heavy objects on top of the projector chassis. Only the chassis corners and the optional rigging frame are capable of withstanding the weight of another projector.

Backup safety chains or wires should always be used with ceiling mount installations.

The projector can be operated any position, as shown in the diagram:



FDA regulations require that a lens Hood is permanently fitted when using the 4.16-6.96:1 lens with the Titan Laser range of projectors in the United States of America. Fitting can be provided by your reseller or System Integrator.



When using projectors in environments with third party high power laser systems avoid direct laser beams pointing towards the projection lens. This may cause incident light to converge into the optical engine and cause damage to the DLP DMD.

Please pay attention to projector installation with respect to other staging laser light equipment set-up. These systems can cause permanent damage to the DMD imaging devices used in our projectors. This damage is not covered by our warranty.

Make sure the lens cap is removed from the rear of the lens before it is inserted into the projector.

Make sure the lens caps are removed from the lens before operating the projector. Light energy levels this have been known to cause damage to both the lens and projector optics. This damage is not covered by our warranty.

Light hazard warning



Failure to comply with the following may result in serious injury:

- No direct exposure to the beam is permitted, RG3 IEC 62471-5:2015.
- Operators control access to the beam within the hazard distance or install the projector at sufficient height to prevent exposures of spectators' eyes within the hazard distance.




Fig. 1: hazard distance

The **hazard distance (Fig. 1)** is the distance measured from the projection lens at which the intensity or energy per unit of surface is lower than the applicable exposure limit on the cornea or skin. If the person is within the hazard distance, the beam is considered unsafe for exposure.

Light hazard distances

Lens	Hazard Distance
0.67: 1	2m
1.12 : 1	3.5m
1.16-1.49:1	5.5m
1.39-1.87:1	6.5m
1.87-2.56:1	8.5m
2.56-4.16:1	10.5m
4.16-6.96:1	14m
6.92 - 10.36:1	



Do not use the 0.67:1 and 1.12:1 fixed throw lenses with the 4K-UHD projectors

Operation and configuration precautions



Do not make changes to the networking configuration unless you understand what you are doing, or have taken advice from your Network Manager. If you make a mistake, it is possible that you will lose contact with the projector. Always double-check your settings before pressing the APPLY button. Always keep a written note of the original settings, and any changes you have made.

Software update should NOT be carried out except by, or with the supervision of, Digital Projection Service personnel.

Compliance with international standards



RF Interference

FCC

The Federal Communications Commission does not allow any modifications or changes to the unit EXCEPT those specified by Digital Projection in this manual. Failure to comply with this government regulation could void your right to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant with Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the user will be responsible for correcting any interference.

Noise

GSGV Acoustic Noise Information Ordinance



The maximum sound pressure level is 52 dB (A) according to ISO 3744 or ISO 7779.

European Waste Electrical and Electronic Equipment (WEEE) Directive




Digital Projection Ltd is fully committed to minimising Waste Electrical and Electronic Equipment. Our products are designed with reuse, recycling and recovery of all components in mind. To this end, at end of life, your projector may be returned to Digital Projection Ltd or its agent so that the environmental impact can be minimised.


Whats in the Box?




Remote control




2x AAA batteries



Important Information



HDMI cable



Remote cable



Power Cable UK/ROW



Power Cable USA




Lens Adapter Bracket

Basic Operation Instructions

Positioning the screen and projector

1. Install the screen, ensuring that it is in the best position for viewing by your audience.
2. Mount the projector, ensuring that it is at a suitable distance from the screen for the image to fill the screen. Set the adjustable feet so that the projector is level, and perpendicular to the screen.

The drawing below shows the positions of the feet for table mounting, and the fixing holes to mount the projector in inverted ceiling installations.



1 Four adjustable feet

2 Four M10 holes for ceiling mount

The screws should not penetrate more than 30 mm into the body of the projector.



Do not use the threaded holes for the adjustable feet to hang or mount the projector.




Stacking and rigging

The top of the projector has pins and the bottom of the projector has cups. The pins and cups can connect together and be locked into place with a locking pin.



This system should only be used to stack a maximum two projectors.


1. Remove the adjustable feet from the projector that will be stacked on the top. **1**
2. Mount the projector on top of the other projector. Ensure that all four cups are placed over the pins on the bottom projector. **2**
3. Push the locking pins into place on each cup and pin. **3**



A mounting rail may also be fitted using the pin and cup system. This is an optional accessory to the projector. It can be used with commercially available rigging truss clamps to attach the projector to a staging or lighting truss.



Only qualified riggers should make this installation after careful consideration of the strength and safety of the truss.



Four eye-bolts are fitted to the top of the projector to enable the flying of the projector using steel wire or chains.




This system should only be used to fly a single projector. Do not stack projectors and fly them together.


Point-to point connections

Refer to the following guidelines when connecting one end of a suspension cable directly to an eye-bolt and the other to a suspension point.


- The suspension cables can be connected to the eye-bolts at an angle of up to 45° around the eye ring.
- The suspension cables must not be connected **1** to the eye-bolts at any angle across the eye ring.
- The suspension cable must run vertically up **2** from the projector.



Examples of correct configurations:




Example of an incorrect configuration





Threaded suspension cables

Refer to the following guidelines when threading the suspension cable through the eye-bolts and connecting both ends to suspension points.

- The suspension cable can exit the eye-bolts at an angle of up to 45° around the eye ring. **1**
- The suspension cable can exit the eye-bolts at an angle of up to 45° across the eye ring. **2**
- The suspension cable should not be threaded through 2 or more eye-bolts



Example configurations:



Do not use the carry handles to mount or hang the projector.

Inserting a new lens



Before changing the lens, always make sure the projector is switched off and fully disconnected from its power supply.



Always allow the projector to cool for five minutes before disconnecting the power or moving the projector.



The lens release lever should always be set to the locked position to prevent the lens from falling out.



Do not place the projector with its front panel down on a surface, as this may damage the lens or the lens release lever.





Avoid touching the surface of the lens as this may result in image impairment.




Take care to preserve the original lens packaging and protective caps for future use.

1. Turn the lens release lever clockwise so that it is pointing upwards, to open the lock fully.
2. Remove the rear lens cap from the lens.
3. Insert the lens into the lens aperture, making sure that the plug on the zoom drive mechanism lines up with the socket on the front of the projector, then push the lens in firmly as far as it will go.
4. Turn the lens release lever anti-clockwise to the mid-position.



5. The lens can now be pushed in further. Push the lens in firmly as far as it will go.
6. Turn the lens release lever fully anti-clockwise so that it is pointing downwards, to close the lock fully. **4**



Removing the lens

To remove the lens, reverse the procedure described in **Inserting a new lens** above:


1. Turn the release lever up to the mid-position, then pull the lens out as far as it will go.
2. Turn the release lever clockwise so it is pointing upwards, then pull the lens out completely.

Fitting a lens hood




FDA regulations requires that a lens Hood is permanently fitted when using the 4.16-6.96:1 lens with the Titan Laser range of projectors in the United States of America. Fitting can be provided by your reseller or System Integrator.


1. Remove the six screws. **1**
2. Remove the lens glass



3. Place hood over the lens, aligned with the screw holes.
4. Screw in the six screws to secure the hood. **2**
5. Place the six sponges over the locating pins on the hood. **3**



6. Place the glass and bracket over the hood.
7. Screw in the six screws to secure the glass and bracket to the hood. **4**




Connecting the power supply

Rest of the world:

- 1 Firmly push the mains connector into the **socket**.

USA only:

- 2 Firmly push the mains connector into the **socket**.
Rotate the connector 90° clockwise to lock it in place



Use only the power cable provided.

Ensure that the power outlet includes a ground connection as this equipment **MUST** be earthed.

Handle the power cable carefully and avoid sharp bends. Do not use a damaged power cable.

The USA model can operate at 110V or 200V. Voltage selection is automatic, but the projector must be powered off before switching power outlets.



Light output power is reduced to approx 30% when using the USA model and operating on 110V.

Switching the projector on

1. Connect the power cable between the mains supply and the projector. (See **Connecting the power supply** above.) Switch the breaker switch next to the power connector to on.

The **POWER** indicator turns red to signal that the projector is on and in STANDBY mode.

2. Press one of the following buttons:

- On the remote control, the **ON** button
- On the projector control panel, the **POWER** button.

The **POWER** indicator begins flashing green as the projector powers up. When the flashing stops, the **POWER** indicator lights solid green and the Digital Projection logo appears on the screen. The projector is switched on and projecting.

Switching the projector off

1. Press **OFF** on the remote control or **POWER** on the control panel, then press again to confirm your choice.

The **POWER** indicator on the control panel will start flashing blue, the projected image will turn off and the cooling fans will run for a short time until the **POWER** indicator goes steady red to indicate that the projector has entered STANDBY mode.

2. If you need to switch the projector off completely, switch the breaker switch next to the power connector to off and then disconnect the power cable from the projector.

Selecting an input signal

1. Connect one or more image sources to the projector.
2. Select the input you want to display:
 - Press one of the input buttons on the remote control.
 - Alternatively, open the On-screen display (OSD) by pressing **MENU**. Highlight **Input** from the main menu, press **ENTER/OK** and then select an input signal using the **UP** and **DOWN** arrow buttons. Press **ENTER/OK** to confirm your choice.

Selecting a test pattern

To display a test pattern:

- Press **TEST** on the remote control. If necessary, press again to change the test pattern. Test patterns are displayed in the following order:

Off, White, Black, Red, Green, Blue, CheckerBoard, CrossHatch, V Burst, H Burst, ColorBar

After the final test pattern, the projector exits test pattern mode and returns to the main image. To view test patterns again, you need to press **TEST** again.

- Alternatively, open the OSD by pressing **MENU**. Highlight **Test Patterns** from the main menu, then select a test pattern using the **LEFT** and **RIGHT** arrow buttons.

Adjusting the lens

The lens can be adjusted using the **Lens** menu, or using the lens buttons on the remote control.

Lens menu

The **Lens** menu provides access to the **Lens Control** setting and the **Lens Center** command.

Lens Control allows **Zoom**, **Focus** and **Shift** adjustment using the arrow buttons. The setting operates in **Zoom/Focus Adjustment** and **Shift Adjustment** mode.

Press **ENTER/SELECT** to switch between the two modes.

Remote control

Use the remote control to adjust zoom, focus and shift directly, without opening a menu:

- **OK** enters lens control, then switches between **Zoom/Focus Adjustment** and **Shift Adjustment**.
- **EXIT** exits lens control and opens the **Lens** menu.
- **MENU** exits lens control and returns to the main image.
- The arrow buttons adjust zoom, focus and shift as indicated on the screen.

Adjusting the image

Orientation

- This can be set from the **Setup** menu.

Highlight **Orientation** and choose from **Front Tabletop**, **Front Ceiling**, **Rear Tabletop** and **Rear Ceiling**.


Keystone

- This can be set from the **Geometry** menu.

Picture

- Settings such as **Gamma**, **Brightness**, **Contrast**, **Saturation**, **Hue** and **Sharpness** can be set from the **Image** menu

Control Panel Reference



- 1 POWER**
Switches the projector on and off (STANDBY).
Indicator:
Off = the projector is switched off
Flashing green = the projector is warming up
Flashing blue = the projector is cooling down
On, red = STANDBY mode
On, green = the projector is switched on
- 2 INPUT**
Switches to the next input source.
- 3 AUTO SYNC**
Re-synchronises with the current input signal.
- 4 ASPECT**
Changes the aspect ratio.
- 5 CENTER LENS**
Centers the lens.
- 6 PIC MUTE**
Switches the laser off/on.
Indicator:
Off = the projector is in standby
On, blue = the projector is on, normal projection
On, red = the projector is on, picture mute is activated

7**LIGHT INDICATOR**

Off = light is switched off

Flashing red (cycles of single flashes) = failure to light up during power up

Flashing red (cycles of double flashes) = failure to light up

On, green = light is switched on

8**TEMP INDICATOR**

Off = no problem

Flashing red = temperature error

9**HOTKEYS**

User selectable functions.

Pre-set functions:

HOTKEY 1 Information

HOTKEY 2 Test Pattern

HOTKEY 3 Lens Memory Load

Additional options:

Picture Mode

Ambient Brightness Correction

Freeze

PIP Swap

10**STATUS**

Off = no problem

Flashing red (continuously) = cover error

Flashing red (cycles of four flashes) = fan error

On, red = system error

11**MENU**

Displays and exits the OSD.

12**Arrow buttons & ENTER**

Navigation buttons used to highlight menu entries in the OSD.

Press **ENTER** to open or execute the highlighted menu entry.

13**EXIT**

Exits the current OSD page and enters the level above.

14**LENS SHIFT arrow buttons**

Each of these buttons moves the lens in the specified direction.

15**FOCUS plus and minus buttons**


Used to move the focus in and out.

16**ZOOM plus and minus buttons**

Used to zoom in and out.

Remote Control Reference

- 1 Power ON/OFF**
Turns the projector on and off.
To turn the projector off, press the OFF button twice within five seconds.
- 2 Pic Mute OPEN / CLOSE**
Shows and hides the projected image.
- 3 OSD ON / OFF**
Enables and disables screen timeout messages and showing the OSD during projection.
- 4 MENU**
Access the projector OSD (on-screen display). If the OSD is open, press this button to go back to the previous menu.
- 5 Navigation (arrows and OK)**
Navigate through the menus with the arrows, confirm your choice with **OK**. In lens adjustment modes, the arrows are used to move, zoom or focus the lens. See **11** below.
In lens adjustment modes, or when the OSD is not showing, the **OK** button switches between modes: **Shift Adjustment** and **Zoom / Focus Adjustment**.
- 6 EXIT**
Close the current OSD page and return to the level above.
- 7 FREEZE**
Freeze the current frame.
- 8 DEFAULT**
Restore default settings.
- 9 INFO**
Access information about the projector.
- 10 RE-SYNC**
Re-synchronise with the current input signal.



11

LENS adjustment**FOCUS IN / OUT:** adjust focus.**SHIFT:** press and hold this button, then use the Navigation arrow buttons to move the lens.**ZOOM IN / OUT:** adjust zoom.

If focus cannot be achieved using the focus in / out feature, press Shift & 7 to adjust for far focus, or Shift & 8 to adjust for near focus.

12

USER PRESET A, B, C, D

Load user presets.

13

ALT

Press and hold this button to access alternative functions for all buttons with a green label.

14

DVI / DisplayPort2 / numeric input 3

There is no DVI input on this projector.

There is no DisplayPort2 input on this projector

15

HDMI 2 / HDMI 4 / numeric input 2

Select the HDMI 1 input.

Use with **ALT** to switch to the HDMI 4 input.

16

HDMI 1 / HDMI 3 / numeric input 1

Select the HDMI 1 input.

Use with **ALT** to switch to the HDMI 3 input.


17

TEST / SWAP / numeric input 0

Show a test pattern. Press again to show the next test pattern:

...Off, White, Black, Red, Green, Blue, Checkerboard, CrossHatch, V Burst, H Burst, ColorBar, Pluge...

Use with **ALT** to SWAP the Main and PIP displays.



18 DisplayPort 1 / R / numeric input 4

Select the DisplayPort 1 input.

Use with **ALT** to toggle the Red channel on and off

19 HD-T / G / numeric input 5

Select the HDBaseT input.

Use with **ALT** to toggle the Green channel on and off

20 SDI / B / numeric input 6

Select the 3G-SDI input.

Use with **ALT** to toggle the Blue channel on and off

21 VGA / 3D / numeric input 7

Select the VGA input.

Use with **ALT** to toggle the 3D Format setting between Off and Auto.

22 COMP1 / EYE / numeric input 8

There is no Component 1 input on this projector

Use with **ALT** to switch between left and right eye 3D dominance.

23 COMP2 / PIP / numeric input 9

There is no Component 2 input on this projector

Use with **ALT** to toggle the PIP window on and off.

24 ADDR / ALL

Assign and unassign an IR remote address.

To assign an address:

1. Press and hold this button until the indicator starts flashing.
2. Release this button and while the indicator is still flashing, enter a two-digit address using the numeric input buttons. The indicator will flash three times quickly to confirm the change.

To unassign an address and return to the default address 00,

- Press and hold **ALT** and this button simultaneously until the indicator flashes to confirm the change.

