

IR Code



| Customer code: 32CD | |
|---------------------|-------------------------|
| Key code | Printing-key definition |
| 81 | Power on/off |
| 3E | Switch |
| C3 | Source |
| 97 | User |
| C4 | Re-Sync |
| CB | L |
| CC | R |
| C6 | Up arrow |
| C8 | Left arrow |
| C9 | Right arrow |

| | |
|-----|--------------|
| C7 | Down arrow |
| C5 | Enter |
| CA | Enter |
| N/A | Laser |
| C1 | Page+ |
| 95 | Mode |
| C2 | Page- |
| 85 | Keystone+ |
| 84 | Keystone- |
| 8C | Volume + |
| 8F | Volume - |
| 87 | Brightness/1 |
| 88 | Menu/2 |
| 89 | Zoom/3 |
| 86 | HDMI/4 |
| 8B | Freeze/5 |
| 8A | AV mute/6 |
| 83 | S-Video/7 |
| 8E | VGA/8 |
| 8D | Video/9 |
| 96 | Eco* |
| 93 | 3D |

The IR codes below are for user-defined remote only.

| | |
|----|-------------------------|
| 79 | Power off (single push) |
| 82 | Power off |
| 80 | Power on |
| 9A | VGA2 |
| 99 | Network Display |
| 9E | DVI |
| 94 | Contrast |