





MODE

During Start-up

Status Led



_ see user manual 10000 Important Info

____ normal/eco/power

___ service information

- Do not block the ventilation in -and outlets. - Using the projector at a non recommended tilt angle will reduce the lifetime of the lamps or create unexpected behaviour of the unit. - Laser light can cause severe damage to the DMD. This damage is not covered by warranty.

and wait two minutes, then switch off the main power. - Ensure that the projector is operating with clean filters.