

2009/05/07

PLC-WTC500L IR Command List

- ☐ Transmission format of LCD projector operation key
: NEC Format (single command / command pipelining mode)
- ☐ Transmission format of PC mouse operation button (mouse cursor button) / L / R key
: Interlink Mouse Code Format (Includes 3 bit of ID)
- ☐ Format for the transmission of OSD Laser operation button (mouse cursor button)
: Interlink OSD Mouse Code Format (Includes 3 bit of ID)
- ☐ Custom Code + Custom Code
: 8 patterns as below
33h+00h(Default; code1),33h+11h(code2),33h+22h(code3),33h+33h(code4),
33h+44h(code5),33h+55h(code6),33h+66h(code7),33h+77h(code8)

Key No.	Data Code (HEX)	Function
S1	*1	L-CLICK Back-side Click Trigger Key
S2	11	ON
S3	10	OFF
S4	38	INPUT 1
S5	39	INPUT 2
S6	06	INPUT 3
S7	89	AUTO PC
S8	43	FREEZE
S9	16	INFO
S10	8C	CURSOR UP
S11	1E	CURSOR LEFT/VOLUME -
S12	1D	CURSOR RIGHT/VOLUME +
S13	8D	CURSOR DOWN
S14	1C	MENU
S15	0F	SELECT
S16	*1	R-CLICK
S17	8A	P-TIMER
S18	88	D. ZOOM
S19	82	SCREEN
S20	80	ZOOM
S21	87	FOCUS
S22	40	LENS SHIFT
S23	07	PIP
S24	5C	PIP VOL
S25	5B	KEYSTONE
S26	84/85 *2	LASER
S27	0B	MUTE
S28	8B	SHUTTER
SOB1	*1	Mouse Cursor button

*1... Transmit code for Mouse *2... Transmit code to set Laser Pointer / OSD Laser to ON/OFF