

Control Commands

PT-DZ12000*

PT-D12000*

PT-DW100*

Using the Serial Terminals

1. Basic Format

Transmission from the computer begins with STX, then the ID, command, parameter, and ETX are sent in this order. Add parameters according to the details of control.

Basic control command (without parameter)

Start (STX)	ID	Separator (semicolon)	Command	End (ETX)
1 byte	4 bytes	1 byte	3 bytes	1 byte

Basic control command (with parameters)

Start (STX)	ID	Separator (semicolon)	Command	Separator (colon)	Parameters	End (ETX)
1 byte	4 bytes	1 byte	3 bytes	1 byte	Undefined length	1 byte

Basic control command (with subcommand; numeric specification)

Start (STX)	ID	Separator (semicolon)	Command	Separator (colon)		
1 byte	4 bytes	1 byte	3 bytes	1 byte		
Subcommand		Operation	Sign	Parameters		End (ETX)
5 bytes		1 byte	1 byte	5 bytes		1 byte

Operation

Specifies method of processing the value specified by parameters.

Code	Description of processing
=	Sets the value specified by parameters.
_ (underbar)	Adds the value specified by parameters to the current value.

Sign

Specifies positive or negative of the value specified by parameters.

Code	Description
+	The value specified by parameters is a positive number (including 0).
-	The value specified by parameters is a negative number.

Parameters

Sets the setting or the adjustment value without zero suppression by the right justification of five digits. For example, set as "00001" when a setting value is 1.

Basic control command (with subcommand: character-string specification)

Start (STX)	ID	Separator (semicolon)	Command	Separator (colon)	
1 byte	4 bytes	1 byte	3 bytes	1 byte	
Subcommand		=	Parameters		End (ETX)
5 bytes		1 byte	Variable-length		1 byte

Parameters

The maximum length and the character that can be set vary depending on the kind of the subcommand. Moreover, the end of the character string is not NULL (00h) but ETX (03h).

ID of the basic control command

ID	4 bytes String	ID	4 bytes String	ID	4 bytes String	ID	4 bytes String
ALL	ADZZ	ID23	AD23	ID46	AD46	Group E	AD0E
ID1	AD01	ID24	AD24	ID47	AD47	Group F	AD0F
ID2	AD02	ID25	AD25	ID48	AD48	Group G	AD0G
ID3	AD03	ID26	AD26	ID49	AD49	Group H	AD0H
ID4	AD04	ID27	AD27	ID50	AD50	Group I	AD0I
ID5	AD05	ID28	AD28	ID51	AD51	Group J	AD0J
ID6	AD06	ID29	AD29	ID52	AD52	Group K	AD0K
ID7	AD07	ID30	AD30	ID53	AD53	Group L	AD0L
ID8	AD08	ID31	AD31	ID54	AD54	Group M	AD0M
ID9	AD09	ID32	AD32	ID55	AD55	Group N	AD0N
ID10	AD10	ID33	AD33	ID56	AD56	Group O	AD0O
ID11	AD11	ID34	AD34	ID57	AD57	Group P	AD0P
ID12	AD12	ID35	AD35	ID58	AD58	Group Q	AD0Q
ID13	AD13	ID36	AD36	ID59	AD59	Group R	AD0R
ID14	AD14	ID37	AD37	ID60	AD60	Group S	AD0S
ID15	AD15	ID38	AD38	ID61	AD61	Group T	AD0T
ID16	AD16	ID39	AD39	ID62	AD62	Group U	AD0U
ID17	AD17	ID40	AD40	ID63	AD63	Group V	AD0V
ID18	AD18	ID41	AD41	ID64	AD64	Group W	AD0W
ID19	AD19	ID42	AD42	Group A	AD0A	Group X	AD0X
ID20	AD20	ID43	AD43	Group B	AD0B	Group Y	AD0Y
ID21	AD21	ID44	AD44	Group C	AD0C	Group Z	AD0Z
ID22	AD22	ID45	AD45	Group D	AD0D		

Response (Callback) of the basic control command

In the period when commands can be accepted

Differs according to each command.

In the period when commands cannot be accepted

Hexadecimal	02h	45h	52h	34h	30h	31h	03h
Character		E	R	4	0	1	

In case of the parameter error

Hexadecimal	02h	45h	52h	34h	30h	32h	03h
Character		E	R	4	0	2	

Notes when two or more projectors are used

- Make the communication conditions the same between output/input. IN and OUT can be independently set respectively. (When you set RS-422 OUT of the first projector to 38 400 bps, set RS-422 IN of the second projector to 38 400 bps.)
- Make only one to RESPONSE(ID ALL) ON, and make all of the remainder to RESPONSE(ID ALL) OFF.
- Set ID number different in each projector.
- I/O to RS-422 OUT is not done during MAIN POWER OFF. Turn on MAIN POWER of all projectors.
- Make only one of the each group to RESPONSE(ID GROUP) ON, and make the remainder to RESPONSE(ID GROUP) OFF.

Attention:

- No command may be sent or received for 10 to 60 seconds after the lamp starts lighting. Try sending any command after that period has elapsed.
- When sending several commands, be sure to wait for a response from the projector, and send the next command after 0.5 seconds or more pass.
- It might take time by the time the response returns because the command is processed in the projector. Set the time-out to ten seconds or more.

Notes:

- This projector will respond to the computer only in the following cases:
 - If the sent ID coincides with the projector ID,
RESPONSE(ID ALL) in RS-232C settings of this projector is ON and the sent ID is ALL, or
 - If Group (A-Z) of the sent ID coincides with RS-232C settings of this projector and RESPONSE(ID GROUP) in RS-232C settings of this projector is OFF.
- When the command is received during STNDBY, this projector returns the receiving command as it is as a response (callback) if it is in the period when the concerned command cannot be accepted.
- Each setting/query command concerning P IN P controls operation for information on the user being set currently by the P IN P setting. Therefore, ER401 is returned as a response (callback) when the P IN P setting is OFF.

2. Basic Control Command

Explanatory notes

○: Yes (Enable)

×: No (Disable)

△: Case by case (Refer to the note.)

2.1. Power ON (Lamp ON)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	4Fh	4Eh	03h
Character		A	D	Z	Z	;	P	O	N	

■ Response (Callback)

In the period when the command can be accepted (This command in power-on condition is included)

Hexadecimal	02h	50h	4Fh	4Eh	03h
Character		P	O	N	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	△

■ Notes:

- When you confirm whether to have succeeded in power-on, confirm it by QPW (query power condition) command after receiving the callback of PON command.
- When REMOTE2 is effective, ER401 is returned as a response (callback).

2.2. Power OFF (Standby)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	4Fh	46h	03h
Character		A	D	Z	Z	;	P	O	F	

■ Response (Callback)

In the period when the command can be accepted (This command in power-off condition is included)

Hexadecimal	02h	50h	4Fh	46h	03h
Character		P	O	F	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	△

■ Notes:

- When you confirm whether to have succeeded in power-off, confirm it by QPW (Query Power) command after receiving the callback of POF command.
- When REMOTE2 is effective, ER401 is returned as a response (callback).

2.3. AUTO SETUP

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	53h	03h
Character		A	D	Z	Z	;	O	A	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	53h	03h
Character		O	A	S	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	×	○	×	○

■ Note:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB PC signals are input. In other cases, ER401 is returned.

2.4. SHUTTER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	48h	3Ah	*1	03h
Character		A	D	Z	Z	;	O	S	H	:	*2	

■ Parameters (*1, *2)

	Shutter OFF	Shutter ON
Hexadecimal	30h	31h
Character	0	1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	48h	3Ah	*1	03h
Character		O	S	H	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	△

■ Note:

- The setting by REMOTE2 is given to priority. When a command different from the setting of REMOTE2 is sent, ER402 is returned.

2.5. Freeze

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	46h	5Ah	3Ah	*1	03h
Character		A	D	Z	Z	;	O	F	Z	:	*2	

■ Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	5Ah	3Ah	*1	03h
Character		O	F	Z	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	×	○	○	○

2.6. Input Change

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	49h	49h	53h	3Ah	*1	*3	*5	03h
Character		A	D	Z	Z	;	I	I	S	:	*2	*4	*6	

■ Parameters (*1, *2, *3, *4, *5, *6)

	RGB1			RGB2		
Hexadecimal	52h	47h	31h	52h	47h	32h
Character	R	G	1	R	G	2
	VIDEO			S-VIDEO		
Hexadecimal	56h	49h	44h	53h	56h	44h
Character	V	I	D	S	V	D
	DVI			AUX		
Hexadecimal	44h	56h	49h	41h	55h	58h
Character	D	V	I	A	U	X

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	49h	49h	53h	3Ah	*1	*3	*5	03h
Character		I	I	S	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	○	○	△

■ Notes:

- REMOTE2 is given to priority. Calls back ER402 if the input select of REMOTE2 is available.
- When AUX is specified for the parameter with incompatible input module installed in the slot, ER401 is returned.
- When AUX is specified for the parameter with no input module installed in the slot, ER402 is returned.

2.7. TEST PATTERN

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	54h	53h	3Ah	*1	*3	03h
Character		A	D	Z	Z	;	O	T	S	:	*2	*4	

■ Parameters (*1, *2, *3, *4)

	OFF		White		Black		Flag		Reversed flag	
Hexadecimal	30h	30h	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	0	0	1	0	2	0	3	0	4
	Window		Reversed window		Focus		Colorbar		Gray 1 (20% brightness)	
Hexadecimal	30h	35h	30h	36h	30h	37h	30h	38h	31h	30h
Character	0	5	0	6	0	7	0	8	1	0
	Ramp		White		Red		Green		Blue	
Hexadecimal	31h	31h	32h	31h	32h	32h	32	33	32h	34h
Character	1	1	2	1	2	2	2	3	2	4
	10% brightness (White)		5% brightness (White)		Cyan		Magenta		Yellow	
Hexadecimal	32h	35h	32h	36h	32h	38h	32h	39h	33h	30h
Character	2	5	2	6	2	8	2	9	3	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	54h	53h	3Ah	*1	*3	03h
Character		O	T	S	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

2.8. ON SCREEN

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Fh	53h	3Ah	*1	03h
Character		A	D	Z	Z	;	O	O	S	:	*2	

■ Parameters (*1, *2)

	Shutter OFF		Shutter ON	
Hexadecimal	30h		31h	
Character	0		1	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Fh	53h	3Ah	*1	03h
Character		O	O	S	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	×	○	○	○

■ Note:

- When the display setting of SECURITY is not OFF, ER401 is returned.

2.9. MENU key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Dh	4Eh	03h
Character		A	D	Z	Z	;	O	M	N	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Dh	4Eh	03h
Character		O	M	N	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	×	○	○	○

2.10. ENTER key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	4Eh	03h
Character		A	D	Z	Z	;	O	E	N	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	4Eh	03h
Character		O	E	N	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	×	○	○	○

2.11. Up (↑) key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	55h	03h
Character		A	D	Z	Z	;	O	C	U	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	55h	03h
Character		O	C	U	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	×	○	○	○

2.12. Down (↓) key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	44h	03h
Character		A	D	Z	Z	;	O	C	D	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	44h	03h
Character		O	C	D	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	×	○	○	○

2.13. Left (←) key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	4Ch	03h
Character		A	D	Z	Z	;	O	C	L	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	4Ch	03h
Character		O	C	L	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	×	○	○	○

2.14. Right (→) key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	52h	03h
Character		A	D	Z	Z	;	O	C	R	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	52h	03h
Character		O	C	R	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	×	○	○	○

2.15. DEFAULT key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	54h	03h
Character		A	D	Z	Z	;	O	S	T	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	54h	03h
Character		O	S	T	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	×	○	○	○

2.16. FUNC1 key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	46h	43h	31h	03h
Character		A	D	Z	Z	;	F	C	1	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	46h	43h	31h	03h
Character		F	C	1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	△	△	○	△	△

■ Note:

- The acceptability conforms to the function allocated in FUNC1.

2.17. SYSTEM SELECTOR

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	4Ch	03h
Character		A	D	Z	Z	;	O	S	L	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	4Ch	03h
Character		O	S	L	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	○	○	○

■ Note:

- When the input signal is not switchable, ER401 is returned.

2.18. ASPECT key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	31h	03h
Character		A	D	Z	Z	;	V	S	1	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	31h	03h
Character		V	S	1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	×	○	○	○

2.19. Numeric key

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Eh	4Bh	3Ah	*1	03h
Character		A	D	Z	Z	;	O	N	K	:	*2	

■ Parameters (*1, *2)

	0 key	1 key	2 key	3 key	4 key	5 key	6 key	7 key	8 key	9 key
Hexadecimal	30h	31h	32h	33h	34h	35h	36h	37h	38h	39h
Character	0	1	2	3	4	5	6	7	8	9

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Eh	4Bh	3Ah	*1	03h
Character		O	N	K	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	×	○	○	○

2.20. LAMP SELECT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Ch	50h	4Dh	3Ah	*1	*3	03h
Character		A	D	Z	Z	;	L	P	M	:	*2	*4	

Parameters (*1, *2, *3, *4)

	QUAD		L1/L4		L2/L3		DUAL		L1/L2/L3	
Hexadecimal	30h	30h	30h	31h	30h	32h	33h	33h	30h	34h
Character	0	0	0	1	0	2	0	3	0	4
	L1/L2/L4		L1/L3/L4		L2/L3/L4		TRIPLE		L1	
Hexadecimal	30h	35h	30h	36h	30h	37h	30h	38h	30h	39h
Character	0	5	0	6	0	7	0	8	0	9
	L2		L3		L4		SINGLE			
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h		
Character	1	0	1	1	1	2	1	3		

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Ch	50h	4Dh	3Ah	*1	*3	03h
Character		L	P	M	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

Note:

- During the lamp change processing, ER401 is returned.

2.21. INSTALLATION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	49h	4Ch	3Ah	*1	03h
Character		A	D	Z	Z	;	O	I	L	:	*2	

Parameters (*1, *2)

	FRONT-FLOOR		REAR-FLOOR		FRONT-CEILING		REAR-CEILING	
Hexadecimal	30h		31h		32h		33h	
Character	0		1		2		3	

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	49h	4Ch	3Ah	*1	03h
Character		O	I	L	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

2.22. FUNC1

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	46h	43h	3Ah
Character		A	D	Z	Z	;	O	F	C	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

Parameters (*1, *2, *3, *4)

	P IN P		SUB MEMORY		SYSTEM SELECTOR	
Hexadecimal	30h		32h		34h	
Character	0		2		4	
	SYSTEM DAYLIGHT VIEW		FREEZE		DISABLE	
Hexadecimal	35h		36h		2Dh	31h
Character	5		6		-	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	43h	3Ah	*1	*3	03h
Character		O	F	C	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	○	○	○

Note:

- Parameters *3 and *4 are specified only in case of two digits.

2.23. SUB MEMORY CHANGE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	53h	3Ah
Character		A	D	Z	Z	;	O	C	S	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

■ Parameters (*1, *2, *3, *4)

*nn of submemory number (mm-nn)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	93		94		95		96	
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	53h	3Ah	*1	*3	03h
Character		O	C	S	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

2.24. SUB MEMORY CHANGE (Enhanced)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	53h	3Ah
Character		A	D	Z	Z	;	O	C	S	:
Hexadecimal	*1	*3	2Dh	*5	*7	03h				
Character	*2	*4	-	*6	*8					

■ Parameters

mm of submemory number (mm-nn) (*1, *2, *3, *4)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	92		93		94		95	
Hexadecimal	39h	32h	39h	33h	39h	34h	39h	35h
Character	9	2	9	3	9	4	9	5

nn of submemory number (mm-nn) (*5, *6, *7, *8)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	93		94		95		96	
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	53h	3Ah	*1	*3	2Dh	*5	*7	03h
Character		O	C	S	:	*2	*4	-	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

2.25. SUB MEMORY STORE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	53h	03h
Character		A	D	Z	Z	;	O	E	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	53h	03h
Character		O	E	S	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

2.26. SUB MEMORY DELETE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	44h	53h	3Ah
Character		A	D	Z	Z	;	O	D	S	:
Hexadecimal	*1	*3	2Dh	*5	*7	03h				
Character	*2	*4	-	*6	*8					

■ Parameters (*1, *2, *3, *4, *5, *6)

mm of submemory number (mm-nn) (*1,*2)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	92		93		94		95	
Hexadecimal	39h	32h	39h	33h	39h	34h	39h	35h
Character	9	2	9	3	9	4	9	5

nn of submemory number (mm-nn) (*3,*4)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	93		94		95		96	
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	44h	53h	3Ah	*1	*3	2Dh	*5	*7	03h
Character		O	D	S	:	*2	*4	-	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.27. PICTURE MODE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	50h	4Dh	3Ah
Character		A	D	Z	Z	;	V	P	M	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	DYNAMIC			GRAPHIC			USER		
Hexadecimal	44h	59h	4Eh	47h	52h	41h	55h	53h	52h
Character	D	Y	N	G	R	A	U	S	R
	STANDARD			CINEMA			NATURAL		
Hexadecimal	53h	54h	44h	43h	49h	4Eh	4Eh	41h	54h
Character	S	T	D	C	I	N	N	A	T

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	50h	4Dh	3Ah	*1	*3	*5	03h
Character		V	P	M	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.28. COLOR

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	43h	4Fh	3Ah
Character		A	D	Z	Z	;	V	C	O	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	-50			-49			-48		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	48			49			50		
Hexadecimal	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	8	0	9	9	1	0	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	4Fh	3Ah	*1	*3	*5	03h
Character		V	C	O	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Note:

- It is displayed in the menu by the value in which 50 is subtracted from the specified value.

2.29. TINT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	4Eh	3Ah
Character		A	D	Z	Z	;	V	T	N	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	-31			-30			-29		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29			30			31		
Hexadecimal	30h	36h	30h	30h	36h	31h	30h	36h	32h
Character	0	6	0	0	6	1	0	6	2

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	4Eh	3Ah	*1	*3	*5	03h
Character		V	T	N	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Note:

- It is displayed in the menu by the value in which 31 is subtracted from the specified value.

2.30. COLOR TEMP.

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	54h	45h	3Ah
Character		A	D	Z	Z	;	O	T	E	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

■ Parameters (*1, *2, *3, *4)

	LOW	MIDDLE	HIGH	USER1	USER2	DEFAULT
Hexadecimal	30h	31h	32h	34h	39h	31h 30h
Character	0	1	2	4	9	1 0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	54h	45h	3Ah	*1	*3	03h
Character		O	T	E	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- If you specify parameters other than USER1 when COLOR MATCHING is not OFF, ER402 is returned.

2.31. WHITE BALANCE LOW - R

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Fh	52h	3Ah
Character		A	D	Z	Z	;	V	O	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Fh	52h	3Ah	*1	*3	*5	03h
Character		V	O	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.
- It is displayed in the menu by the value in which 128 is subtracted from the specified value.

2.32. WHITE BALANCE LOW - G

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Fh	47h	3Ah
Character		A	D	Z	Z	;	V	O	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Fh	47h	3Ah	*1	*3	*5	03h
Character		V	O	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.
- It is displayed in the menu by the value in which 128 is subtracted from the specified value.

2.33. WHITE BALANCE LOW - B

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Fh	42h	3Ah
Character		A	D	Z	Z	;	V	O	B	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Fh	42h	3Ah	*1	*3	*5	03h
Character		V	O	B	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Notes:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.
- It is displayed in the menu by the value in which 128 is subtracted from the specified value.

2.34. WHITE BALANCE HIGH - R

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	48h	52h	3Ah
Character		A	D	Z	Z	;	V	H	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	52h	3Ah	*1	*3	*5	03h
Character		V	H	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.

2.35. WHITE BALANCE HIGH - G

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	48h	47h	3Ah
Character		A	D	Z	Z	;	V	H	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	47h	3Ah	*1	*3	*5	03h
Character		V	H	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.

2.36. WHITE BALANCE HIGH - B

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	48h	42h	3Ah
Character		A	D	Z	Z	;	V	H	B	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	42h	3Ah	*1	*3	*5	03h
Character		V	H	B	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP, ER401 is returned.

2.37. CONTRAST

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	43h	4Eh	3Ah
Character		A	D	Z	Z	;	V	C	N	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	29			30			31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	4Eh	3Ah	*1	*3	*5	03h
Character		V	C	N	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Note:

- It is displayed in the menu by the value in which 32 is subtracted from the specified value.

2.38. BRIGHTNESS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	42h	52h	3Ah
Character		A	D	Z	Z	;	V	B	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	31h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	29			30			31		
Hexadecimal	30h	36h	30h	30h	36h	31h	30h	36h	32h
Character	0	6	1	0	6	2	0	6	3

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	42h	52h	3Ah	*1	*3	*5	03h
Character		V	B	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Note:

- It is displayed in the menu by the value in which 32 is subtracted from the specified value.

2.39. SYSTEM DAYLIGHT VIEW

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	4Ch	56h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	D	L	V	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	2					3				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Ch	56h	49h	30h
Character		V	X	X	:	D	L	V	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.40. SHARPNESS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	52h	3Ah
Character		A	D	Z	Z	;	V	S	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal	30h	31h	33h	30h	31h	34h	30h	31h	35h
Character	0	1	3	0	1	4	0	1	5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	52h	3Ah	*1	*3	*5	03h
Character		V	S	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

2.41. NOISE REDUCTION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Eh	53h	3Ah
Character		A	D	Z	Z	;	V	N	S	:
Hexadecimal	*1	03h								
Character	*2									

■ Parameters (*1, *2)

	OFF		ON or 1		2		3	
Hexadecimal	30h		31h		32h		33h	
Character	0		1		2		3	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Eh	53h	3Ah	*1	03h
Character		V	N	S	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Notes:

- When FRAME DELAY is set to SHORT, ER401 is returned.
- During P IN P, ER401 is returned.

2.42. DYNAMIC IRIS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2)

Mode

	OFF	1	2	3	USER	AUTO IRIS	MANUAL IRIS	DYNAMIC GAMMA
Hexadecimal	30h	31h	32h	33h	34h	41h	4Dh	44h
Character	0	1	2	3	4	A	M	D

* When Mode is OFF - USER, parameters *3 - *6 are not sent.

Example: When you set USER into Mode

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	34h	03h
Character		A	D	Z	Z	;	O	A	I	4	

* When Mode is AUTO IRIS or DYNAMIC GAMMA, parameters *5 and *6 are not sent.

Example: When Mode is AUTO IRIS and you set 3 into AUTO IRIS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	41h	33h	03h							
Character	A	3								

Example: When Mode is MANUAL IRIS and you set 30 into MANUAL IRIS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	4Dh	33h	30h	03h						
Character	M	3	0							

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	*1	03h
Character		O	A	I	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.43. DYNAMIC IRIS (AUTO IRIS)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	41h	*1	03h							
Character	A	*2								

Parameters (*1, *2)

	OFF	1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	41h	*1	03h
Character		O	A	I	:	A	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.44. DYNAMIC IRIS (MANUAL IRIS)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	4Dh	*1	*3	03h						
Character	M	*2	*4							

Parameters (*1, *2, *3, *4)

	OFF		1		2		3	
Hexadecimal	30h	30h	30h	31h	30h	32h	30h	33h
Character	0	0	0	1	0	2	0	3
	60		61		62		63	
Hexadecimal	36h	30h	36h	31h	36h	32h	36h	33h
Character	6	0	6	1	6	2	6	3

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	4Dh	*1	03h
Character		O	A	I	:	M	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.45. DYNAMIC IRIS (DYNAMIC GAMMA)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	44h	*1	03h							
Character	D	*2								

Parameters (*1, *2)

	OFF		1		2		3	
Hexadecimal	30h		31h		32h		33h	
Character	0		1		2		3	

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	44h	*1	03h
Character		O	A	I	:	D	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.46. TV-SYSTEM

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	47h	3Ah
Character		A	D	Z	Z	;	V	S	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	AUTO1			AUTO2			NTSC		
Hexadecimal	41h	54h	31h	41h	54h	32h	4Eh	54h	53h
Character	A	T	1	A	T	2	N	T	S
	NTSC4.43			PAL			PAL-M		
Hexadecimal	4Eh	34h	34h	50h	41h	4Ch	50h	41h	4Dh
Character	N	4	4	P	A	L	P	A	M
	PAL-N			SECAM			PAL60		
Hexadecimal	50h	41h	4Eh	53h	45h	43h	50h	36h	30h
Character	P	A	N	S	E	C	P	6	0

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	47h	3Ah	*1	*3	*5	03h
Character		V	S	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.47. SHIFT H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	48h	3Ah
Character		A	D	Z	Z	;	V	T	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	0				1				2			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	2
Character	0	0	0	0	0	0	0	1	0	0	0	2
	4093				4094				4095			
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	3	4	0	9	4	4	0	9	5

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	48h	3Ah	*1	*3	*5	03h
Character		V	T	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Note:

- The maximum value that can be actually set changes according to the input signal and the input resolution setting, etc.

2.48. SHIFT V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	56h	3Ah
Character		A	D	Z	Z	;	V	T	V	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0				1				2			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	1	0	0	0	2
	4093				4094				4095			
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	3	4	0	9	4	4	0	9	5

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	56h	3Ah	*1	*3	*5	03h
Character		V	T	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Notes:

- The maximum value that can be actually set changes according to the input signal and the input resolution setting, etc.
- When a value of the odd number is specified for the interlace signal, the specified value is returned as a response (callback) though the value to which 1 is subtracted is set.

2.49. ASPECT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	45h	3Ah
Character		A	D	Z	Z	:	V	S	E	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

■ Parameters (*1, *2, *3, *4)

- Input route: VIDEO

Input signal: NTSC

	VID AUTO	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

- Input route: VIDEO

Input signal: Except NTSC

	DEFAULT	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

- Input route: S-VIDEO

Input signal: NTSC

	VID AUTO(PRI)	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT	S1 AUTO
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0
	VID AUTO			
Hexadecimal	33h	30h		
Character	3	0		

- Input route: S-VIDEO

Input signal: Except NTSC

	DEFAULT	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

- Input route: Except VIDEO/S-VIDEO

	DEFAULT	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	45h	3Ah	*1	*3	03h
Character		V	S	E	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

■ Notes:

- When it is not able to set it according to the input signal, ER402 is returned.
- Parameters *3 and *4 are specified only in case of two digits.

2.50. ZOOM H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	48h	3Ah
Character		A	D	Z	Z	;	O	Z	H	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	48h	3Ah	*1	*3	*5	03h
Character		O	Z	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Note:

- When ASPECT is THROUGH, ER401 is returned.

2.51. ZOOM V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	56h	3Ah	*1	*3	*5	03h
Character		A	D	Z	Z	;	O	Z	V	:	*2	*4	*6	

Parameters (*1, *2, *3, *4, *5, *6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	56h	3Ah	*1	*3	*5	03h
Character		O	Z	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Note:

- When ASPECT is THROUGH, ER401 is returned.

2.52. ZOOM HV

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	4Fh	3Ah
Character		A	D	Z	Z	;	O	Z	O	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	4Fh	3Ah	*1	*3	*5	03h
Character		O	Z	O	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Note:

- When ASPECT is THROUGH, ER401 is returned.

2.53. INTERLOCKED ZOOM

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	53h	3Ah	*1	03h
Character		A	D	Z	Z	;	O	Z	S	:	*2	

Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	53h	3Ah	*1	03h
Character		O	Z	S	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Note:

- When ASPECT is THROUGH, ER401 is returned.

2.54. CLOCK PHASE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	43h	50h	3Ah
Character		A	D	Z	Z	;	V	C	P	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29			30			31		
Hexadecimal	30h	32h	39h	30h	33h	30h	30h	33h	31h
Character	0	2	9	0	3	0	0	3	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	50h	3Ah	*1	*3	*5	03h
Character		V	C	P	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	×	○

Note:

- It is able to accept only when the selected slot is RGB1 or RGB2, and ER401 is returned besides.

2.55. INPUT RESOLUTION - TOTAL DOTS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	44h	3Ah
Character		A	D	Z	Z	;	V	T	D	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	301				302				
Hexadecimal	30h	33h	30h	31h	30h	33h	30h	32h	
Character	0	3	0	1	0	3	0	2	
	4094				4095				
Hexadecimal	34h	30h	39h	34h	34h	30h	39h	35h	
Character	4	0	9	4	4	0	9	5	

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	44h	3Ah	*1	*3	*5	*7	03h
Character		V	T	D	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

Notes:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.
- The maximum value that can be actually set changes according to the input signal and the input resolution setting, etc.
- When less than number of display dots is specified, ER402 is returned.

2.56. INPUT RESOLUTION - DISPLAY DOTS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	44h	44h	3Ah
Character		A	D	Z	Z	;	V	D	D	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	300				301			
Hexadecimal	30h	33h	30h	30h	30h	33h	30h	31h
Character	0	3	0	0	0	3	0	1
	2047				2048			
Hexadecimal	32h	30h	34h	37h	32h	30h	34h	38h
Character	2	0	4	7	2	0	4	8

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	44h	44h	3Ah	*1	*3	*5	*7	03h
Character		V	D	D	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Notes:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.
- When the value that exceeds the number of total dots is specified, ER402 is returned.

2.57. INPUT RESOLUTION - TOTAL LINES

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	4Ch	3Ah
Character		A	D	Z	Z	;	V	T	L	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	221				222			
Hexadecimal	30h	32h	31h	31h	30h	32h	31h	32h
Character	0	2	1	1	0	2	1	2
	4094				4095			
Hexadecimal	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	4	4	0	9	5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	4Ch	3Ah	*1	*3	*5	*7	03h
Character		V	T	L	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

■ Notes:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.
- When less than number of display lines is specified, ER402 is returned.

2.58. INPUT RESOLUTION - DISPLAY LINES

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	44h	4Ch	3Ah
Character		A	D	Z	Z	;	V	D	L	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	220				221			
Hexadecimal	30h	32h	32h	30h	30h	32h	32h	31h
Character	0	2	2	0	0	2	2	1
	4093				4094			
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h
Character	4	0	9	3	4	0	9	4

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	44h	4Ch	3Ah	*1	*3	*5	*7	03h
Character		V	D	L	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

Notes:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.
- When the value that exceeds the number of total lines is specified, ER402 is returned.

2.59. CLAMP POSITION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ch	54h	3Ah	*1	*3	*5	03h
Character		A	D	Z	Z	;	V	L	T	:	*2	*4	*6	

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ch	54h	3Ah	*1	*3	*5	03h
Character		V	L	T	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	×	○	×	○	○

Note:

- It is able to accept only when RGB1 or RGB2 is selected, and ER401 is returned besides.

2.60. KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Bh	53h	3Ah
Character		A	D	Z	Z	;	O	K	S	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	-127				-126				-125			
Hexadecimal	2Dh	31h	32h	37h	2Dh	31h	32h	36h	2Dh	31h	32h	35h
Character	-	1	2	7	-	1	2	6	-	1	2	5
	+125				+126				+127			
Hexadecimal	2Bh	31h	32h	35h	2Bh	31h	32h	36h	2Bh	31h	32h	37h
Character	+	1	2	5	+	1	2	6	+	1	2	7

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Bh	53h	3Ah	*1	*3	*5	*7	03h
Character		O	K	S	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- For PT-DZ12000*/D12000*, ER401 is returned.

2.61. SUB KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	4Bh	3Ah
Character		A	D	Z	Z	;	O	S	K	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	-127				-126				-125			
Hexadecimal	2Dh	31h	32h	37h	2Dh	31h	32h	36h	2Dh	31h	32h	35h
Character	-	1	2	7	-	1	2	6	-	1	2	5
	+125				+126				+127			
Hexadecimal	2Bh	31h	32h	35h	2Bh	31h	32h	36h	2Bh	31h	32h	37h
Character	+	1	2	5	+	1	2	6	+	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	4Bh	3Ah	*1	*3	*5	*7	03h
Character		O	S	K	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- For PT-DZ12000*/D12000*, ER401 is returned.
- When 0 is set into KEYSTONE, ER401 is returned.
- Even if SUB KEYSTONE value is changed, it might not operate according to KEYSTONE condition.

2.62. LINEARITY

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ch	49h	3Ah
Character		A	D	Z	Z	;	V	L	I	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	-127				-126				-125			
Hexadecimal	2Dh	31h	32h	37h	2Dh	31h	32h	36h	2Dh	31h	32h	35h
Character	-	1	2	7	-	1	2	6	-	1	2	5
	+125				+126				+127			
Hexadecimal	2Bh	31h	32h	35h	2Bh	31h	32h	36h	2Bh	31h	32h	37h
Character	+	1	2	5	+	1	2	6	+	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ch	49h	3Ah	*1	*3	*5	*7	03h
Character		V	L	I	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- For PT-DZ12000*/D12000*, ER401 is returned.
- When 0 is set into KEYSTONE, ER401 is returned.
- Even if LINEARITY value is changed, it might not operate according to KEYSTONE condition.

2.63. GEOMETRY

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Dh	49h	30h	3Dh	2Bh	*1	*3	*5
Character	G	M	M	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					KEYSTONE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	CURVED					PC				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Dh	49h	30h
Character		V	X	X	:	G	M	M	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.64. GEOMETRY:KEYSTONE - V-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	31h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	1	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	31h
Character		V	X	X	:	G	M	K	I	1
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.65. GEOMETRY:KEYSTONE - V-SUB-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	32h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	2	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	32h
Character		V	X	X	:	G	M	K	I	2
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- For PT-DW100*, ER401 is returned.
- When 0 is set into GEOMETRY:KEYSTONE - V-KEYSTONE, ER401 is returned.

2.66. GEOMETRY:KEYSTONE - H-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	35h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	5	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	35h
Character		V	X	X	:	G	M	K	I	5
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.67. GEOMETRY:KEystone - H-SUB-KEystone

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	36h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	36h
Character		V	X	X	:	G	M	K	I	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- For PT-DW100*, ER401 is returned.
- When 0 is set into GEOMETRY:KEystone - H-KEystone, ER401 is returned.

2.68. GEOMETRY:KEystone - LINEARITY

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	33h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	3	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	33h
Character		V	X	X	:	G	M	K	I	3
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.69. GEOMETRY:CURVED - LENS THROW RATIO

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	53h	30h	3Dh	*1	*3	*5	*7
Character	G	M	C	S	0	=	*2	*4	*6	*8
Hexadecimal	*9	03h								
Character	*10									

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0.7					0.9				
Hexadecimal	30h	2Eh	37h	30h	30h	2Eh	39h	30h		
Character	0	.	7	0	0	.	9	0		
	16.4					16.5				
Hexadecimal	31h	36h	2Eh	34h	30h	31h	36h	2E	35h	30h
Character	1	6	.	4	0	1	6	.	5	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	53h	30h
Character		V	X	X	:	G	M	C	S	0
Hexadecimal	3Dh	*1	*3	*5	*7	*9	03h			
Character	=	*2	*4	*6	*8	*10				

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Notes:

- For PT-DW100*, ER401 is returned.
- Characters that can be specified are only a figure and a period (decimal point).
- The parameter is able to specify it from 0.70 to 16.50 at intervals of 0.10.
- The parameter length is variable.
- When the following parameters are specified, ER402 is returned.
 - 1) Integer part is omitted
 - 2) Figures below decimal point are omitted
 - 3) 3 digits or more below the decimal point are specified

2.70. GEOMETRY:CURVED - V-SUB-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	31h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	1	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	30h
Character		V	X	X	:	G	M	C	I	1
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.71. GEOMETRY:CURVED - H-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	35h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	5	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	32h
Character		V	X	X	:	G	M	C	I	2
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.72. GEOMETRY:CURVED - V ARC

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	33h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	3	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	33h
Character		V	X	X	:	G	M	C	I	3
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.73. GEOMETRY:CURVED - H ARC

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	37h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	36h
Character		V	X	X	:	G	M	C	I	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.74. GEOMETRY:CURVED - V BALANCE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	32h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	2	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	32h
Character		V	X	X	:	G	M	C	I	2
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.75. GEOMETRY:CURVED - H BALANCE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	36h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

-127							-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
126							127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	36h
Character		V	X	X	:	G	M	C	I	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- For PT-DW100*, ER401 is returned.

2.76. DISPLAY LANGUAGE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Ch	47h	3Ah
Character		A	D	Z	Z	;	O	L	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

English			German			French			
Hexadecimal	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
Character	E	N	G	D	E	U	F	R	A
Spanish			Italian			Japanese			
Hexadecimal	45h	53h	50h	49h	54h	4Ch	4Ah	50H	4Eh
Character	E	S	P	I	T	L	J	P	N
Chinese			Russian			Korean			
Hexadecimal	43h	48h	49h	52h	55h	53h	4Bh	4Fh	52h
Character	C	H	I	R	U	S	K	O	R

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	47h	3Ah	*1	*3	*5	03h
Character		O	L	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

2.77. BLANKING - UPPER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	55h	3Ah
Character		A	D	Z	Z	:	D	B	U	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	598			599			600		
Hexadecimal	35h	39h	38h	35h	39h	39h	36h	30h	30h
Character	5	9	8	5	9	9	6	0	0

D12000

	523			524			525		
Hexadecimal	35h	32h	33h	35h	32h	34h	35h	32h	35h
Character	5	2	3	5	2	4	5	2	5

DW100

	382			383			384		
Hexadecimal	33h	38h	32h	33h	38h	33h	33h	38h	34h
Character	3	8	2	3	8	3	3	8	4

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	55h	3Ah	*1	*3	*5	03h
Character		D	B	U	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- The maximum value that can be set changes according to the setting condition of the input signal, ASPECT and ZOOM.

2.78. BLANKING - LOWER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	42h	3Ah
Character		A	D	Z	Z	:	D	B	B	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	598			599			600		
Hexadecimal	35h	39h	38h	35h	39h	39h	36h	30h	30h
Character	5	9	8	5	9	9	6	0	0

D12000

	523			524			525		
Hexadecimal	35h	32h	33h	35h	32h	34h	35h	32h	35h
Character	5	2	3	5	2	4	5	2	5

DW100

	382			383			384		
Hexadecimal	33h	38h	32h	33h	38h	33h	33h	38h	34h
Character	3	8	2	3	8	3	3	8	4

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	42h	3Ah	*1	*3	*5	03h
Character		D	B	B	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- The maximum value that can be set changes according to the setting condition of the input signal, ASPECT and ZOOM.

2.79. BLANKING - LEFT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	4Ch	3Ah
Character		A	D	Z	Z	;	D	B	L	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	958			959			960		
Hexadecimal	39h	35h	38h	39h	35h	39h	39h	36h	30h
Character	9	5	8	9	5	9	9	6	0

D12000

	698			699			700		
Hexadecimal	36h	39h	38h	36h	39h	39h	37h	30h	30h
Character	6	9	8	6	9	9	7	0	0

DW100

	681			682			683		
Hexadecimal	36h	38h	31h	36h	38h	32h	36h	38h	33h
Character	6	8	1	6	8	2	6	8	3

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	4Ch	3Ah	*1	*3	*5	03h
Character		D	B	L	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- The maximum value that can be set changes according to the setting condition of the input signal, ASPECT and ZOOM.

2.80. BLANKING - RIGHT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	52h	3Ah
Character		A	D	Z	Z	;	D	B	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	958			959			960		
Hexadecimal	39h	35h	38h	39h	35h	39h	39h	36h	30h
Character	9	5	8	9	5	9	9	6	0

D12000

	698			699			700		
Hexadecimal	36h	39h	38h	36h	39h	39h	37h	30h	30h
Character	6	9	8	6	9	9	7	0	0

DW100

	681			682			683		
Hexadecimal	36h	38h	31h	36h	38h	32h	36h	38h	33h
Character	6	8	1	6	8	2	6	8	3

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	52h	3Ah	*1	*3	*5	03h
Character		D	B	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- The maximum value that can be set changes according to the setting condition of the input signal, ASPECT and ZOOM.

2.81. EDGE BLENDING

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	44h	42h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	E	D	B	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					ON				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	USER									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	44h	42h	49h	30h
Character		V	X	X	:	E	D	B	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

2.82. SCREEN FORMAT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	46h	3Ah
Character		A	D	Z	Z	;	V	S	F	:
Hexadecimal	*1	03h								
Character	*2									

■ Parameters (*1, *2)

	16:10 *1		16:9		4:3 *2	
Hexadecimal	30h		31h		32h	
Character	0		1		2	

1: Able to specify only for PT-DZ12000.

2: Able to specify only for PT-D12000.

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	46h	3Ah	*1	03h
Character		V	S	F	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- If set for PT-DW100*, ER401 is returned.

2.83. SCREEN POSITION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	56h	53h	50h	49h	30h	3Dh	*1	*3	*5	*7
Character	V	S	P	I	0	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)
DZ12000

	-60						-59					
Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h	39h
Character	-	0	0	0	6	0	-	0	0	0	5	9
	59						60					
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	36h	30h
Character	+	0	0	0	5	9	+	0	0	0	6	0

D12000

	-132						-131					
Hexadecimal	2Dh	30h	30h	31h	33h	32h	2Dh	30h	30h	31h	33h	31h
Character	-	0	0	1	3	2	-	0	0	1	3	1
	130						131					
Hexadecimal	2Bh	30h	30h	31h	33h	30h	2Bh	30h	30h	31h	33h	31h
Character	+	0	0	1	3	0	+	0	0	1	3	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	56h	53h	50h	49h	30h
Character		V	X	X	:	V	S	P	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

- Notes:

- If set for PT-DW100*, ER401 is returned.
- When a format except 16:9 is specified for SCREEN FORMAT, ER401 is returned.

2.84. DVI EDID

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	4Ch	3Ah	*1	03h
Character		A	D	Z	Z	;	O	E	D	:	*2	

- Parameters (*1, *2)

	EDID1	EDID2 (PC)
Hexadecimal	31h	32h
Character	1	2

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	4Ch	3Ah	*1	03h
Character		O	E	D	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

2.85. AUX DVI EDID

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	4Ch	3Ah
Character		A	D	Z	Z	;	O	E	D	:
Hexadecimal	*1	41h	55h	58h	03h					
Character	*2	A	U	X						

- Parameters (*1, *2)

	EDID1	EDID2 (PC)
Hexadecimal	31h	32h
Character	1	2

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	4Ch	3Ah	*1	41h	55h	58h	03h
Character		O	E	D	:	*2	A	U	X	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

2.86. DVI SIGNAL LEVEL

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	56h	49h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	D	V	I	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0-255:PC					16-235				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	56h	49h	49h	30h
Character		V	X	X	:	D	V	I	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

2.87. AUX DVI SIGNAL LEVEL

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	56h	49h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	V	I	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0-255:PC					16-235				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	56h	49h	49h	31h
Character		V	X	X	:	D	V	I	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	×	○	○

2.88. P I N P

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	50h	50h	3Ah
Character		A	D	Z	Z	;	O	P	P	:
Hexadecimal	*1	03h								
Character	*2									

■ Parameters (*1, *2)

	OFF		USER1		USER2		USER3	
Hexadecimal	30h		31h		32h		33h	
Character	0		1		2		3	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	50h	50h	3Ah	*1	03h
Character		O	P	P	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.89. P IN P - MAIN WINDOW

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	49h	3Ah
Character		A	D	Z	Z	;	M	S	I	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2)

	RGB1			RGB2			DVI		
Hexadecimal	52h	47h	31h	52h	47h	32h	44h	56h	49h
Character	R	G	I	R	G	2	D	V	I
	VIDEO			S VIDEO			AUX		
Hexadecimal	56h	49h	44h	53h	56h	44h	41h	55h	58h
Character	V	I	D	S	V	D	A	U	X

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	49h	3Ah	*1	*3	*5	03h
Character		M	S	I	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Notes:

- When AUX is specified for the parameter with incompatible input module installed in the slot, ER401 is returned.
- When AUX is specified for the parameter with no input module installed in the slot, ER402 is returned.
- When FRAME DELAY is set besides DEFAULT, ER401 is returned.
- If the same content as the channel set to sub window is specified ER402 is returned.
- If RGB1 (RGB2) is specified when RGB2 (RGB1) is set for the sub window, ER402 is returned.
- If S-VIDEO (VIDEO) is specified when VIDEO (S-VIDEO) is set for the sub window, ER402 is returned.

2.90. P IN P - MAIN WINDOW:SIZE - INTERLOCKED

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	4Ch	3Ah
Character		A	D	Z	Z	;	M	S	L	:
Hexadecimal	*1	03h								
Character	*2									

Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	4Ch	3Ah	*1	03h
Character		M	S	L	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.91. P IN P - MAIN WINDOW:SIZE - V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	56h	3Ah
Character		A	D	Z	Z	;	M	S	V	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	10		11		12		13		14		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	31h	34h	
Character	1	0	1	1	1	2	1	3	1	4	
	96		97		98		99		100		
Hexadecimal	39h	36h	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	6	9	7	9	8	9	9	1	0	0

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	56h	3Ah	*1	*3	*5	03h
Character		M	S	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.92. P IN P - MAIN WINDOW:SIZE - H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	48h	3Ah
Character		A	D	Z	Z	;	M	S	H	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	10		11		12		13		14		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	31h	34h	
Character	1	0	1	1	1	2	1	3	1	4	
	96		97		98		99		100		
Hexadecimal	39h	36h	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	6	9	7	9	8	9	9	1	0	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	48h	3Ah	*1	*3	*5	03h
Character		M	S	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.93. P IN P - MAIN WINDOW:SIZE - HV

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	5Ah	3Ah
Character		A	D	Z	Z	;	M	S	Z	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	10		11		12		13		14		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	31h	34h	
Character	1	0	1	1	1	2	1	3	1	4	
	96		97		98		99		100		
Hexadecimal	39h	36h	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	6	9	7	9	8	9	9	1	0	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	5Ah	3Ah	*1	*3	*5	03h
Character		M	S	Z	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.94. P IN P - MAIN WINDOW:POSITION - V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	50h	56h	3Ah
Character		A	D	Z	Z	;	M	P	V	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

DZ12000

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

D12000

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	3

DW100

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

■ Note:

- The maximum value and minimum value that can be actually set change according to the setting condition of the input signal, ASPECT and ZOOM.

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	50h	56h	3Ah	*1	*3	*5	*7	03h
Character		M	P	V	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT or RASTER POSITION is set besides 0, ER401 is returned.

2.95. P IN P - MAIN WINDOW:POSITION - H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	50h	48h	3Ah
Character		A	D	Z	Z	;	M	P	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

DZ12000

	-928				-927				-926			
Hexadecimal	2Dh	39h	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
	+926				+927				+928			
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

D12000

	-668				-667				-666			
Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
	+666				+667				+668			
Hexadecimal	2Bh	36h	36h	36h	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	6	6	+	6	6	7	+	6	6	8

DW100

	-651				-650				-649			
Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
	+649				+650				+651			
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

■ Note:

- The maximum value and minimum value that can be actually set change according to the setting condition of the input signal, ASPECT and ZOOM.

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	50h	48h	3Ah	*1	*3	*5	*7	03h
Character		M	P	H	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.96. P IN P - SUB WINDOW

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	49h	53h	3Ah
Character		A	D	Z	Z	;	S	I	S	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2)

	RGB1			RGB2			DVI		
Hexadecimal	52h	47h	31h	52h	47h	32h	44h	56h	49h
Character	R	G	1	R	G	2	D	V	I
	VIDEO			S VIDEO			AUX		
Hexadecimal	56h	49h	44h	53h	56h	44h	41h	55h	58h
Character	V	I	D	S	V	D	A	U	X

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	49h	53h	3Ah	*1	03h
Character		S	I	S	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.
- If the same content as the channel set to main window is specified ER402 is returned.
- If RGB1 (RGB2) is specified when RGB2 (RGB1) is set for the main window, ER402 is returned.
- If S-VIDEO (VIDEO) is specified when VIDEO (S-VIDEO) is set for the main window, ER402 is returned.

2.97. P IN P - SUB WINDOW:SIZE - INTERLOCKED

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	4Ch	3Ah
Character		A	D	Z	Z	;	S	S	L	:
Hexadecimal	*1	03h								
Character	*2									

■ Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	4Ch	3Ah	*1	03h
Character		S	S	L	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.98. P IN P - SUB WINDOW:SIZE - V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	56h	3Ah
Character		A	D	Z	Z	;	S	S	V	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	10		11		12		13		14		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	31h	34h	
Character	1	0	1	1	1	2	1	3	1	4	
	96		97		98		99		100		
Hexadecimal	39h	36h	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	6	9	7	9	8	9	9	1	0	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	56h	3Ah	*1	*3	*5	03h
Character		S	S	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.99. P IN P - SUB WINDOW:SIZE - H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	48h	3Ah
Character		A	D	Z	Z	;	S	S	H	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

■ Parameters (*1, *2, *3, *4, *5, *6)

	10		11		12		13		14		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	31h	34h	
Character	1	0	1	1	1	2	1	3	1	4	
	96		97		98		99		100		
Hexadecimal	39h	36h	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	6	9	7	9	8	9	9	1	0	0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	48h	3Ah	*1	*3	*5	03h
Character		M	S	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.100. P IN P - SUB WINDOW:SIZE - HV

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	5Ah	3Ah
Character		A	D	Z	Z	:	S	S	Z	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

Parameters (*1, *2, *3, *4, *5, *6)

	10		11		12		13		14		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	31h	34h	
Character	1	0	1	1	1	2	1	3	1	4	
	96		97		98		99		100		
Hexadecimal	39h	36h	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	6	9	7	9	8	9	9	1	0	0

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	5Ah	3Ah	*1	*3	*5	03h
Character		S	S	Z	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.101. P IN P - SUB WINDOW:POSITION - V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	50h	56h	3Ah
Character		A	D	Z	Z	:	S	P	V	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

DZ12000

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

D12000

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	3

DW100

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

Note:

- The maximum value and minimum value that can be actually set change according to the setting condition of the input signal, ASPECT and ZOOM.

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	50h	56h	3Ah	*1	*3	*5	*7	03h
Character		S	P	V	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.102. P IN P - SUB WINDOW:POSITION - H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	50h	48h	3Ah
Character		A	D	Z	Z	;	S	P	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

DZ12000

	-928				-927				-926			
Hexadecimal	2Dh	39h	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
	+926				+927				+928			
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

D12000

	-668				-667				-666			
Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
	+666				+667				+668			
Hexadecimal	2Bh	36h	36h	36h	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	6	6	+	6	6	7	+	6	6	8

DW100

	-651				-650				-649			
Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
	+649				+650				+651			
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

Note:

- The maximum value and minimum value that can be actually set change according to the setting condition of the input signal, ASPECT and ZOOM.

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	50h	48h	3Ah	*1	*3	*5	*7	03h
Character		S	P	H	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.103. P IN P - FRAME LOCK

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	46h	4Ch	3Ah
Character		A	D	Z	Z	;	P	F	L	:
Hexadecimal	*1	03h								
Character	*2									

Parameters (*1, *2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	50h	46h	4Ch	3Ah	*1	03h
Character		P	F	L	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.
- When moving picture signals are input to either main or sub, the frame lock is fixed to the moving picture signals.

2.104. P IN P - TYPE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	54h	50h	3Ah	*1	03h
Character		A	D	Z	Z	;	P	T	P	:	*2	

Parameters (*1, *2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	50h	54h	50h	3Ah	*1	03h
Character		P	T	P	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	×	○	○	×	○	○

Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.105. AUTO POWER OFF

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	46h	3Ah
Character		A	D	Z	Z	;	O	A	F	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

Parameters (*1, *2, *3, *4)

	DISABLE		45MIN.		60MIN.	
Hexadecimal	30h	30h	34h	35h	36h	30h
Character	0	0	4	5	6	0
	75MIN.		90MIN.			
Hexadecimal	37h	35h	39h	30h		
Character	7	5	9	0		

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	46h	3Ah	*1	*3	03h
Character		O	A	F	:	*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
×	○	○	○	○	○	○

2.106. Set Date

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	54h	53h	44h	3Ah
Character		A	D	Z	Z	;	T	S	D	:
Hexadecimal	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*D2	*w	03h
Character										

Parameters

*y1 - *y4: Year (4 digits)

*m1, *m2: Month (2 digits)

*d1, *d2: Day (2 digits)

*w: Day of the week (Mon = 1, Tue = 2, Wed = 3, Thu = 4, Fri = 5, Sat = 6, Sun = 7)

Set it by UTC (Coordinated Universal Time).

Example: Sunday, June 29, 2008

	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*D2	*w
Hexadecimal	32h	30h	30h	38h	30h	36h	32h	39h	37h
Character	2	0	0	8	0	6	2	9	7

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	54h	53h	44h	3Ah	*y1	*y2	
Character		T	S	D	:			
Hexadecimal	*y3	*y4	*m1	*m2	*d1	*d2	*w	03h
Character								

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

2.107. Set Time

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	54h	53h	54h	3Ah
Character		A	D	Z	Z	;	T	S	T	:
Hexadecimal	*h1	*h2	*m1	*m2	*s1	*s2	03h			
Character										

Parameters

*h1, *h2: Hour (2 digits)

*m1, *m2 : Minute (2 digits)

*s1, *s2 : Second (2 digits)

Set it by UTC (Coordinated Universal Time).

Example: 3 seconds at 3:45 p.m.

	*h1	*h2	*m1	*m2	*s1	*s2
Hexadecimal	31h	35h	34h	35h	30h	33h
Character	1	5	4	5	0	3

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	54h	53h	54h	3Ah		
Character		T	S	T	:		
Hexadecimal	*h1	*h2	*m1	*m2	*s1	*s2	03h
Character							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.108. INPUT GUIDE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	44h	3Ah
Character		A	D	Z	Z	;	O	I	D	:
Hexadecimal	*1	03h								
Character	*2									

Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	44h	3Ah	*1	03h
Character		O	I	D	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.109. WARNING MESSAGE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	57h	4Dh	44h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	W	M	D	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					ON				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	57h	4Dh	44h	49h	30h
Character		V	X	X	:	W	M	D	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.110. OSD DESIGN

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	4Fh	44h	3Ah
Character		A	D	Z	Z	;	M	O	D	:
Hexadecimal	*1	03h								
Character	*2									

■ Parameters (*1, *2)

	1	2	3
Hexadecimal	30h	31h	32h
Character	0	1	2
	4	5	6
Hexadecimal	33h	34h	35h
Character	3	4	5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	4Fh	44h	3Ah	*1	03h
Character		M	O	D	:	*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.111. Query Power

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	57h	03h
Character		A	D	Z	Z	;	Q	P	W	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	30h	30h	03h
Character		0	0	0	

ON

Hexadecimal	02h	30h	30h	31h	03h
Character		0	0	1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.112. Query SHUTTER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	48h	03h
Character		A	D	Z	Z	;	Q	S	H	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.113. Query FREEZE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	46h	5Ah	03h
Character		A	D	Z	Z	;	Q	F	Z	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.114. Query Input Change

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	4Eh	03h
Character		A	D	Z	Z	;	Q	I	N	

■ Response (Callback)

RGB1

Hexadecimal	02h	52h	47h	31h	03h
Character		R	G	1	

RGB2

Hexadecimal	02h	52h	47h	32h	03h
Character		R	G	2	

VIDEO

Hexadecimal	02h	56h	49h	44h	03h
Character		V	I	D	

S-VIDEO

Hexadecimal	02h	53h	56h	44h	03h
Character		S	V	D	

DVI

Hexadecimal	02h	44h	56h	49h	03h
Character		D	V	I	

AUX

Hexadecimal	02h	41h	55h	58h	03h
Character		A	U	X	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

2.115. Query TEST PATTERN

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	53h	03h
Character		A	D	Z	Z	;	Q	T	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

■ Parameters (*1, *2, *3, *4)

	OFF		White		Black		Flag		Reversed flag	
Hexadecimal	30h	30h	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	0	0	1	0	2	0	3	0	4
	Window		Reversed window		Focus		Colorbar		Gray 1 (20% brightness)	
Hexadecimal	30h	35h	30h	36h	30h	37h	30h	38h	31h	30h
Character	0	5	0	6	0	7	0	8	1	0
	Ramp		White		Red		Green		Blue	
Hexadecimal	31h	31h	32h	31h	32h	32h	32	33	32h	34h
Character	1	1	2	1	2	2	2	3	2	4
	10% brightness (White)		5% brightness (White)		Cyan		Magenta		Yellow	
Hexadecimal	32h	35h	32h	36h	32h	38h	32h	39h	33h	30h
Character	2	5	2	6	2	8	2	9	3	0

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

2.116. Query ON SCREEN

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	53h	03h
Character		A	D	Z	Z	;	Q	O	S	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

2.117. Query PICTURE MODE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	4Dh	03h
Character		A	D	Z	Z	;	Q	P	M	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	DYNAMIC			GRAPHIC			USER		
Hexadecimal	44h	59h	4Eh	47h	52h	41h	52h	41h	41h
Character	D	Y	N	G	R	A	U	S	R
	STANDARD			CINEMA			NATURAL		
Hexadecimal	53h	54h	44h	43h	49h	4Eh	4Eh	41h	54h
Character	S	T	D	C	I	N	N	A	T

2.118. Query COLOR

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	43h	03h
Character		A	D	Z	Z	;	Q	V	C	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-50			-49			-48		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	48			49			50		
Hexadecimal	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	8	0	9	9	1	0	0

■ Note:

- The value in which 50 is added to the value displayed in the menu is returned as a response (callback).

2.119. Query TINT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	54h	03h
Character		A	D	Z	Z	;	Q	V	T	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-31			-30			-29		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29			30			31		
Hexadecimal	30h	36h	30h	30h	36h	31h	30h	36h	32h
Character	0	6	0	0	6	1	0	6	2

■ Note:

- The value in which 31 is added to the value displayed in the menu is returned as a response (callback).

2.120. Query COLOR TEMP.

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	45h	03h
Character		A	D	Z	Z	;	Q	T	E	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4)

	LOW	MIDDLE	HIGH	USER1	USER2	DEFAULT
Hexadecimal	30h	31h	32h	34h	39h	31h 30h
Character	0	1	2	4	9	1 0

■ Note:

- The response (callback) other than DEFAULT (10) is one digit.

2.121. Query WHITE BALANCE LOW - R

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	52h	03h
Character		A	D	Z	Z	;	Q	O	R	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Notes:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.
- The value in which 128 is added to the value displayed in the menu is returned as a response (callback).

2.122. Query WHITE BALANCE LOW - G

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	47h	03h
Character		A	D	Z	Z	;	Q	O	G	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Notes:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.
- The value in which 128 is added to the value displayed in the menu is returned as a response (callback).

2.123. WHITE BALANCE LOW - B

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	42h	03h
Character		A	D	Z	Z	;	Q	O	B	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Notes:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.
- The value in which 128 is added to the value displayed in the menu is returned as a response (callback).

2.124. Query WHITE BALANCE HIGH - R

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	48h	52h	03h
Character		A	D	Z	Z	;	Q	H	R	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Note:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.

2.125. Query WHITE BALANCE HIGH - G

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	48h	47h	03h
Character		A	D	Z	Z	;	Q	H	G	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Note:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.

2.126. Query WHITE BALANCE HIGH - B

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	48h	42h	03h
Character		A	D	Z	Z	;	Q	H	B	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

■ Note:

- When a parameter other than USER1 or USER2 is specified for COLOR TEMP., ER401 is returned.

2.127. Query CONTRAST

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	52h	03h
Character		A	D	Z	Z	;	Q	V	R	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	29			30			31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■ Note:

- The value in which 32 is added to the value displayed in the menu is returned as a response (callback).

2.128. Query BRIGHTNESS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	42h	03h
Character		A	D	Z	Z	;	Q	V	B	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	29			30			31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■ Note:

- The value in which 32 is added to the value displayed in the menu is returned as a response (callback).

2.129. Query SYSTEM DAYLIGHT VIEW

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	4Ch	56h	49h	30h	03h				
Character	D	L	V	I	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	4Ch	56h	49h	30h	3Dh	2Bh	*1	*3
Character		D	L	V	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	OFF					1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	2					3				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3

■ Note:

- For PT-DW100*, ER401 is returned.

2.130. Query SHARPNESS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	53h	03h
Character		A	D	Z	Z	;	Q	V	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal	30h	31h	33h	30h	31h	34h	30h	31h	35h
Character	0	1	3	0	1	4	0	1	5

2.131. Query NOISE REDUCTION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Eh	53h	03h
Character		A	D	Z	Z	;	Q	N	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	OFF	ON or 1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

■ Notes:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.
- During P IN P, ER401 is returned.

2.132. Query DYNAMIC IRIS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	49h	03h
Character		A	D	Z	Z	;	Q	A	I	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	OFF	1	2	3	USER
Hexadecimal	30h	31h	32h	33h	34h
Character	0	1	2	3	4

2.133. Query DYNAMIC IRIS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	49h	3Ah	*1	03h
Character		A	D	Z	Z	;	Q	A	I	:	*2	

■ Parameters (*1, *2)

	AUTO IRIS	MANUAL IRIS	DYNAMIC GAMMA
Hexadecimal	41h	4Dh	44h
Character	A	M	D

■ Response (Callback)

In the period when the command can be accepted

When AUTO IRIS or DYNAMIC GAMMA is specified for the parameter (*1, *2)

Hexadecimal	02h	*3	03h
Character		*4	

When MANUAL IRIS is specified for the parameter (*1, *2)

Hexadecimal	02h	*5	*7	03h
Character		*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*3, *4)

	OFF	1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

■ Parameters (*5, *6, *7, *8)

	OFF	1	2	3				
Hexadecimal	30h	30h	30h	31h	30h	32h	30h	33h
Character	0	0	0	1	0	2	0	3
	60	61	62	63				
Hexadecimal	36h	30h	36h	31h	36h	32h	36h	33h
Character	6	0	6	1	6	2	6	3

2.134. Query TV-SYSTEM

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	47h	03h
Character		A	D	Z	Z	;	Q	S	G	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	AUTO1			AUTO2			NTSC		
Hexadecimal	41h	54h	31h	41h	54h	32h	4Eh	54h	53h
Character	A	T	1	A	T	2	N	T	S
	NTSC4.43			PAL			PAL-M		
Hexadecimal	4Eh	34h	34h	50h	41h	4Ch	50h	41h	4Dh
Character	N	4	4	P	A	L	P	A	M
	PAL-N			SECAM			PAL60		
Hexadecimal	50h	41h	4Eh	53h	45h	43h	50h	36h	30h
Character	P	A	N	S	E	C	P	6	0

2.135. Query SHIFT H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	48h	03h
Character		A	D	Z	Z	;	Q	T	H	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	0				1				2			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	2
Character	0	0	0	0	0	0	0	1	0	0	0	2
	4093				4094				4095			
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	3	4	0	9	4	4	0	9	5

2.136. Query SHIFT V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	56h	03h
Character		A	D	Z	Z	;	Q	T	V	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	0				1				2			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	1	0	0	0	2
	4093				4094				4095			
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	3	4	0	9	4	4	0	9	5

2.137. Query ASPECT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	45h	03h
Character		A	D	Z	Z	;	Q	S	E	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4)

- Input route: VIDEO

Input signal: NTSC

	VID AUTO	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT *1	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

- Input route: VIDEO

Input signal: Except NTSC

	DEFAULT	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT *1	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

- Input route: S-VIDEO

Input signal: NTSC

	VID AUTO(PRI)	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT *1	S1 AUTO *1
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0
	VID AUTO *1			
Hexadecimal	33h	30h		
Character	3	0		

- Input route: S-VIDEO

Input signal: Except NTSC

	DEFAULT	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT *1	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

- Input route: Except VIDEO/S-VIDEO

Input signal: SD

	DEFAULT	4:3	16:9	THROUGH
Hexadecimal	30h	31h	32h	35h
Character	0	1	2	5
	HV FIT	H FIT	V FIT *1	
Hexadecimal	36h	39h	31h	30h
Character	6	9	1	0

*1: The response (callback) other than this item is one digit.

2.138. Query ZOOM H

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	48h	03h
Character		A	D	Z	Z	;	Q	Z	H	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

■ Note:

- When ASPECT is THROUGH, ER401 is returned.

2.139. Query ZOOM V

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	56h	03h
Character		A	D	Z	Z	;	Q	Z	V	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

■ Note:

- When ASPECT is THROUGH, ER401 is returned.

2.140. Query ZOOM HV

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	4Fh	03h
Character		A	D	Z	Z	;	Q	Z	O	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

■ Note:

- When ASPECT is THROUGH, ER401 is returned.

2.141. Query INTERLOCKED ZOOM

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	53h	03h
Character		A	D	Z	Z	;	Q	Z	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

■ Note:

- When ASPECT is THROUGH, ER401 is returned.

2.142. Query CLOCK PHASE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	43h	50h	03h
Character		A	D	Z	Z	;	Q	C	P	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	×	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29			30			31		
Hexadecimal	30h	32h	39h	30h	33h	30h	30h	33h	31h
Character	0	2	9	0	3	0	0	3	1

■ Note:

- It is able to accept only when the selected slot is RGB1 or RGB2, and ER401 is returned besides.

2.143. Query INPUT RESOLUTION - TOTAL DOTS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	44h	03h
Character		A	D	Z	Z	;	Q	T	D	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	301				302			
Hexadecimal	30h	33h	30h	31h	30h	33h	30h	32h
Character	0	3	0	1	0	3	0	2
	4094				4095			
Hexadecimal	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	4	4	0	9	5

■ Note:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.

2.144. Query INPUT RESOLUTION - DISPLAY DOTS

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	44h	03h
Character		A	D	Z	Z	;	Q	D	D	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	300				301			
Hexadecimal	30h	33h	30h	30h	30h	33h	30h	31h
Character	0	3	0	0	0	3	0	1
	2047				2048			
Hexadecimal	32h	30h	34h	37h	32h	30h	34h	36h
Character	2	0	4	7	2	0	4	8

■ Note:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.

2.145. Query INPUT RESOLUTION - TOTAL LINES

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	4Ch	03h
Character		A	D	Z	Z	;	Q	T	L	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	221				222			
Hexadecimal	30h	32h	32h	31h	30h	32h	32h	32h
Character	0	2	2	1	0	2	2	2
	4094				4095			
Hexadecimal	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	4	4	0	9	5

■ Note:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.

2.146. Query INPUT RESOLUTION - DISPLAY LINES

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	4Ch	03h
Character		A	D	Z	Z	;	Q	D	L	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	TEST PATTERN	REMOTE2
○	×	×	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	220				221			
Hexadecimal	30h	32h	32h	30h	30h	32h	32h	31h
Character	0	2	2	0	0	2	2	1
	4093				4094			
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h
Character	4	0	9	3	4	0	9	4

■ Note:

- This command is acceptable only when RGB1 or RGB2 is selected and RGB signals are input. In other cases, ER401 is returned.

2.147. Query CLAMP POSITION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	54h	03h
Character		A	D	Z	Z	;	Q	L	T	

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	×	○	○	○	○

Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

Note:

- This command is acceptable only when RGB1 or RGB2 is selected. In other cases, ER401 is returned.

2.148. Query KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Bh	53h	03h
Character		A	D	Z	Z	;	Q	K	S	

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	-127				-126				-125			
Hexadecimal	2Dh	31h	32h	37h	2Dh	31h	32h	36h	2Dh	31h	32h	35h
Character	-	1	2	7	-	1	2	6	-	1	2	5
	+125				+126				+127			
Hexadecimal	2Bh	31h	32h	35h	2Bh	31h	32h	36h	2Bh	31h	32h	37h
Character	+	1	2	5	+	1	2	6	+	1	2	7

Note:

- For PT-DZ12000*/D12000*, ER401 is returned.

2.149. Query SUB KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Bh	03h
Character		A	D	Z	Z	;	Q	S	K	

Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	-127				-126				-125			
Hexadecimal	2Dh	31h	32h	37h	2Dh	31h	32h	36h	2Dh	31h	32h	35h
Character	-	1	2	7	-	1	2	6	-	1	2	5
	+125				+126				+127			
Hexadecimal	2Bh	31h	32h	35h	2Bh	31h	32h	36h	2Bh	31h	32h	37h
Character	+	1	2	5	+	1	2	6	+	1	2	7

Note:

- For PT-DZ12000*/D12000*, ER401 is returned.

2.150. Query LINEARITY

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	49h	03h
Character		A	D	Z	Z	;	Q	L	I	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	-127				-126				-125			
Hexadecimal	2Dh	31h	32h	37h	2Dh	31h	32h	36h	2Dh	31h	32h	35h
Character	.	1	2	7	.	1	2	6	.	1	2	5
	+125				+126				+127			
Hexadecimal	2Bh	31h	32h	35h	2Bh	31h	32h	36h	2Bh	31h	32h	37h
Character	+	1	2	5	+	1	2	6	+	1	2	7

■ Note:

- For PT-DZ12000*/D12000*, ER401 is returned.

2.151. Query GEOMETRY

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Dh	49h	30h	03h				
Character	G	M	M	I	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Dh	49h	30h	3Dh	2Bh	*1	*3
Character		G	M	M	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					KEYSTONE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	CURVED					PC				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3

■ Note:

- For PT-DW100*, ER401 is returned.

2.152. Query GEOMETRY:KEYSTONE - V-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	31h	03h				
Character	G	M	K	I	1					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	31h	3Dh	*1	*3	*5
Character		G	M	K	I	1	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	.	0	0	1	2	7	.	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.153. Query GEOMETRY:KEYSTONE - V-SUB-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	32h	03h				
Character	G	M	K	I	2					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	32h	3Dh	*1	*3	*5
Character		G	M	K	I	2	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.154. Query GEOMETRY:KEYSTONE - H-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	35h	03h				
Character	G	M	K	I	5					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	35h	3Dh	*1	*3	*5
Character		G	M	K	I	5	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.155. Query GEOMETRY:KEystone - H-SUB-KEystone

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	36h	03h				
Character	G	M	K	I	6					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	36h	3Dh	*1	*3	*5
Character		G	M	K	I	6	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.156. Query GEOMETRY:KEystone - LINEARITY

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	33h	03h				
Character	G	M	K	I	3					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	33h	3Dh	*1	*3	*5
Character		G	M	K	I	3	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.157. Query GEOMETRY:CURVED - LENS THROW RATIO

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	53h	30h	03h				
Character	G	M	C	S	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	53h	30h	3Dh	*1	*3	*5
Character		G	M	C	S	0	=	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0.7					0.9				
Hexadecimal	30h	2Eh	37h	30h		30h	2Eh	39h	30h	
Character	0	.	7	0		0	.	9	0	
	16.4					16.5				
Hexadecimal	31h	36h	2Eh	34h	30h	31h	36h	2E	35h	30h
Character	1	6	.	4	0	1	6	.	5	0

■ Note:

- For PT-DW100*, ER401 is returned.

2.158. Query GEOMETRY:CURVED - V-SUB-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	31h	03h				
Character	G	M	C	I	1					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	31h	3Dh	*1	*3	*5
Character		G	M	C	I	1	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.159. Query GEOMETRY:CURVED - H-KEYSTONE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	35h	03h				
Character	G	M	C	I	5					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	35h	3Dh	*1	*3	*5
Character		G	M	C	I	5	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.160. Query GEOMETRY:CURVED - V ARC

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	33h	03h				
Character	G	M	C	I	3					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	33h	3Dh	*1	*3	*5
Character		G	M	C	I	3	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.161. Query GEOMETRY:CURVED - H ARC

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	37h	03h				
Character	G	M	C	I	7					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	37h	3Dh	*1	*3	*5
Character		G	M	C	I	7	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.162. Query GEOMETRY:CURVED - V BALANCE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	32h	03h				
Character	G	M	C	I	2					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	32h	3Dh	*1	*3	*5
Character		G	M	C	I	2	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.163. Query GEOMETRY:CURVED - H BALANCE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	36h	03h				
Character	G	M	C	I	6					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	36h	3Dh	*1	*3	*5
Character		G	M	C	I	6	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

	-127						-126					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Dh	30h	30h	31h	32h	36h
Character	-	0	0	1	2	7	-	0	0	1	2	6
	126						127					
Hexadecimal	2Bh	30h	30h	31h	32h	36h	2Bh	30h	30h	31h	32h	37h
Character	+	0	0	1	2	6	+	0	0	1	2	7

■ Note:

- For PT-DW100*, ER401 is returned.

2.164. Query DISPLAY LANGUAGE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	47h	03h
Character		A	D	Z	Z	;	Q	L	G	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	English			German			French		
Hexadecimal	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
Character	E	N	G	D	E	U	F	R	A
	Spanish			Italian			Japanese		
Hexadecimal	45h	53h	50h	49h	54h	4Ch	4Ah	50h	4Eh
Character	E	S	P	I	T	L	J	P	N
	Chinese			Russian			Korean		
Hexadecimal	43h	48h	49h	52h	55h	53h	4Bh	4Fh	52h
Character	C	H	I	R	U	S	K	O	R

2.165. Query BLANKING - UPPER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	55h	03h
Character		A	D	Z	Z	;	Q	L	U	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	598			599			600		
Hexadecimal	35h	39h	38h	35h	39h	39h	36h	30h	30h
Character	5	9	8	5	9	9	6	0	0

D12000

	523			524			525		
Hexadecimal	35h	32h	33h	35h	32h	34h	35h	32h	35h
Character	5	2	3	5	2	4	5	2	5

DW100

	382			383			384		
Hexadecimal	33h	38h	32h	33h	38h	33h	33h	38h	34h
Character	3	8	2	3	8	3	3	8	4

2.166. Query BLANKING - LOWER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	42h	03h
Character		A	D	Z	Z	;	Q	L	B	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	598			599			600		
Hexadecimal	35h	39h	38h	35h	39h	39h	36h	30h	30h
Character	5	9	8	5	9	9	6	0	0

D12000

	523			524			525		
Hexadecimal	35h	32h	33h	35h	32h	34h	35h	32h	35h
Character	5	2	3	5	2	4	5	2	5

DW100

	382			383			384		
Hexadecimal	33h	38h	32h	33h	38h	33h	33h	38h	34h
Character	3	8	2	3	8	3	3	8	4

2.167. Query BLANKING - LEFT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	4Ch	03h
Character		A	D	Z	Z	;	Q	L	L	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	958			959			960		
Hexadecimal	39h	35h	38h	39h	35h	39h	39h	36h	30h
Character	9	5	8	9	5	9	9	6	0

D12000

	698			699			700		
Hexadecimal	36h	39h	38h	36h	39h	39h	37h	30h	30h
Character	6	9	8	6	9	9	7	0	0

DW100

	681			682			683		
Hexadecimal	36h	38h	31h	36h	38h	32h	36h	38h	33h
Character	6	8	1	6	8	2	6	8	3

2.168. Query BLANKING - RIGHT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	52h	03h
Character		A	D	Z	Z	;	Q	L	R	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

DZ12000

	958			959			960		
Hexadecimal	39h	35h	38h	39h	35h	39h	39h	36h	30h
Character	9	5	8	9	5	9	9	6	0

D12000

	698			699			700		
Hexadecimal	36h	39h	38h	36h	39h	39h	37h	30h	30h
Character	6	9	8	6	9	9	7	0	0

DW100

	681			682			683		
Hexadecimal	36h	38h	31h	36h	38h	32h	36h	38h	33h
Character	6	8	1	6	8	2	6	8	3

2.169. Query EDGE BLENDING

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	44h	42h	49h	30h	03h				
Character	E	D	B	I	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	44h	42h	49h	30h	3Dh	2Bh	*1	*3
Character		E	D	B	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					ON				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	USER									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

2.170. Query SCREEN FORMAT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	46h	03h
Character		A	D	Z	Z	;	Q	S	F	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	16:10 *1	16:9	4:3 *2
Hexadecimal	30h	31h	32h
Character	0	1	2

1: Returns only in PT-DZ12000.

2: Returns only in PT-D12000.

■ Note:

- If querying on PT-DW100*, ER401 is returned.

2.171. Query SCREEN POSITION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	56h	53h	50h	49h	30h	03h				
Character	V	S	P	I	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	50h	49h	30h	3Dh	2Bh	*1	*3
Character		V	S	P	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10, *11, *12)

DZ12000

	-60						-59					
Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h	39h
Character	-	0	0	0	6	0	-	0	0	0	5	9
	59						60					
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	36h	30h
Character	+	0	0	0	5	9	+	0	0	0	6	0

D12000

	-132						-131					
Hexadecimal	2Dh	30h	30h	31h	33h	32h	2Dh	30h	30h	31h	33h	31h
Character	-	0	0	1	3	2	-	0	0	1	3	1
	130						131					
Hexadecimal	2Bh	30h	30h	31h	33h	30h	2Bh	30h	30h	31h	33h	31h
Character	+	0	0	1	3	0	+	0	0	1	3	1

■ Notes:

- If querying on PT-DW100*, ER401 is returned.
- When a format except 16:9 is specified for SCREEN FORMAT, ER401 is returned.

2.172. Query INSTALLATION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	50h	03h
Character		A	D	Z	Z	;	Q	S	P	

■ Response (Callback)

FRONT-FLOOR

Hexadecimal	02h	30h	03h
Character		0	

REAR-FLOOR

Hexadecimal	02h	31h	03h
Character		1	

FRONT-CEILING

Hexadecimal	02h	32h	03h
Character		2	

REAR-CEILING

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.173. Query PROJECTOR RUNTIME

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	54h	03h
Character		A	D	Z	Z	;	Q	S	T	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	*9	03h
Character		*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0					1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	99998					99999				
Hexadecimal	39h	39h	39h	39h	38h	39h	39h	39h	39h	39h
Character	9	9	9	9	8	9	9	9	9	9

2.174. Query LAMP RUNTIME

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	24h	4Ch	3Ah	*1	03h
Character		A	D	Z	Z	;	Q	\$	L	:	*2	

■ Parameters (*1, *2)

	LAMP1	LAMP2	LAMP3	LAMP4
Hexadecimal	31h	32h	33h	34h
Character	1	2	3	4

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

	0 h				1 h			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	1
	9998 h				9999 h			
Hexadecimal	39h	39h	39h	38h	39h	39h	39h	39h
Character	9	9	9	8	9	9	9	9

■ Note:

- It returns with 65535 (five digits) when LAMP RUNTIME cannot be obtained.

2.175. Query LAMP SELECT

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Ch	03h
Character		A	D	Z	Z	;	Q	S	L	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*1, *2, *3, *4)

	QUAD		L1/L4		L2/L3		DUAL		L1/L2/L3	
Hexadecimal	30h		31h		32h		33h		34h	
Character	0		1		2		3		4	
	L1/L2/L4		L1/L3/L4		L2/L3/L4		TRIPLE		L1	
Hexadecimal	35h		36h		37h		38h		39h	
Character	5		6		7		8		9	
	L2		L3		L4		SINGLE			
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h		
Character	1	0	1	1	1	2	1	3		

■ Note:

- The response (callback) of QUAD (0) - L1 (9) is one digit.

2.176. Query Lamp Status

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h		53h	03h
Character		A	D	Z	Z	;	Q	\$	S	

■ Response (Callback)

Lamp OFF

Hexadecimal	02h	30h	03h
Character		0	

In turning ON

Hexadecimal	02h	31h	03h
Character		1	

Lamp ON

Hexadecimal	02h	32h	03h
Character		2	

Cooling

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.177. Query RESPONSE(ID ALL)

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	59h	03h
Character		A	D	Z	Z	;	Q	V	Y	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.178. Query TEMP.

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	4Dh	3Ah
Character		A	D	Z	Z	;	Q	T	M	:
Hexadecimal	*1	03h								
Character	*2									

■ Parameters (*1, *2)

	Intake air	Surrounding of lamp	Optical module
Hexadecimal	30h	31h	32h
Character	0	1	2

■ Response (Callback)

For -20°C

		Celsius						Fahrenheit				
Hexadecimal	02h	2Dh	30h	32h	30h	2Fh	2Dh	30h	30h	34h	03h	
Character		-	0	2	0	/	-	0	0	4		

For 120°C

		Celsius						Fahrenheit				
Hexadecimal	02h	30h	31h	32h	30h	2Fh	30h	32h	34h	38h	03h	
Character		0	1	2	0	/	0	2	4	8		

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.179. Query ALTITUDE MODE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	46h	4Dh	03h
Character		A	D	Z	Z	;	Q	F	M	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.180. Query FUNC1

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	46h	43h	03h
Character		A	D	Z	Z	;	Q	F	C	

■ Response (Callback)

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4)

	P IN P	SUB MEMORY	SYSTEM SELECTOR	
Hexadecimal	30h	32h	34h	
Character	0	2	4	
	SYSTEM DAYLIGHT VIEW	FREEZE	DISABLE *1	
Hexadecimal	35h	36h	2Dh	31h
Character	5	6	-	1

*1: The response (callback) other than this item is one digit.

■ Note:

- In PT-DW100*, as for SYSTEM DAYLIGHT VIEW, ER402 is returned.

2.181. Query Usage Condition of Sub Memory

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	42h	03h
Character		A	D	Z	Z	;	Q	S	B	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4)

When the sub memory is not used, ER401 is returned.

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	93		94		95		96	
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

2.182. Query DVI EDID

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	42h	4Ch	03h
Character		A	D	Z	Z	;	Q	E	D	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2)

	EDID1	EDID2(PC)
Hexadecimal	31h	32h
Character	1	2

2.183. Query AUX DVI EDID

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	42h	4Ch	3Ah
Character		A	D	Z	Z	;	Q	E	D	:
Hexadecimal	41h	55h	58h	03h						
Character	A	U	X							

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2)

	EDID1	EDID2(PC)
Hexadecimal	31h	32h
Character	1	2

2.184. Query DVI SIGNAL LEVEL

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	56h	49h	49h	30h	03h				
Character	D	V	I	I	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	56h	49h	49h	30h	3Dh	2Bh	*1	*3
Character		D	V	I	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0-255·PC					16-235				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

2.185. Query AUX DVI SIGNAL LEVEL

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	56h	49h	49h	31h	03h				
Character	D	V	I	I	I					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	56h	49h	49h	31h	3Dh	2Bh	*1	*3
Character		D	V	I	I	I	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	0-255:PC					16-235				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

2.186. Query P IN P

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	50h	03h
Character		A	D	Z	Z	;	Q	P	P	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	OFF	USER1	USER2	USER3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.187. Query P IN P - MAIN WINDOW

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	4Dh	03h
Character		A	D	Z	Z	;	Q	I	M	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	RGB1			RGB2			DVI		
Hexadecimal	52h	47h	31h	52h	47h	32h	44h	56h	49h
Character	R	G	I	R	G	2	D	V	I
	VIDEO			S VIDEO			AUX		
Hexadecimal	56h	49h	44h	53h	56h	44h	41h	55h	58h
Character	V	I	D	S	V	D	A	U	X

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.188. Query P IN P - MAIN WINDOW:SIZE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Dh	03h
Character		A	D	Z	Z	;	Q	S	M	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	2Ch	56h	*5	*7	*9	2Ch	48h
Character		*2	*4	,	V	*6	*8	*10	,	H
Hexadecimal	*11	*13	*15	2Ch	48h	56h	*17	*19	*21	03h
Character	*12	*14	*16	,	H	V	*18	*20	*22	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4)

INTERLOCKED

	OFF		ON	
Hexadecimal	4Fh	46h	4Fh	4Eh
Character	○	F	○	N

■ Parameters (*5, *6, *7, *8, *9, *10)

V SIZE

	10			11			12			13			14		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h	30h	31h	33h	30h	31h	34h
Character	0	1	0	0	1	1	0	1	2	0	1	3	0	1	4
	96			97			98			99			100		
Hexadecimal	30h	39h	36h	30h	39h	37h	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	6	0	9	7	0	9	8	0	9	9	1	0	0

■ Parameters (*11, *12, *13, *14, *15, *16)

H SIZE

	10			11			12			13			14		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h	30h	31h	33h	30h	31h	34h
Character	0	1	0	0	1	1	0	1	2	0	1	3	0	1	4
	96			97			98			99			100		
Hexadecimal	30h	39h	36h	30h	39h	37h	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	6	0	9	7	0	9	8	0	9	9	1	0	0

■ Parameters (*17, *18, *19, *20, *21, *22)

HV SIZE

	10			11			12			13			14		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h	30h	31h	33h	30h	31h	34h
Character	0	1	0	0	1	1	0	1	2	0	1	3	0	1	4
	96			97			98			99			100		
Hexadecimal	30h	39h	36h	30h	39h	37h	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	6	0	9	7	0	9	8	0	9	9	1	0	0

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.189. Query P IN P - MAIN WINDOW:POSITION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	4Dh	03h
Character		A	D	Z	Z	;	Q	P	A	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	*1	*3	*5	*7	2Ch	48h	*9	*11	*13	*15	03h
Character		V	*2	*4	*6	*8	,	H	*10	*12	*14	*16	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

V POSITION

DZ12000

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

D12000

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	5

DW100

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

■ Parameters (*9, *10, *11, *12, *13, *14, *15, *16)

H POSITION

DZ12000

	-928				-927				-926			
Hexadecimal	2Dh	39	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
	+926				+927				+928			
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

D12000

	-668				-667				-666			
Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
	+666				+667				+668			
Hexadecimal	2Bh	36h	6	6	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	7	2	+	6	6	7	+	6	6	8

DW100

	-651				-650				-649			
Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
	+649				+650				+651			
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.190. Query P IN P - SUB WINDOW

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	53h	03h
Character		A	D	Z	Z	;	Q	I	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	RGB1			RGB2			DVI		
Hexadecimal	52h	47h	31h	52h	47h	32h	44h	56h	49h
Character	R	G	1	R	G	2	D	V	I
	VIDEO			S VIDEO			AUX		
Hexadecimal	56h	49h	44hh	53h	56h	44h	41h	55h	58h
Character	V	I	D	S	V	D	A	U	X

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.191. Query P IN P - SUB WINDOW:SIZE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	53h	03h
Character		A	D	Z	Z	;	Q	S	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	2Ch	56h	*5	*7	*9	2Ch	48h
Character		*2	*4	,	V	*6	*8	*10	,	H
Hexadecimal	*11	*13	*15	2Ch	48h	56h	*17	*19	*21	03h
Character	*12	*14	*16	,	H	V	*18	*20	*22	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4)

INTERLOCKED

	OFF		ON	
Hexadecimal	4Fh	46h	4Fh	4Eh
Character	○	F	○	N

■ Parameters (*5, *6, *7, *8, *9, *10)

V SIZE

	10			11			12			13			14		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h	30h	31h	33h	30h	31h	34h
Character	0	1	0	0	1	1	0	1	2	0	1	3	0	1	4
	96			97			98			99			100		
Hexadecimal	30h	39h	36h	30h	39h	37h	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	6	0	9	7	0	9	8	0	9	9	1	0	0

■ Parameters (*11, *12, *13, *14, *15, *16)

H SIZE

	10			11			12			13			14		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h	30h	31h	33h	30h	31h	34h
Character	0	1	0	0	1	1	0	1	2	0	1	3	0	1	4
	96			97			98			99			100		
Hexadecimal	30h	39h	36h	30h	39h	37h	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	6	0	9	7	0	9	8	0	9	9	1	0	0

■ Parameters (*17, *18, *19, *20, *21, *22)

HV SIZE

	10			11			12			13			14		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h	30h	31h	33h	30h	31h	34h
Character	0	1	0	0	1	1	0	1	2	0	1	3	0	1	4
	96			97			98			99			100		
Hexadecimal	30h	39h	36h	30h	39h	37h	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	6	0	9	7	0	9	8	0	9	9	1	0	0

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.192. Query P IN P - SUB WINDOW:POSITION

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	53h	03h
Character		A	D	Z	Z	;	Q	P	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	*1	*3	*5	*7	2Ch	48h	*9	*11	*13	*15	03h
Character		V	*2	*4	*6	*8	,	H	*10	*12	*14	*16	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8)

V POSITION

DZ12000

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

D12000

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	5

DW100

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

■ Parameters (*9, *10, *11, *12, *13, *14, *15, *16)

H POSITION

DZ12000

	-928				-927				-926			
Hexadecimal	2Dh	39	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
	+926				+927				+928			
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

D12000

	-668				-667				-666			
Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
	+666				+667				+668			
Hexadecimal	2Bh	36h	6	6	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	7	2	+	6	6	7	+	6	6	8

DW100

	-651				-650				-649			
Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
	+649				+650				+651			
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.193. Query P IN P - FRAME LOCK

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	46h	03h
Character		A	D	Z	Z	;	Q	P	F	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.194. Query P IN P - TYPE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	54h	03h
Character		A	D	Z	Z	;	Q	P	T	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	○	○	○

■ Parameters (*1, *2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

■ Note:

- When FRAME DELAY is set besides DEFAULT, ER401 is returned.

2.195. Query AUTO POWER OFF

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	46h	03h
Character		A	D	Z	Z	;	Q	A	F	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*1, *2, *3, *4)

	DISABLE		45MIN.		60MIN.	
Hexadecimal	30h	30h	34h	35h	36h	30h
Character	0	0	4	5	6	0
	75MIN.		90MIN.			
Hexadecimal	37h	35h	39h	30h		
Character	7	5	9	0		

2.196. Query Date

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	44h	03h
Character		A	D	Z	Z	;	Q	G	D	

■ Response (Callback)

Hexadecimal	02h	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*D2	*w	03h
Character											

■ Parameters

*y1 - *y4: Year (4 digits)

*m1, *m2: Month (2 digits)

*d1, *d2: Day (2 digits)

*w: Day of the week (Mon = 1, Tue = 2, Wed = 3, Thu = 4, Fri = 5, Sat = 6, Sun = 7)

Set it by UTC (Coordinated Universal Time).

Example: Sunday, June 29, 2008

	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*D2	*w
Hexadecimal	32h	30h	30h	38h	30h	36h	32h	39h	37h
Character	2	0	0	8	0	6	2	9	7

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.197. Query Time

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	54h	03h
Character		A	D	Z	Z	;	Q	G	T	

■ Response (Callback)

Hexadecimal	02h	*h1	*h2	*m1	*m2	*s1	*s2	03h
Character								

■ Parameters

*h1, *h2: Hour (2 digits)

*m1, *m2 : Minute (2 digits)

*s1, *s2 : Second (2 digits)

Set it by UTC (Coordinated Universal Time).

Example: 3 seconds at 3:45 p.m.

	*h1	*h2	*m1	*m2	*s1	*s2
Hexadecimal	31h	35h	34h	35h	30h	33h
Character	1	5	4	5	0	3

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.198. Query Model (Series) Name

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	44h	03h
Character		A	D	Z	Z	;	Q	I	D	

■ Response (Callback)

In the period when the command can be accepted

DZ12000

Hexadecimal	02h	44h	5Ah	31h	32h	30h	30h	30h	03h
Character		D	Z	1	2	0	0	0	

D12000

Hexadecimal	02h	44h	31h	32h	30h	30h	30h	03h
Character		D	1	2	0	0	0	

DW100

Hexadecimal	02h	44h	57h	31h	30h	30h	03h
Character		D	W	1	0	0	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

2.199. Query Lamp ON Status

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	h	h	03h
Character		A	D	Z	Z	;	Q	L	S	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4)

	Lamp OFF		L1/L2/L3/L4 ON		L1/L4 ON		L2/L3		L1/L2/L3	
Hexadecimal	30h		31h		32h		33h		34h	
Character	0		1		2		3		4	
	L1/L2/L4		L1/L3/L4		L2/L3/L4		L1		L2	
Hexadecimal	35h		36h		37h		38h		39h	
Character	5		6		7		8		9	
	L3		L4							
Hexadecimal	31h	30h	31h	31h						
Character	1	0	1	1						

2.200. Query INPUT GUIDE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	41h	03h
Character		A	D	Z	Z	;	Q	D	I	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.201. Query WARNING MESSAGE

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	57h	4Dh	44h	49h	30h	03h				
Character	W	M	D	I	0					

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	57h	4Dh	44h	49h	30h	3Dh	2Bh	*1	*3
Character		W	M	D	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

	OFF					ON				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

2.202. Query OSD DESIGN

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	44h	3Ah
Character		A	D	Z	Z	;	Q	O	D	:

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2)

	1	2	3
Hexadecimal	30h	31h	32h
Character	0	1	2
	4	5	6
Hexadecimal	33h	34h	35h
Character	3	4	5

2.203. Query SERIAL NUMBER

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Eh	3Ah
Character		A	D	Z	Z	;	Q	S	N	:

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	~	*21	*23	03h
Character		*2	*4		*22	*24	

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

■ Parameters (*1, *2, *3, *4, - *21, *22, *23, *24)

The set serial number (length) is returned.

Example: Serial number unsetting

Hexadecimal	02h	03h
Character		

Example: When SW0101234 is set into the serial number

Hexadecimal	02h	53h	57h	30h	31h	30h	31h	32h	33h	34h	03h
Character		S	W	0	1	0	1	2	3	4	

3. Extended Control Command

Start (STX)	ID	Command	Parameters	End (ETX)
1 byte	1 byte	1 byte or 3 bytes	Undefined length	1 byte

ID of the extended control command

ID	Hexadecimal (1 byte)	ID	Hexadecimal (1 byte)	ID	Hexadecimal (1 byte)	ID	Hexadecimal (1 byte)
ALL	00	ID23	17	ID46	2E	Group E	84
ID1	01	ID24	18	ID47	2F	Group F	85
ID2	02	ID25	19	ID48	30	Group G	86
ID3	03	ID26	1A	ID49	31	Group H	87
ID4	04	ID27	1B	ID50	32	Group I	88
ID5	05	ID28	1C	ID51	33	Group J	89
ID6	06	ID29	1D	ID52	34	Group K	8A
ID7	07	ID30	1E	ID53	35	Group L	8B
ID8	08	ID31	1F	ID54	36	Group M	8C
ID9	09	ID32	20	ID55	37	Group N	8D
ID10	0A	ID33	21	ID56	38	Group O	8E
ID11	0B	ID34	22	ID57	39	Group P	8F
ID12	0C	ID35	23	ID58	3A	Group Q	90
ID13	0D	ID36	24	ID59	3B	Group R	91
ID14	0E	ID37	25	ID60	3C	Group S	92
ID15	0F	ID38	26	ID61	3D	Group T	93
ID16	10	ID39	27	ID62	3E	Group U	94
ID17	11	ID40	28	ID63	3F	Group V	95
ID18	12	ID41	29	ID64	40	Group W	96
ID19	13	ID42	2A	Group A	80	Group X	97
ID20	14	ID43	2B	Group B	81	Group Y	98
ID21	15	ID44	2C	Group C	82	Group Z	99
ID22	16	ID45	2D	Group D	83		

3.1. Lens Control

Hexadecimal	02h	*1	B1h	7Ch	*2	*3	*4	03h
Remarks	STX	ID	Command		Parameters			ETX

■ Parameters (*2)

	LENS SHIFT H	LENS SHIFT V	LENS FOCUS	LENS ZOOM
Hexadecimal	00h	01h	02h	03h

■ Parameters (*3)

	Slowly	Normal	Fast	Home position *
Hexadecimal	00h	01h	02h	80h

■ Parameters (*4)

	Right / Up / Forward / In / Cancel	Left / Down / Backward / Out / Start
Hexadecimal	00h	01h

■ Note:

- It is effective only when the parameter (*2) is LENS SHIFT H (00h) or LENS SHIFT V (01h).

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*5	B3h	7Ch	*2	*3	*4	03h
	STX	ID	Callback		Parameters			ETX

In the period when the command cannot be accepted

Hexadecimal	02h	*5	FFh	03h
	STX	ID	Error	ETX

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	×	○	○	×	○	○

3.2. SELF CHECK Information

Hexadecimal	02h	*1	FEh	FEh	03h
Remarks	STX	ID	Command	Option	ETX

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*5	FEh	FEh	*2	*3	*4	-	*15	*16	*17	03h
	STX	ID			Parameters							

Acceptability

SECURITY	STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2
○	○	○	○	○	○	○

■ Parameters (*2 - *17)

Bit	Name	Description	Condition of Clear Bit
0	Temperature warning (IN)	Intake air temperature is the specific value or higher.	It is less than the specific value.
1	Temperature warning (OPT)	Optical module (DMD surroundings) temperature is the specific value or higher.	It is less than the specific value.
2	Temperature warning (OUT)	Exhaust air temperature is the specific value or higher.	It is less than the specific value.
3	Low temperature warning (OPT)	Optical module (DMD surroundings) temperature is less than the specific value.	It is the specific value or higher.
4	Temperature error (IN)	Intake air temperature is the specific value or higher.	It is less than the specific value.
5	Temperature error (OPT)	Optical module (DMD surroundings) temperature is the specific value or higher.	It is less than the specific value.
6	Temperature error (OUT)	Exhaust air temperature is the specific value or higher.	It is less than the specific value.
7	Low temperature error (OPT)	Optical module (DMD surroundings) temperature is less than the specific value.	It is the specific value or higher.
8	Lamp 1 operating time warning	Lamp cumulative usage time is the specific value or longer.	Lamp replacement
9	Lamp 2 operating time warning		
10	Lamp 3 operating time warning		
11	Lamp 4 operating time warning		
12	Lamp 1 operating time exceeded		
13	Lamp 2 operating time exceeded	Lamp goes out after turning on.	Executes the lamp turning on processing.
14	Lamp 3 operating time exceeded		
15	Lamp 4 operating time exceeded		
16	Lamp 1 going out		
17	Lamp 2 going out	Lamp ignition failure	
18	Lamp 3 going out		
19	Lamp 4 going out		
20	Lamp 1 lighting failure		
21	Lamp 2 lighting failure	Lamp not installed, or Lamp memory read failure	MAIN POWER ON after the lamp is installed, or Lamp memory initialization
22	Lamp 3 lighting failure		
23	Lamp 4 lighting failure		
24	Lamp 1 not installed		
25	Lamp 2 not installed		
26	Lamp 3 not installed		
27	Lamp 4 not installed		
28	AC power supply voltage drop warning (less than 90 V)		
29	Lamp unit cover is not closed	Lamp unit cover is not closed for 1 second or longer.	POWER ON after the lamp unit cover is closed
30	Special filter selected	"SPECIAL" is selected by AIR FILTER sub menu in EXTRA OPTION.	Selects "NORMAL" by AIR FILTER sub menu in EXTRA OPTION.
31	.		

32	Thermosensor disconnected (IN)	Intake air thermosensor is disconnected.	MAIN POWER ON
33	Thermosensor disconnected (OPT)	Optical module (DMD) thermosensor is disconnected.	
34	Thermosensor disconnected (OUT)	Exhaust air thermosensor is disconnected.	
35	Airflow sensor disconnected	Airflow sensor is disconnected.	
36	Air filter is blocked		
37	Internal clock battery replacement	The date is before December 31, 2005 or after January 1, 2036.	Sets the date after the battery is replaced.
38	-		
39	Air filter unit not installed		
40	-		
41	-		
42	-		
43	-		
44	-		
45	-		
46	-		
47	Fan error 19	G-prism fan	Fan normal operation
48	Fan error 1	Power unit fan	
49	Fan error 2	Lamp fan 1	
50	Fan error 3	Lamp fan 2	
51	Fan error 4	Lamp fan 3	
52	Fan error 5	Lamp fan 4	
53	Fan error 6	Ballast fan 1	
54	Fan error 7	Ballast fan 3	
55	Fan error 8	GB-DMD fan	
56	Fan error 9	Exhaust fan (C)C	
57	Fan error 10	Exhaust fan (L)	
58	Fan error 11	Exhaust fan (R)	
59	Fan error 12	R-DMD fan	
60	Fan error 13	Liquid cooling pump (G)	
61	Fan error 14	Liquid cooling pump (B)	
62	Fan error 15	Color prism fan	
63	Fan error 16	Lamp prism fan	
64	Fan error 17	Ballast fan 2	
65	Fan error 18	Ballast fan 4	
66	Shutter error	Shutter error	Shutter ON/OFF
67	Dynamic iris error		
68	Air filter unit error	Air filter cleaning processing time out	Executes cleaning.
69	2.5 V DC error	The voltage is higher than 120% or lower than 80%.	POWER ON
70	3.3 V DC error		
71	5.0 V DC error		
72	Lamp 1 uninitialization	Lamp EEPROM is not initialized.	Lamp EEPROM initialization
73	Lamp 2 uninitialization		
74	Lamp 3 uninitialization		
75	Lamp 4 uninitialization		
76	-		
77	-		
78	-		
79	-		
80	FPGA1 configuration error		
81	FPGA3 configuration error		DW100* only
82	FPGA2/3 configuration error		DZ12000/D12000* only

83	FLASH ROM error		
84	RAM error		
85	FPGA evolvement error		
86	Lens shift error		
87	Ballast communication error	Fails in the communication with lamp 1 ballast MPU.	POWER ON
88	Ballast communication error	Fails in the communication with lamp 2 ballast MPU.	
89	Ballast communication error	Fails in the communication with lamp 3 ballast MPU.	
90	Ballast communication error	Fails in the communication with lamp 4 ballast MPU.	
91	Optical output restriction for the projector protection	40°C (35°C when ALTITUDE MODE is ON) or higher in ambient temperature at QUAD mode	POWER ON in lower than ambient temperature specified value or sets LAMP SELECT other than QUAD.
92	-		
93	-		
94	-		
95	-		
96	RESIZE setting error		MAIN POWER ON
97	Network CPU communication error		MAIN POWER ON
98	Sub CPU communication error		MAIN POWER ON
99	IIC communication retry 1		
100	IIC communication retry 2		
101	IIC communication retry 3		
102	IIC communication retry 4		
103	IIC communication retry 5		
104	IIC communication retry 6		
105	IIC communication retry 7		
106	IIC communication retry 8		
107	IIC communication retry 9		
108	IIC communication retry 10		
109	IIC communication retry 11		
110	IIC communication retry 12		
111	IIC communication retry 13		
112	IIC communication retry 14		
113	IIC communication retry 15		
114	IIC communication retry 16		
115	A·P.C.Board uninitialization		A·P.C.Board initialization
116	FM·R test failure	RDRAM test error	POWER ON
117	FM·G test failure		
118	FM·B test failure		
119	FPGA1 setting error		
120	FPGA2 setting error		
121	FM communication error	Communication error with FM	MAIN POWER ON
122	WF·Module communication error	Fails in the communication with the geometry IC.	MAIN POWER ON
123	-		
124	-		
125	-		
126	Internal error (Used in main CPU)	All fans have stopped in the factory mode.	POWER ON
127	Internal error (Used in main CPU)	Error Axx has been occurred.	When the error Axx is canceled

■ Note:

- In this projector, must specify option FEh.