

# Control Commands

Model No. **PT-VX500/VX501/VX510 series**  
**PT-VW430/VW431D/VW440 series**  
**PT-VX405KEA/VX45KEA**

## CONTENTS

<b>1. BASIC FORMAT</b> .....	<b>5</b>
<b>2. BASIC CONTROL COMMAND</b> .....	<b>6</b>
2.1. Power ON (LAMP ON) .....	6
2.2. Power OFF (STANDBY).....	6
2.3. VOLUME (+) Key .....	6
2.4. VOLUME (-) Key .....	6
2.5. INPUT SELECT.....	7
2.6. FREEZE Key .....	7
2.7. FREEZE Key (TOGGLE).....	7
2.8. MENU Key.....	8
2.9. ENTER Key .....	8
2.10. UP (↑) Key .....	8
2.11. DOWN (↓) Key.....	8
2.12. LEFT (←) Key .....	8
2.13. RIGHT (→) Key .....	8
2.14. AUTO SETUP Key .....	9
2.15. AV MUTE Key .....	9
2.16. AV MUTE Key (TOGGLE).....	9
2.17. D. ZOOM ▲ Key.....	9
2.18. D. ZOOM ▼ Key.....	9
2.19. KEYSTONE Key.....	10
2.20. DIGITAL LINK Key.....	10
2.21. PICTURE MODE.....	10
2.22. CONTRAST.....	10
2.23. BRIGHTNESS .....	11
2.24. COLOR.....	11

2.25.	TINT.....	11
2.26.	SHARPNESS .....	12
2.27.	COLOR TEMPERATURE.....	12
2.28.	DAYLIGHT VIEW.....	12
2.29.	PROGRESSIVE .....	13
2.30.	NOISE REDUCTION.....	13
2.31.	TV SYSTEM.....	13
2.32.	RGB/YPbPr .....	13
2.33.	KEYSTONE.....	14
2.34.	SHIFT H.....	14
2.35.	SHIFT V.....	14
2.36.	DOT CLOCK .....	15
2.37.	FINE SYNC .....	15
2.38.	SCREEN .....	15
2.39.	LANGUAGE .....	16
2.40.	HDMI SETUP .....	16
2.41.	CLOSED CAPTION SETTING.....	16
2.42.	ASPECT (Only available for model VW430 series) .....	17
2.43.	LOGO .....	17
2.44.	AUTO INPUT MODE SELECTION .....	17
2.45.	INPUT SEARCH.....	17
2.46.	BACKGROUND.....	18
2.47.	DIRECT ON.....	18
2.48.	INSTALLATION .....	18
2.49.	FAN CONTROL.....	18
2.50.	LAMP POWER .....	19
2.51.	POWER MANAGEMENT.....	19
2.52.	STANDBY MODE.....	19
2.53.	EMULATE MODE.....	19
2.54.	VOLUME .....	20
2.55.	MUTE .....	21
2.56.	DIGITAL LINK mode.....	21
2.57.	Duplex (Ethernet) .....	21
2.58.	Duplex (DIGITAL LINK) .....	22
2.59.	DIGITAL LINK SIGNAL LEVEL .....	22
2.60.	Query POWER .....	22
2.61.	Query INPUT SELECT.....	23
2.62.	Query FREEZE .....	23
2.63.	Query AV MUTE .....	23
2.64.	Query PICTURE MODE.....	24
2.65.	Query CONTRAST .....	24
2.66.	Query BRIGHTNESS .....	24

2.67.	Query COLOR.....	25
2.68.	Query TINT.....	25
2.69.	Query SHARPNESS .....	25
2.70.	Query COLOR TEMPERATURE.....	26
2.71.	Query DAYLIGHT VIEW.....	26
2.72.	Query PROGRESSIVE .....	26
2.73.	Query NOISE REDUCTION.....	27
2.74.	Query TV SYSTEM .....	27
2.75.	Query RGB/YPbPr .....	27
2.76.	Query KEYSTONE .....	27
2.77.	Query SHIFT H.....	28
2.78.	Query SHIFT V.....	28
2.79.	Query DOT CLOCK.....	28
2.80.	Query FINE SYNC .....	29
2.81.	Query SCREEN.....	29
2.82.	Query LANGUAGE.....	29
2.83.	Query HDMI SETUP .....	30
2.84.	Query CLOSED CAPTION SETTING .....	30
2.85.	Query ASPECT (Avalable only for model VW430 series).....	30
2.86.	Query LOGO .....	30
2.87.	Query AUTO INPUT MODE SELECTION.....	31
2.88.	Query INPUT SEARCH.....	31
2.89.	Query BACKGROUND.....	31
2.90.	Query DIRECT ON.....	31
2.91.	Query INSTALLATION .....	32
2.92.	Query FAN CONTROL.....	32
2.93.	Query LAMP POWER .....	32
2.94.	Query POWER MANAGMENT .....	32
2.95.	Query STANDBY MODE .....	33
2.96.	Query EMULATE MODE .....	33
2.97.	Query VOLUME .....	34
2.98.	Query DIGITAL LINK Input switch.....	34
2.99.	Query DIGITAL LINK Mode.....	34
2.100.	Query DUPLEX(ETHERNET) .....	35
2.101.	Query DUPLEX(DIGITAL LINK).....	35
2.102.	Query DIGITAL LINK SIGNAL LEVEL .....	36
2.103.	Query DIGITAL LINK STATUS – LINK STATUS .....	36
2.104.	Query DIGITAL LINK STATUS – HDMI STATUS .....	36
2.105.	Query DIGITAL LINK STATUS – SIGNAL QUALITY - MIN.....	37
2.106.	Query DIGITAL LINK STATUS – SIGNAL QUALITY - MAX .....	37
2.107.	Query RUNTIME - LAMP .....	37
2.108.	Query LAMP STATUS .....	38

2.109. Query TEMP INFORMATION..... 38  
2.110. Query SERIAL NUMBER ..... 38  
2.111. Query MAC ADDRESS ..... 38  
2.112. Query RUNTIME - PROJECTOR..... 39  
2.113. Query LAMP SERIAL NUMBER ..... 39

# 1. BASIC FORMAT

Transmission from the computer begins with STX, and then the command, parameter and ETX are set in order. Add parameters according to the details of control.

Basic control command (without parameter)

Start (STX)	Command	End (ETX)
1 byte	3 bytes	1 byte

Basic control command (with parameter)

Start (STX)	Command	Separator (Colon)	Parameters Undefined	End (ETX)
1 byte	3 bytes	1 byte	length	1 byte

Response (Callback) of the basic control command

In the period when the command can be accepted

Differs according to each command

In the period when the command cannot be accepted or not available.

Hexadecimal	02h	45h	52h	34h	30h	31h	03h
Character		E	R	4	0	1	

In case of the parameter error

Hexadecimal	02h	45h	52h	34h	30h	32h	03h
Character		E	R	4	0	2	

Attention:

- When sending several commands, be sure to wait for a response from the projector, and send the next command after 0.5 seconds or more pass.
- It might take time by the time the response returns because the command is processed in the projector. Set the time-out to 10 seconds or longer

## 2. BASIC CONTROL COMMAND

### Explanatory notes

- : Enable
- ×: Disable

#### 2.1. Power ON (LAMP ON)

Hexadecimal	02h	50h	4Fh	4Eh	03h
Character		P	O	N	

##### ■Response (Callback)

In the period when the command can be accepted (This command in power-on condition is included.)

Hexadecimal	02h	50h	4Fh	4Eh	03h
Character		P	O	N	

##### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
×	○	○	×	×	×

##### ■Note:

- When you confirm whether to have succeeded in power-on, confirm it by QPW (Query Power) command after receiving the callback of PON command.

#### 2.2. Power OFF (STANDBY)

Hexadecimal	02h	50h	4Fh	46h	03h
Character		P	O	F	

##### ■Response (Callback)

In the period when the command can be accepted (This command in power-on condition is included.)

Hexadecimal	02h	50h	4Fh	46h	03h
Character		P	O	F	

##### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	×	×	○	○	○

##### ■Note:

- When you confirm whether to have succeeded in power-off, confirm it by QPW (Query Power) command after receiving the callback of PON command.

#### 2.3. VOLUME (+) Key

Hexadecimal	02h	41h	55h	55h	03h
Character		A	U	U	

##### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	55h	55h	03h
Character		A	U	U	

##### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
×	×	×	○	○	○

#### 2.4. VOLUME (−) Key

Hexadecimal	02h	41h	55h	44h	03h
Character		A	U	D	

##### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	55h	44h	03h
Character		A	U	D	

##### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
×	×	×	○	○	○

## 2.5. INPUT SELECT

Hexadecimal Character	02h	49h	49h	53h	3Ah	*1	*3	*5	03h
		I	I	S	:	*2	*4	*6	

### Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	COMPUTER1			COMPUTER2		
Hexadecimal Character	52h	47h	31h	52h	47h	32h
	R	G	1	R	G	2
	VIDEO			S-VIDEO		
Hexadecimal Character	56h	49h	44h	53h	56h	44h
	V	I	D	S	V	D
	SCART			HDMI		
Hexadecimal Character	53h	43h	54h	48h	44h	31h
	S	C	T	H	D	1
	DIGITAL LINK					
Hexadecimal Character	44h	4Ch	31h			
	D	L	1			

### Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	49h	49h	53h	3Ah	*1	*3	*5	03h
		I	I	S	:	*2	*4	*6	

### [Model PT-VW431D]

Hexadecimal Character	02h	49h	49h	53h	3Ah	44h	4Ch	31h
		I	I	S	:	D	L	1
Hexadecimal Character	3Ah	*1	*3	*5	03h			
	:	*2	*4	*6				

### Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	HDMI1			HDMI2		
Hexadecimal Character	48h	44h	31h	48h	44h	32h
	H	D	1	H	D	2
	COMPUTER1			COMPUTER2		
Hexadecimal Character	50h	43h	31h	50h	43h	32h
	P	C	1	P	C	2
	VIDEO			S-VIDEO		
Hexadecimal Character	56h	49h	44h	53h	56h	44h
	V	I	D	S	V	D

- Effective only for DIGITAL LINK connection, otherwise it returns ER401.

### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### Note:

- When the "Monitor out" is selected for COMPUTER2 with the terminal setting and then COMPUTER2 is selected, ER401 is returned. OnlyVW431D supports DIGITAL LINK function.

## 2.6. FREEZE Key

Hexadecimal Character	02h	4Fh	46h	5Ah	3Ah	*1	03h
		O	F	Z	:	*2	

### Parameters (\*1,\*2)

	OFF	ON
Hexadecimal Character	30h	31h
	0	1

### Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	46h	5Ah	3Ah	*1	03h
		O	F	Z	:	*2	

### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

## 2.7. FREEZE Key (TOGGLE)

Hexadecimal Character	02h	4Fh	46h	5Ah	03h
		O	F	Z	

### Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	46h	5Ah	03h
		O	F	Z	

### Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

## 2.8. MENU Key

Hexadecimal	02h	4Fh	4Dh	4Eh	03h
Character		O	M	N	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Dh	4Eh	03h
Character		O	M	N	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.9. ENTER Key

Hexadecimal	02h	4Fh	45h	4Eh	03h
Character		O	E	N	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	4Eh	03h
Character		O	E	N	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	x	x	o	o	o

## 2.10. UP (↑) Key

Hexadecimal	02h	4Fh	43h	55h	03h
Character		O	C	U	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	55h	03h
Character		O	C	U	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	x	x	o	o	o

## 2.11. DOWN (↓) Key

Hexadecimal	02h	4Fh	43h	44h	03h
Character		O	C	D	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	44h	03h
Character		O	C	D	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	x	x	o	o	o

## 2.12. LEFT (←) Key

Hexadecimal	02h	4Fh	43h	4Ch	03h
Character		O	C	L	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	4Ch	03h
Character		O	C	L	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	x	x	o	o	o

## 2.13. RIGHT (→) Key

Hexadecimal	02h	4Fh	43h	52h	03h
Character		O	C	R	



■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	52h	03h
Character		O	C	R	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	x	x	○	○	○

2.14. AUTO SETUP Key

Hexadecimal	02h	4Fh	41h	53h	03h
Character		O	A	S	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	53h	03h
Character		O	A	S	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	○	○	○

2.15. AV MUTE Key

Hexadecimal	02h	4Fh	53h	48h	3Ah	*1	03h
Character		O	S	H	:	*2	

■Parameters (\*1,\*2)

	AV MUTE OFF	AV MUTE ON
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	48h	3Ah	*1	03h
Character		O	S	H	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	○	○	○

2.16. AV MUTE Key (TOGGLE)

Hexadecimal	02h	4Fh	53h	48h	03h
Character		O	S	H	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	48h	03h
Character		O	S	H	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	○	○	○

2.17. D. ZOOM ▲ Key

Hexadecimal	02h	44h	5Ah	55h	03h
Character		D	Z	U	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	5Ah	55h	03h
Character		D	Z	U	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	○	○

2.18. D. ZOOM ▼ Key

Hexadecimal	02h	44h	5Ah	44h	03h
Character		D	Z	D	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	5Ah	44h	03h
Character		D	Z	D	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.19. KEYSTONE Key

Hexadecimal Character	02h	4Bh	53h	54h	03h
		K	S	T	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Bh	53h	54h	03h
		K	S	T	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.20. DIGITAL LINK Key

Hexadecimal Character	02h	44h	4Ch	4Bh	03h
		D	L	K	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Ch	4Bh	03h
		D	L	K	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

\*Only VW431D supports DIGITAL LINK function.

2.21. PICTURE MODE

Hexadecimal Character	02h	56h	50h	4Dh	3Ah	*1	*3	*5	03h
		V	P	M	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	DYNAMIC			STANDARD			CINEMA		
Hexadecimal Character	44h	59h	4Eh	53h	54h	44h	43h	49h	4Eh
	D	Y	N	S	T	D	C	I	N
	REAL			BLACK BOARD			COLOR BOARD		
Hexadecimal Character	52h	45h	41h	42h	42h	44h	43h	42h	44h
	R	E	A	B	B	D	C	B	D
	IMAGE 1			IMAGE 2			IMAGE 3		
Hexadecimal Character	49h	4Dh	31h	49h	4Dh	32h	49h	4Dh	33h
	I	M	1	I	M	2	I	M	3
	IMAGE 4								
Hexadecimal Character	49h	4Dh	34h						
	I	M	4						

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	50h	4Dh	3Ah	*1	*3	*5	03h
		V	P	M	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.22. CONTRAST

Hexadecimal Character	02h	56h	43h	4Eh	3Ah	*1	*3	*5	03h
		V	C	N	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	43h	4Eh	3Ah	*1	*3	*5	03h
		V	C	N	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.23. BRIGHTNESS

Hexadecimal Character	02h	56h	42h	52h	3Ah	*1	*3	*5	03h
		V	B	R	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	42h	52h	3Ah	*1	*3	*5	03h
		V	B	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.24. COLOR

Hexadecimal Character	02h	56h	43h	4Fh	3Ah	*1	*3	*5	03h
		V	C	O	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	43h	4Fh	3Ah	*1	*3	*5	03h
		V	C	O	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.25. TINT

Hexadecimal Character	02h	56h	54h	4Eh	3Ah	*1	*3	*5	03h
		V	T	N	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	54h	4Eh	3Ah	*1	*3	*5	03h
		V	T	N	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.26. SHARPNESS

Hexadecimal Character	02h	56h	53h	52h	3Ah	*1	*3	*5	03h
		V	S	R	:	*2	*4	*6	

### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal Character	30h	31h	33h	30h	31h	34h	30h	31h	35h
	0	1	3	0	1	4	0	1	5

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	53h	52h	3Ah	*1	*3	*5	03h
		V	S	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.27. COLOR TEMPERATURE

[LOW/MID/HIGH]

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1	03h
		O	T	E	:	*2	

### ■Parameters (\*1,\*2)

	LOW	MID	HIGH
Hexadecimal Character	30h	31h	32h
	0	1	2

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1	03h
		O	T	E	:	*2	

[XLOW]

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1	*3	03h
		O	T	E	:	*2	*4	

### ■Parameters (\*1,\*2,\*3,\*4)

	XLOW	
Hexadecimal Character	31h	31h
	1	1

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1	*3	03h
		O	T	E	:	*2	*4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.28. DAYLIGHT VIEW

Hexadecimal Character	02h	56h	58h	58h	3Ah	44h	4Ch	56h	49h
		V	X	X	:	D	L	V	I
Hexadecimal Character	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	0	=	+	*2	*4	*6	*8	*1-	

### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

In case of Front Installation

	OFF				
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0
	AUTO				
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1
	ON				
Hexadecimal Character	30h	30h	30h	30h	32h
	0	0	0	0	2

In case of Rear Installation

	OFF				
Hexadecimal Character	30h	30h	30h	30h	30h

Character	0	0	0	0	0
	ON				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

## 2.29. PROGRESSIVE

Hexadecimal	02h	4Fh	50h	44h	3Ah	*1	03h
Character		O	P	D	:	*2	

### ■Parameters (\*1,\*2)

	FILM	OFF	L1
Hexadecimal	30h	31h	32h
Character	0	1	2

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	50h	44h	3Ah	*1	03h
Character		O	P	D	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### ■Note:

- This command is available only when an interlaced signal is inputted. In other cases, ER401 is returned.

## 2.30. NOISE REDUCTION

Hexadecimal	02h	56h	4Eh	52h	3Ah	*1	03h
Character		V	N	R	:	*2	

### ■Parameters (\*1,\*2)

	OFF	L1	L2
Hexadecimal	30h	31h	32h
Character	0	1	2

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Eh	52h	3Ah	*1	03h
Character		V	N	R	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.31. TV SYSTEM

Hexadecimal	02h	56h	53h	47h	3Ah	*1	*3	*5	03h
Character		V	S	G	:	*2	*4	*6	

### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	AUTO			NTSC			NTSC4.43			PAL		
Hexadecimal	41h	55h	54h	4Eh	54h	53h	4Eh	34h	34h	50h	41h	4Ch
Character	A	U	T	N	T	S	N	4	4	P	A	L
	PAL-M			PAL-N			SECAM					
Hexadecimal	50h	41h	4Dh	50h	41h	4Eh	53h	45h	43h			
Character	P	A	M	P	A	N	S	E	C			

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	47h	3Ah	*1	*3	*5	03h
Character		V	S	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### ■Note:

- This command is acceptable only when the input is VIDEO or S-VIDEO. In other cases, ER401 is returned.

## 2.32. RGB/YPbPr

Hexadecimal	02h	4Fh	52h	46h	3Ah	*1	03h
Character		O	R	F	:	*2	

### ■Parameters (\*1,\*2)

	YPbPr
Hexadecimal	31h
Character	1

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	52h	46h	3Ah	*1	03h
Character		O	R	F	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- This command is acceptable only when the input is Computer 1-RGB or Computer 1-component.

### 2.33. KEYSTONE

Hexadecimal	02h	4Fh	4Bh	53h	3Ah	*1	*3	*5	03h
Character		O	K	S	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	-60			-59			-58		
Hexadecimal	2Dh	36h	30h	2Dh	35h	39h	2Dh	35h	38h
Character	-	6	0	-	5	9	-	5	8
	58			59			60		
Hexadecimal	30h	35h	38h	30h	35h	39h	30h	36h	30h
Character	0	5	8	0	5	9	0	6	0

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Bh	53h	3Ah	*1	*3	*5	03h
Character		O	K	S	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### 2.34. SHIFT H

Hexadecimal	02h	56h	48h	50h	3Ah	*1	*3	*5	*7	03h
Character		V	H	P	:	*2	*4	*6	*8	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0				1			
Hexadecimal	30h	30h	03h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	1
	319				320			
Hexadecimal	30h	33h	31h	39h	30h	33h	32h	30h
Character	0	3	1	9	0	3	20	0

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	50h	3Ah	*1	*3	*5	*7	03h
Character		V	H	P	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.  
- The parameter differs according to the input signals.

### 2.35. SHIFT V

Hexadecimal	02h	56h	56h	50h	3Ah	*1	*3	*5	03h
Character		V	V	P	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	3-h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	36			37			38		
Hexadecimal	30h	33h	36h	30h	33h	37h	30h	33h	38h
Character	0	3	6	0	3	7	0	3	8

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	56h	50h	3Ah	*1	*3	*5	03h
Character		V	V	P	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.

- The parameter differs according to the input signals.

### 2.36. DOT CLOCK

Hexadecimal	02h	56h	44h	43h	3Ah	*1	*3	*5	03h
Character		V	D	C	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	1190				1189			
Hexadecimal	31h	31h	39h	30h	31h	31h	38h	39h
Character	1	1	9	0	1	1	8	9
	2894				2895			
Hexadecimal	32h	38h	39h	34h	32h	38h	39h	35h
Character	2	8	9	4	2	8	9	5

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	44h	43h	3Ah	*1	*3	*5	03h
Character		V	D	C	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the input signals.

### 2.37. FINE SYNC

Hexadecimal	02h	56h	43h	50h	3Ah	*1	*3	*5	03h
Character		V	C	P	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29			30			31		
Hexadecimal	30h	32h	39h	30h	33h	30h	30h	33h	31h
Character	0	2	9	0	3	0	0	3	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	50h	3Ah	*1	*3	*5	03h
Character		V	C	P	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.

### 2.38. SCREEN

Hexadecimal	02h	56h	53h	31h	3Ah	*1	*3	03h
Character		V	S	1	:	*2	*4	

■Parameters (\*1,\*2,\*3,\*4)

	NORMAL		WIDE		TRUE		FULL		ZOOM	
Hexadecimal	30h	31h	30h	32h	30h	35h	30h	36h	34h	30h
Character	0	1	0	2	0	5	0	6	4	0
	PITTARI-WIDE		CUSTOM							
Hexadecimal	36h	30h	35h	30h						
Character	6	0	5	0						

\* PITTARI-WIDE is only available for model VW430 series.

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	31h	3Ah	*1	*3	03h
Character		V	S	1	:	*2	*4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When unselective mode is selected at the no signal, ER401 is returned.

### 2.39. LANGUAGE

Hexadecimal Character	02h	4Fh	4Ch	47h	3Ah	*1	*3	*5	03h
		O	L	G	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,)

	English			German			French		
Hexadecimal Character	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
	E	N	G	D	E	U	F	R	A
	Spanish			Italian			Japanese		
Hexadecimal Character	45h	53h	50h	49h	54h	4Ch	4Ah	50h	4Eh
	E	S	P	I	T	L	J	P	N
	Chinese			Russian			Korean		
Hexadecimal Character	43h	48h	49h	52h	55h	53h	4Bh	4Fh	52h
	C	H	I	R	U	S	K	O	R
	Portuguese			Swedish			Norwegian		
Hexadecimal Character	50h	4Fh	52h	53h	56h	45h	4Eh	4Fh	52h
	P	O	R	S	V	E	N	O	R
	Danish			Polish			Czech		
Hexadecimal Character	44h	41h	4Eh	50h	4Fh	4Ch	43h	45h	53h
	D	A	N	P	O	L	C	E	S
	Hungarian			Thai			Holland		
Hexadecimal Character	4Dh	41h	47h	54h	48h	41h	4Eh	4Ch	44h
	M	A	G	T	H	A	N	L	D
	Finland			Romanian			Turkish		
Hexadecimal Character	46h	49h	4Eh	52h	55h	4Dh	54h	55h	52h
	F	I	N	R	U	M	T	U	R
	Arabic			kazakhstan			Vietnamese		
Hexadecimal Character	41h	52h	41h	4Bh	41h	5Ah	56h	49h	45h
	A	R	A	K	A	Z	V	I	E

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	4Ch	47h	3Ah	*1	*3	*5	03h
		O	L	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### 2.40. HDMI SETUP

Hexadecimal Character	02h	56h	58h	58h	3Ah	48h	53h	4Ch	49h
		V	X	X	:	H	S	L	I
Hexadecimal Character	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	0	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	EXPAND				
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0
	NORMAL				
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	58h	58h	3Ah	48h	53h	4Ch	49h
		V	X	X	:	H	S	L	I
Hexadecimal Character	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	0	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### 2.41. CLOSED CAPTION SETTING

Hexadecimal Character	02h	4Fh	43h	43h	3Ah	*1	03h
		O	C	C	:	*2	

■Parameters (\*1,\*2)

	OFF	CC1	CC2	CC3	CC4
Hexadecimal Character	30h	31h	32h	33h	34h
	0	1	2	3	4

■Response (Callback)

In the period when the command can be accepted



Hexadecimal Character	02h	4Fh	43h	43h	3Ah	*1	03h
		O	C	C	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■Note:

- This command is effective only when the system is fixed with "NTSC" and the proper signals (NTSC Video or S-Video signal) are input.

2.42. ASPECT (Only available for model VW430 series)

Hexadecimal Character	02h	56h	53h	46h	3Ah	*1	03h
		V	S	F	:	*2	

■Parameters (\*1,\*2)

	16:10	16:9	4:3
Hexadecimal Character	30h	31h	32h
	0	1	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	53h	46h	3Ah	*1	03h
		V	S	F	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.43. LOGO

Hexadecimal Character	02h	4Dh	4Ch	4Fh	3Ah	*1	03h
		M	L	O	:	*2	

■Parameters (\*1,\*2)

	OFF	USER	DEFAULT
Hexadecimal Character	30h	31h	32h
	0	1	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Dh	4Ch	4Fh	3Ah	*1	03h
		M	L	O	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When the Logo PIN code is "ON", ER401 is returned.  
 - When the user registered Logo is not available, "OFF" and "DEFAULT" are effective. In other cases, ER401 is returned.

2.44. AUTO INPUT MODE SELECTION

Hexadecimal Character	02h	4Fh	53h	53h	3Ah	*1	03h
		O	S	S	:	*2	

■Parameters (\*1,\*2)

	ON1	ON2
Hexadecimal Character	30h	31h
	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	53h	53h	3Ah	*1	03h
		O	S	S	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- This command is effective only when the Signal Search selects "ON2". In other cases, ER401 is returned.

2.45. INPUT SEARCH

Hexadecimal Character	02h	4Fh	53h	52h	3Ah	*1	03h
		O	S	R	:	*2	

■Parameters (\*1,\*2)

	OFF	ON2
Hexadecimal Character	30h	31h

Character	0	1
-----------	---	---

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	52h	3Ah	*1	03h
Character		O	S	R	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.46. BACKGROUND

Hexadecimal	02h	4Fh	42h	43h	3Ah	*1	03h
Character		O	B	C	:	*2	

■Parameters (\*1,\*2)

	BLUE	BLACK	USER
Hexadecimal	30h	31h	32h
Character	0	1	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	42h	43h	3Ah	*1	03h
Character		O	B	C	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When the user registerd Logo is not available, "BLUE" and "BLACK" are effective. In other cases, ER401 is returned.

## 2.47. DIRECT ON

Hexadecimal	02h	4Fh	50h	59h	3Ah	*1	03h
Character		O	P	Y	:	*2	

■Parameters (\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	50h	59h	3Ah	*1	03h
Character		O	P	Y	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.48. INSTALLATION

Hexadecimal	02h	4Fh	49h	4Ch	3Ah	*1	03h
Character		O	I	L	:	*2	

■Parameters (\*1,\*2)

	FRONT/DESK	REAR/DESK	FRONT / CEILING	REAR/CEILING
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	49h	4Ch	3Ah	*1	03h
Character		O	I	L	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.49. FAN CONTROL

Hexadecimal	02h	4Fh	46h	4Dh	3Ah	*1	03h
Character		O	F	M	:	*2	

■Parameters (\*1,\*2)

	OFF	ON1
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	4Dh	3Ah	*1	03h
Character		O	F	M	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.50. LAMP POWER

Hexadecimal	02h	4Fh	4Ch	50h	3Ah	*1	03h
Character		O	L	P	:	*2	

■Parameters (\*1,\*2)

	ECO	NORMAL
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	50h	3Ah	*1	03h
Character		O	L	P	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.51. POWER MANAGEMENT

Hexadecimal	02h	4Fh	41h	46h	3Ah	*1	*3	03h
Character		O	A	F	:	*2	*4	

■Parameters (\*1,\*2,\*3,\*4)

	OFF		15		30	
Hexadecimal	30h	30h	31h	35h	33h	30h
Character	0	0	1	5	3	0

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	46h	3Ah	*1	*3	03h
Character		O	A	F	:	*2	*4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When setting "01" to "30", the setting of Power Magement is set "Shut down" forcibly..

## 2.52. STANDBY MODE

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	4Dh	49h
Character		V	X	X	:	S	T	M	I
Hexadecimal	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	0	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
	ECO				
Hexadecimal	30h	30h	30h	30h	33h
Character	0	0	0	0	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	4Dh	49h
Character		V	X	X	:	S	T	M	I
Hexadecimal	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	0	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

## 2.53. EMULATE MODE

Hexadecimal	02h	56h	58h	58h	3Ah	45h	4Dh	55h	49h
Character		V	X	X	:	E	M	U	I
Hexadecimal	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	0	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

DEFAULT				
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1
D3500				
Hexadecimal Character	30h 0	30h 0	30h 0	32h 2
D4000				
Hexadecimal Character	30h 0	30h 0	30h 0	33h 3
D/W5k series				
Hexadecimal Character	30h 0	30h 0	30h 0	34 4
D/W/Z6k series				
Hexadecimal Character	30h 0	30h 0	30h 0	35h 5
L730				
Hexadecimal Character	30h 0	30h 0	30h 0	36h 6
L780				
Hexadecimal Character	30h 0	30h 0	30h 0	37h 7
L735				
Hexadecimal Character	30h 0	30h 0	30h 0	38h 8
L785				
Hexadecimal Character	30h 0	30h 0	30h 0	39h 9
LB/W series				
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1
F/W series				
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1
LZ370				
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1
VX/VW series				
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	58h	58h	3Ah	45h	4Dh	55h	49h
Character		V	X	X	:	E	M	U	I
Hexadecimal Character	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	0	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.54. VOLUME

Hexadecimal Character	02h	41h	56h	4Ch	3Ah	*1	*3	*5	03h
Character		A	V	L	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

		0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h	
Character	0	0	0	0	0	1	0	0	2	
		61		62			63			
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h	
Character	0	6	1	0	6	2	0	6	3	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	41h	56h	4Ch	3Ah	*1	*3	*5	03h
Character		A	V	L	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### 2.55. MUTE

Hexadecimal Character	02h	41h	4Dh	54h	3Ah	*1	03h
		A	M	T	:	*2	

■Parameters (\*1,\*2)

	Off	On
Hexadecimal Character	30h	31h
	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	41h	40h	54h	3Ah	*1	03h
		A	M	T	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

### 2.56. DIGITAL LINK mode

Hexadecimal Character	02h	56h	58h	58h	3Ah	44h	4Bh	4Dh	49h
		V	X	X	:	D	K	M	I
Hexadecimal Character	31h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	1	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO				
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1
	DIGITAL LINK				
Hexadecimal Character	30h	30h	30h	30h	32h
	0	0	0	0	2
	Ethernet				
Hexadecimal Character	30h	30h	30h	30h	33h
	0	0	0	0	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	58h	58h	3Ah	44h	4Bh	4Dh	49h
		V	X	X	:	D	K	M	I
Hexadecimal Character	31h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	1	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

\*Note

Only VW431D supports this function,

### 2.57. Duplex (Ethernet)

Hexadecimal Character	02h	56h	58h	58h	3Ah	44h	4Bh	44h	49h
		V	X	X	:	D	K	D	I
Hexadecimal Character	31h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	1	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	Autonegotiation				
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0
	100BaseTX-Full				
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1
	100BaseTX-Half				
Hexadecimal Character	30h	30h	30h	30h	32h
	0	0	0	0	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	58h	58h	3Ah	44h	4Bh	44h	49h
		V	X	X	:	D	K	D	I
Hexadecimal Character	31h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
	1	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

\*Note

Only VW431D supports this function,

### 2.58. Duplex (DIGITAL LINK)

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Bh	44h	49h
Character		V	X	X	:	D	K	D	I
Hexadecimal	32h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	2	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

Autonegotiation					
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
100BaseTX-Full					
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1
100BaseTX-Half					
Hexadecimal	30h	30h	30h	30h	32h
Character	0	0	0	0	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Bh	44h	49h
Character		V	X	X	:	D	K	D	I
Hexadecimal	32h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	2	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

\*Note

Only VW431D supports this function,

### 2.59. DIGITAL LINK SIGNAL LEVEL

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Bh	4Ch	49h
Character		V	X	X	:	D	K	L	I
Hexadecimal	31h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	1	=	+	*2	*4	*6	*8	*10	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

ENHANCED (0-1023)					
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1
NORMAL (64-940)					
Hexadecimal	30h	30h	30h	30h	32h
Character	0	0	0	0	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Bh	4Ch	49h
Character		V	X	X	:	D	K	L	I
Hexadecimal	31h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	1	=	+	*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

\*Note

Only VW431D supports this function,

### 2.60. Query POWER

Hexadecimal	02h	51h	50h	57h	03h
Character		Q	P	W	:

■Response (Callback)

OFF

Hexadecimal	02h	30h	30h	30h	03h
Character		0	0	0	

ON

Hexadecimal	02h	30h	30h	31h	03h
Character		0	0	1	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	o	o	o	o	o

2.61. Query INPUT SELECT

Hexadecimal	02h	51h	49h	4Eh	03h
Character		Q	I	N	

■Response (Callback)

COMPUTER1

Hexadecimal	02h	52h	47h	31h	03h
Character		R	G	1	

COMPUTER2

Hexadecimal	02h	52h	47h	32h	03h
Character		R	G	2	

VIDEO

Hexadecimal	02h	56h	49h	44h	03h
Character		V	I	D	

S-VIDEO

Hexadecimal	02h	53h	56h	44h	03h
Character		S	V	D	

COMPONENT

Hexadecimal	02h	52h	47h	31h	03h
Character		R	G	1	

SCART

Hexadecimal	02h	53h	43h	54h	03h
Character		S	C	T	

HDMI

Hexadecimal	02h	48h	44h	31h	03h
Character		H	D	1	

DIGITAL LINK (only VW431D)

Hexadecimal	02h	44h	4Ch	31h	03h
Character		D	L	1	

[VW431D]

Hexadecimal	02h	44h	4Ch	31h	3Ah	*1	*3	*5	03h
Character		D	L	1	:	*2	*4	*6	

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	HDMI1			HDMI2		
Hexadecimal	48h	44h	31h	48h	44h	32h
Character	H	D	1	H	D	2
	COMPUTER1			COMPUTER2		
Hexadecimal	50h	43h	31h	50h	43h	32h
Character	P	C	1	P	C	2
	VIDEO			S-VIDEO		
Hexadecimal	56h	49h	44h	53h	56h	44h
Character	V	I	D	S	V	D

- Effective only for DIGITAL LINK connection, otherwise it returns ER401.

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

2.62. Query FREEZE

Hexadecimal	02h	51h	46h	5Ah	03h
Character		Q	F	Z	

■Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

2.63. Query AV MUTE

Hexadecimal	02h	51h	53h	48h	03h
Character		Q	S	H	

■Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal Character	02h	31h	03h
		1	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

## 2.64. Query PICTURE MODE

Hexadecimal Character	02h	51h	50h	4Dh	03h
		Q	P	M	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1	*3	*5	03h
		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	STANDARD			DYNAMIC			CINEMA		
Hexadecimal Character	53h	54h	44h	44h	59h	4Eh	43h	49h	4Eh
	S	T	D	D	Y	N	C	I	N
	REAL			BLACK BOARD			COLOR BOARD		
Hexadecimal Character	52h	45h	41h	42h	42h	44h	43h	42h	44h
	R	E	A	B	B	D	C	B	D
	IMAGE 1			IMAGE 2			IMAGE 3		
Hexadecimal Character	49h	4Dh	31h	49h	4Dh	32h	49h	4Dh	33h
	I	M	1	I	M	2	I	M	3
	IMAGE 4								
Hexadecimal Character	49h	4Dh	34h						
	I	M	4						

## 2.65. Query CONTRAST

Hexadecimal Character	02h	51h	56h	52h	03h
		Q	V	R	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1	*3	*5	03h
		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
	0	6	1	0	6	2	0	6	3

## 2.66. Query BRIGHTNESS

Hexadecimal Character	02h	51h	56h	42h	03h
		Q	V	B	

### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1	*3	*5	03h
		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
	0	6	1	0	6	2	0	6	3



2.67. Query COLOR

Hexadecimal	02h	51h	56h	43h	03h
Character		Q	V	C	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.68. Query TINT

Hexadecimal	02h	51h	56h	54h	03h
Character		Q	V	T	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.69. Query SHARPNESS

Hexadecimal	02h	51h	56h	53h	03h
Character		Q	V	S	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal	30h	31h	33h	30h	31h	34h	30h	31h	35h
Character	0	1	3	0	1	4	0	1	5

### 2.70. Query COLOR TEMPERATURE

Hexadecimal	02h	51h	54h	45h	03h
Character		Q	T	E	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	XLOW		LOW	MID	HIGH
Hexadecimal	31h	31h	30h	31h	32h
Character	1	1	0	1	2

### 2.71. Query DAYLIGHT VIEW

Hexadecimal	02h	51h	56h	58h	3Ah	44h	4Ch	56h	49h	30h	03h
Character		Q	V	X	:	D	L	V	I	0	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	4Ch	56h	49h	30h	3Dh	2Bh
Character		D	L	V	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	*03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

In case of Front Installation

	OFF				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
	AUTO				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1
	ON				
Hexadecimal	30h	30h	30h	30h	32h
Character	0	0	0	0	2

In case of Rear Installation

	OFF				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
	ON				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

### 2.72. Query PROGRESSIVE

Hexadecimal	02h	51h	50h	44h	03h
Character		Q	P	D	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	FILM	OFF	ON
Hexadecimal	30h	31h	32h
Character	0	1	2

■Note:

- This command is available only when an interlaced signal is inputted. In other cases, ER401 is returned.

### 2.73. Query NOISE REDUCTION

Hexadecimal	02h	51h	4Eh	52h	03h
Character		Q	N	R	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	OFF	L1	L2
Hexadecimal	30h	31h	32h
Character	0	1	2

### 2.74. Query TV SYSTEM

Hexadecimal	02h	51h	53h	47h	03h
Character		Q	S	G	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	AUTO			NTSC			NTSC4.43			PAL		
Hexadecimal	41h	55h	54h	4Eh	54h	53h	4Eh	34h	34h	50h	41h	4Ch
Character	A	U	T	N	T	S	N	4	4	P	A	L
	PAL-M			PAL-N			SECAM					
Hexadecimal	50h	41h	4Dh	50h	41h	4Eh	53h	45h	43h			
Character	P	A	M	P	A	N	S	E	C			

■Note:

- This command is acceptable only when the input is VIDEO or S-VIDEO. In other cases, ER401 is returned.

### 2.75. Query RGB/YPbPr

Hexadecimal	02h	51h	52h	46h	03h
Character		Q	R	F	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	RGB	YPbPr
Hexadecimal	30h	31h
Character	0	1

### 2.76. Query KEYSTONE

Hexadecimal	02h	51h	4Bh	53h	03h
Character		Q	K	S	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	-60			-59			-58		
Hexadecimal	2Dh	36h	30h	2Dh	35h	39h	2Dh	35h	38h
Character	-	6	0	-	5	9	-	5	8
	58			59			60		

Hexadecimal	30h	35h	38h	30h	35h	39h	30h	36h	30h
Character	0	5	8	0	5	9	0	6	0

### 2.77. Query SHIFT H

Hexadecimal	02h	51h	48h	50h	03h
Character		Q	H	P	

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

#### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0				1			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	1
	319				320			
Hexadecimal	30h	33h	31h	39h	30h	33h	32h	30h
Character	0	3	1	9	0	3	2	0

#### ■Note:

- This command is acceptable only when the input is COMPUTER.. In other cases, ER401 is returned.
- The parameter differs according to the Input signals.

### 2.78. Query SHIFT V

Hexadecimal	02h	51h	56h	50h	03h
Character		Q	V	P	

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

#### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	36			37			38		
Hexadecimal	30h	33h	36h	30h	33h	37h	30h	33h	38h
Character	0	3	6	0	3	7	0	3	8

#### ■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the Input signals.

### 2.79. Query DOT CLOCK

Hexadecimal	02h	51h	44h	43h	03h
Character		Q	D	C	

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

#### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	1190				1189			
Hexadecimal	31h	31h	39h	30h	31h	31h	38h	39h
Character	1	1	9	0	1	1	8	9
	2894				2895			
Hexadecimal	32h	38h	39h	30h	32h	38h	39h	35h
Character	2	8	9	4	2	8	9	5

#### ■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the Input signals.

### 2.80. Query FINE SYNC

Hexadecimal	02h	51h	43h	50h	03h
Character		Q	C	P	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29			30			31		
Hexadecimal	30h	32h	39h	30h	33h	30h	30h	33h	31h
Character	0	2	9	0	3	0	0	3	1

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.

### 2.81. Query SCREEN

Hexadecimal	02h	51h	53h	31h	03h
Character		Q	S	1	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4)

	NORMAL		WIDE		TRUE		FULL		ZOOM	
Hexadecimal	30h	31h	30h	32h	30h	35h	30h	36h	34h	30h
Character	0	1	0	2	0	5	0	6	4	0
	PITTARI-WIDE		COSTOM							
Hexadecimal	36h	30h	35h	30h						
Character	6	0	5	0						

\*PITTARI-WIDE is only available for model VW430 series.

### 2.82. Query LANGUAGE

Hexadecimal	02h	51h	4Ch	47h	03h
Character		Q	L	G	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	English			German			French		
Hexadecimal	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
Character	E	N	G	D	E	U	F	R	A
	Spanish			Italian			Japanese		
Hexadecimal	45h	53h	50h	49h	54h	4Ch	4Ah	50h	4Eh
Character	E	S	P	I	T	L	J	P	N
	Chinese			Russian			Korean		
Hexadecimal	43h	48h	49h	52h	55h	53h	4Bh	4Fh	52h
Character	C	H	I	R	U	S	K	O	R
	Portuguese			Swedish			Norwegian		
Hexadecimal	50h	4Fh	52h	53h	56h	45h	4Eh	4Fh	52h
Character	P	O	R	S	V	E	N	O	R
	Danish			Polish			Czech		
Hexadecimal	44h	41h	4Eh	50h	4Fh	4Ch	43h	45h	53h
Character	D	A	N	P	O	L	C	E	S
	Hungarian			Thai			Hooland		
Hexadecimal	4Dh	41h	47h	54h	48h	41h	4Eh	4Ch	44h

Character	M	A	G	T	H	A	N	L	D
	Finland			Romanian			Turkish		
Hexadecimal Character	46h	49h	4Eh	52h	55h	4Dh	54h	55h	52h
	F	I	N	R	U	M	T	U	R
	Arabic			Kazakhstan			Vietnamese		
Hexadecimal Character	41h	52h	41h	4Bh	41h	5Ah	56h	49h	45h
	A	R	A	K	A	Z	V	I	E

### 2.83. Query HDMI SETUP

Hexadecimal Character	02h	51h	56h	58h	3Ah	48h	53h	4Ch	49h	30h	03h
	Q	V	X	:	H	S	L	I	0		

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	48h	53h	4Ch	49h	30h	3Dh	2Bh
		H	S	L	I	0	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

#### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	EXPAND				
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0
	NORMAL				
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1

### 2.84. Query CLOSED CAPTION SETTING

Hexadecimal Character	02h	51h	43h	43h	03h
	Q	C	C		

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1	03h
		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

#### ■Parameters (\*1,\*2)

	OFF	CC1	CC2	CC3	CC4
Hexadecimal Character	30h	31h	32h	33h	34h
	0	1	2	3	4

#### ■Note:

- This command is effective only when the system is fixed with "NTSC" and the proper signals (NTSC Video or S-Video signal) are input.

### 2.85. Query ASPECT (Available only for model VW430 series)

Hexadecimal Character	02h	51h	53h	46h	03h
	Q	S	F		

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1	03h
		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

#### ■Parameters (\*1,\*2)

	16:10	16:9	4:3
Hexadecimal Character	30h	31h	32h
	0	1	2

### 2.86. Query LOGO

Hexadecimal Character	02h	51h	4Ch	4Fh	03h
	Q	L	O		

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	OFF	USER	DEFAULT
Hexadecimal	30h	31h	32h
Character	0	1	2

## 2.87. Query AUTO INPUT MODE SELECTION

Hexadecimal	02h	51h	53h	53h	03h
Character		Q	S	S	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	ON1	ON2
Hexadecimal	30h	31h
Character	0	1

■Note:

- This command is effective only when the Signal Search selects "ON1" or "ON2". In other cases, ER401 is returned.

## 2.88. Query INPUT SEARCH

Hexadecimal	02h	51h	53h	52h	03h
Character		Q	S	R	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

## 2.89. Query BACKGROUND

Hexadecimal	02h	51h	42h	43h	03h
Character		Q	B	C	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2)

	BLUE	BLACK	USER
Hexadecimal	30h	31h	32h
Character	0	1	2

## 2.90. Query DIRECT ON

Hexadecimal	02h	51h	50h	59h	03h
Character		Q	P	Y	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	o	x	o	o	o

■Parameters (\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

### 2.91. Query INSTALLATION

Hexadecimal	02h	51h	53h	50h	03h
Character		Q	S	P	

■Response (Callback)

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	o	x	o	o	o

■Parameters (\*1,\*2)

	FRONT/DESK	REAR/DESK	FRONT / CEILING	REAR/CEILING
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

### 2.92. Query FAN CONTROL

Hexadecimal	02h	51h	46h	4Dh	03h
Character		Q	F	M	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	o	x	o	o	o

■Parameters (\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

### 2.93. Query LAMP POWER

Hexadecimal	02h	51h	4Ch	50h	03h
Character		Q	L	P	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	o	x	o	o	o

■Parameters (\*1,\*2)

	ECO	NORMAL
Hexadecimal	30h	31h
Character	0	1

### 2.94. Query POWER MANAGMENT

Hexadecimal	02h	51h	41h	46h	03h
Character		Q	A	F	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability



SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4)

Setting OFF and setting of 0-30 minutes is possible by a unit for 1 minute. The table below shows an examples of "OFF", "0 min" and "30min".

	OFF		1		30	
Hexadecimal Character	30h	30h	30h	31h	33h	30h
	0	0	0	1	3	0

2.95. Query STANDBY MODE

Hexadecimal Character	02h	51h	56h	58h	3Ah	53h	54h	4Dh	49h	30h	03h
	Q	V	X	:	S	T	M	I	0		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	53h	54h	4Dh	49h	33h	3Dh	2Bh
		S	T	M	I	3	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	○	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL				
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0
	ECO				
Hexadecimal Character	30h	30h	30h	30h	33h
	0	0	0	0	3

2.96. Query EMULATE MODE

Hexadecimal Character	02h	51h	56h	58h	3Ah	45h	4Dh	55h	49h	30h	03h
	Q	V	X	:	E	M	U	I	0		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	45h	4Dh	55h	49h	30h	3Dh	2Bh
		E	M	U	I	0	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	DEFAULT				
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1
	D3500				
Hexadecimal Character	30h	30h	30h	30h	32h
	0	0	0	0	2
	D4000				
Hexadecimal Character	30h	30h	30h	30h	33h
	0	0	0	0	3
	D/W5k series				
Hexadecimal Character	30h	30h	30h	30h	34
	0	0	0	0	4
	D/W/Z6k series				
Hexadecimal Character	30h	30h	30h	30h	35h
	0	0	0	0	5
	L730				
Hexadecimal Character	30h	30h	30h	30h	36h
	0	0	0	0	6
	L780				
Hexadecimal Character	30h	30h	30h	30h	37h
	0	0	0	0	7
	L735				
Hexadecimal Character	30h	30h	30h	30h	38h
	0	0	0	0	8

L785					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	39h 9
LB/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	30h 0
F/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	31h 1
LZ370					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	32h 2
VX/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	33h 3

### 2.97. Query VOLUME

Hexadecimal Character	02h	51h	41h	56h	03h
		Q	A	V	

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1	*3	*5	03h
		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

#### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	30h 0	31h 1	30h 0	30h 0	32h 2
	61			62			63		
Hexadecimal Character	30h 0	36h 6	31h 1	30h 0	36h 6	32h 2	30h 0	36h 6	33h 3

### 2.98. Query DIGITAL LINK Input switch

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Ch	31h	53h	31h	03h
		Q	V	X	:	D	L	1	S	1	

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Ch	31h	53h	31h	3Dh
		D	L	1	S	1	=
Hexadecimal Character	*1	*3	*5	*~	03h		
	*2	*4	*6	*z			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

#### ■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*~, \*z)

	HDMI1			HDMI2			COMPUTER1		
Hexadecimal Character	48h H	44h D	31h 1	48h H	44h D	32h 2	50h P	43h C	31h 1
	COMPUTER2			VIDEO			S-VIDEO		
Hexadecimal Character	50h P	43h C	32h 2	56h V	49h I	44h D	53h S	56h V	44h D

\*Note

- Effective only DIGITAL LINK connection, otherwise it returns ER401.
- Only VW431D supports this function.

### 2.99. Query DIGITAL LINK Mode

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Bh	4Dh	49h	31h	03h
		Q	V	X	:	D	K	M	I	1	

#### ■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Bh	4Dh	49h	31h	3Dh	2Bh
		D	K	M	I	1	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
	DIGITAL LINK				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2
	ETHERNET				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	33h 3

\*Note

- Only VW431D supports this function.

2.100.Query DUPLEX(ETHERNET)

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Bh	44h	49h	31h	03h
		Q	V	X	:	D	K	D	I	1	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Bh	44h	49h	31h	3Dh	2Bh
		D	K	D	I	1	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTONEGOTIATION				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	30h 0
	100BASE-TX FULL				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
	100BASE-TX HALF				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2

\*Note

- Only VW431D supports this function.

2.101.Query DUPLEX(DIGITAL LINK)

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Bh	44h	49h	32h	03h
		Q	V	X	:	D	K	D	I	2	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Bh	44h	49h	32h	3Dh	2Bh
		D	K	D	I	2	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTONEGOTIATION				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	30h 0
	100BASE-TX FULL				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
	100BASE-TX HALF				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2

\*Note

- Only VW431D supports this function.

2.102. Query DIGITAL LINK SIGNAL LEVEL

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Bh	4Ch	49h	31h	03h
	Q	V	X	:	D	K	L	I	1		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Bh	4Ch	49h	31h	3Dh	2Bh
	D	K	L	I	1	=	+	
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

ENHANCED (0-1023)					
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1
NORMAL (64-940)					
Hexadecimal Character	30h	30h	30h	30h	32h
	0	0	0	0	2

\*Note

- Only VW431D supports this function.

2.103. Query DIGITAL LINK STATUS – LINK STATUS

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Bh	53h	49h	31h	03h
	Q	V	X	:	D	K	S	I	1		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Bh	53h	49h	31h	3Dh	2Bh
	D	K	S	I	1	=	+	
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

NO LINK					
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0
DIGITAL LINK					
Hexadecimal Character	30h	30h	30h	30h	31h
	0	0	0	0	1
LPM					
Hexadecimal Character	30h	30h	30h	30h	32h
	0	0	0	0	2
ETHERNET					
Hexadecimal Character	30h	30h	30h	30h	33h
	0	0	0	0	3

\*Note

- Only VW431D supports this function.

2.104. Query DIGITAL LINK STATUS – HDMI STATUS

Hexadecimal Character	02h	51h	56h	58h	3Ah	44h	4Bh	53h	49h	32h	03h
	Q	V	X	:	D	K	S	I	1	2	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	44h	4Bh	53h	49h	32h	3Dh	2Bh
	D	K	S	I	1	2	=	+
Hexadecimal Character	*1	*3	*5	*7	*9	03h		
	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

NO LINK					
Hexadecimal Character	30h	30h	30h	30h	30h
	0	0	0	0	0

HDMI ON					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
HDCP ON					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2

\*Note

- Only VW431D supports this function.

## 2.105. Query DIGITAL LINK STATUS – SIGNAL QUALITY - MIN

Hexadecimal Character	02h	51h Q	56h V	58h X	3Ah :	44h D	4Bh K	53h S	49h I	33h 3	03h
-----------------------	-----	----------	----------	----------	----------	----------	----------	----------	----------	----------	-----

### ■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h D	44h K	4Bh S	53h I	49h 3	33h =	3Dh
Hexadecimal Character	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	*11 *12	03h

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

### ■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

-255							-254					
Hexadecimal Character	2Dh -	2Dh -	30h 0	30h 0	32h 2	35h 5	2Dh -	30h 0	30h 0	32h 2	35h 5	34h 4
1							0					
Hexadecimal Character	2Bh +	2Bh +	30h 0	30h 0	30h 0	30h 0	2Bh +	30h 0	30h 0	30h 0	30h 0	30h 0

\*Note

- Only VW431D supports this function.

## 2.106. Query DIGITAL LINK STATUS – SIGNAL QUALITY - MAX

Hexadecimal Character	02h	51h Q	56h V	58h X	3Ah :	44h D	4Bh K	53h S	49h I	34h 4	03h
-----------------------	-----	----------	----------	----------	----------	----------	----------	----------	----------	----------	-----

### ■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h D	44h K	4Bh S	53h I	49h 4	34h =	3Dh
Hexadecimal Character	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	*11 *12	03h

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

### ■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

-255							-254					
Hexadecimal Character	2Dh -	2Dh -	30h 0	30h 0	32h 2	35h 5	2Dh -	30h 0	30h 0	32h 2	35h 5	34h 4
1							0					
Hexadecimal Character	2Bh +	2Bh +	30h 0	30h 0	30h 0	30h 0	2Bh +	30h 0	30h 0	30h 0	30h 0	30h 0

\*Note

- Only VW431D supports this function.

## 2.107. Query RUNTIME - LAMP

Hexadecimal Character	02h	51h Q	24h \$	4Ch L	03h
-----------------------	-----	----------	-----------	----------	-----

### ■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	*1 *2	*3 *4	*5 *6	*7 *8	03h
-----------------------	-----	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

### ■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6)

0 h					1 h			
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	30h 0	30h 0	30h 0	31h 1

	9998 h				9999 h			
Hexadecimal	39h	39h	39h	38h	39h	39h	39h	39h
Character	9	9	9	8	9	9	9	9

- Note:
  - If the lamp runtime cannot be accessed, 0000 is returned.

2.108. Query LAMP STATUS

Hexadecimal	02h	51h	24h	53h	03h
Character		Q	\$	S	

■Response (Callback)

Lamp OFF

Hexadecimal	02h	30h	03h
Character		0	

In turning ON

Hexadecimal	02h	31h	03h
Character		1	

Lamp ON

Hexadecimal	02h	32h	03h
Character		2	

In turning OFF

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

2.109. Query TEMP INFORMATION

Hexadecimal	02h	51h	54h	4Dh	3Ah	*1	03h
Character		Q	T	M	:	*2	

■Parameters (\*1,\*2)

	Intake temp.	Exhaust temp.	Optical temp.
Hexadecimal	30h	31h	32h
Character	0	1	2

■Response (Callback)

Example: 20.0deg;C (68.0deg;F)

Hexadecimal	02h	30h	30h	32h	30h	2Fh	30h	30h	36h	38h	03h
Character		0	0	2	0	/	0	0	6	8	

Example: -10.0deg;C (14.0deg;F)

Hexadecimal	02h	2Dh	30h	31h	30h	2Fh	30h	30h	31h	34h	03h
Character		-	0	1	0	/	0	0	1	4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

2.110. Query SERIAL NUMBER

Hexadecimal	02h	51h	53h	4Eh	03h
Character		Q	S	N	

■Response (Callback)

Example: 123456789

Hexadecimal	02h	31h	32h	33h	34h	35h	36h	37h	38h	39h	03h
Character		1	2	3	4	5	6	7	8	9	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

2.111. Query MAC ADDRESS

Hexadecimal	02h	51h	4Dh	41h	03h
Character		Q	M	A	

■Response (Callback)

Example: AB0102030405

Hexadecimal	02h	41h	42h	30h	31h	30h	32h	30h	33h	30h	34h	30h	35h	03h
Character		A	B	0	1	0	2	0	3	0	4	0	5	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	○	○	○	○

○	○	x	○	○	○
---	---	---	---	---	---

### 2.112. Query RUNTIME - PROJECTOR

Hexadecimal	02h	51h	56h	58h	3Ah	52h	54h	4Dh	49h	30h	03h
Character		Q	V	X	:	R	T	M	I	0	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	52h	54h	4Dh	49h	30h	3Dh	2Bh
Character		R	T	M	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

Example: 55 hours

Hexadecimal	30h	30h	30h	35h	35h
Character	0	0	0	5	5

### 2.113. Query LAMP SERIAL NUMBER

Hexadecimal	02h	51h	56h	58h	3Ah	4Ch	53h	4Eh	53h	30h	03h
Character		Q	V	X	:	L	S	N	S	0	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Ch	53h	4Eh	53h	30h	3Dh		
Character		L	S	N	S	0	=		
Hexadecimal	*1	*3	*5	*7	*9	*11	*13	*15	03h
Character	*2	*4	*6	*8	*10	*12	*14	*16	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (\*1~\*16)

Example: 12345678

Hexadecimal	31h	32h	33h	34h	35h	36h	37h	38h
Character	1	2	3	4	5	6	7	8