Safety Instructions

Before use

Thank you very much for purchasing this product.

This product is an interface box called "Connection & Control Box" for EPSON short throw projectors.

For your safety, read the attached documents carefully to use this product correctly. After you have read all instructions, keep this information for later reference.

The following symbols are used to show dangerous operation or handling. Make sure you understand them before reading the guide.

Warning	This symbol indicates information that, if ignored, could possibly result in serious personal injury or even death due to incorrect handling.
Caution	This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.

Notes on Installation



- When installing this product, keep the enough strength of the wall. Do not install the product to a wall at an angle or an unstable wall.
 Otherwise, the product may fall and cause injury.
 EPSON takes no responsibility for any fall accident due to strength poverty of the wall or fixture for the product.
- Do not set up the product in places where there is a lot of humidity or dust, near cooking or heating appliances, may come in contact with oily or cigarette smoke, or steam.
- Do not set up the product in places where it might be subjected to vibration or shock.
 Otherwise, the screws may be loosen and the product may fall and cause.
 - Otherwise, the screws may be loosen and the product may fall and cause injury.
- Do not apply threadlocker, lubricant or oil to the attachment area of the product.
 - Otherwise, the housing or fixing part may crack and the product may malfunction. Or the product may fall and cause injury.



 Secure the product without any gap against the wall. Make sure the screws are not secured at an angle. Check if the screws are tightened firmly.

1

Notes on Usage

Warning

- Do not place any containers with water, chemical liquid and such in them on top of the product.
- Do not stand on the product or place heavy objects on it.
 Doing so may damage the product.
- Do not insert or drop any piece of metal, the flammable or foreign objects into the slits on the product.
- Do not open any covers on the product except as specifically explained in the attached documents, and do not attempt to disassemble or modify the product. Refer all repairs to qualified service personnel.
- Take care not to spill any beverage such as tea, coffee or juice onto the product, or spray aerosol insecticide.
 It may cause malfunction, fire, or electric shock.
 If any liquid has been spilled on the product, turn off the power and unplug the AC adapter immediately, and then contact your dealer.
 Continuous use may result in fire or electric shock.
- Under the following conditions, turn off the power immediately, unplug the product, disconnect all cables, and then contact your dealer or EPSON customer service call center:
 - If smoke, strange odors or strange noises come from the product.
 - If liquid or foreign objects get inside the product.
 - If the product has been dropped or the housing has been damaged. Do not try to repair the product for yourself.
- When cleaning the product, do not use a moistened cloth or solvents such as alcohol, thinner or benzine.
- The power cable supplied with the product is intended to comply with power supply requirements for the country of purchase. Be sure to use the power cable supplied with this product.
- Do not use the AC adapter that is not supplied with the product.
 Otherwise, damage, overheating, fire or electric shock may occur.
- Be sure to use the AC adapter with the specified voltage.
 Using it with other voltage levels may cause damage, overheating, or smoke which results in fire or electric shock.
- Do not pull the AC adapter cord or put a heavy object on it.
 Doing so may cause fire or electric shock.
- Do not touch the product, AC adapter, plug, or cables with wet hands.
 Doing so may cause damage, fire, or electric shock.
- Take the following precautions when handling the plug.
 Failure to comply with these precautions could result in fire or electric shock.
 - Do not overload wall outlets, extension cables, or power strips.
 - Do not insert the dusty plug into an outlet.
 - Insert the plug firmly into the outlet.
 - Do not hold the plug with wet hands.
 - Do not pull the power cable when disconnecting the plug. Be sure to hold the plug when disconnecting it.



 Do not use the AC adapter in a small space, or cover it with a cloth and such.

Otherwise, the AC adapter may become hot and may be deteriorated.



- Be sure to turn off the main power switch after use.
- Clean the product periodically. If the product has not been cleaned for a long time, dust may build up and it may cause fire or electric shock.
- Disconnect all cables from the product before cleaning.

Notes on Storage and Transportation



- Do not store the product in places where oily or cigarette smoke may be present.
- Do not leave the product in places where it may become extremely hot such as in a vehicle with the windows closed, in direct sunlight, or near the exhaust duct of an air conditioner.



 Before moving the product, turn off the power and unplug from the outlet, and make sure all the cables are disconnected.

For Canadian Users

CAN ICES-3 (B)/NMB-3(B)

This product is also designed for IT power distribution system with phase-to-phase voltage 230V

In north America, a flame resistant CL2 rated interface cable is necessary for in-wall installation. Use an interface cable that complies with the NFPA70 standard.

Supplier's DECLARATION of CONFORMITY

According to 47CFR, Part 2 and 15
Class B Personal Computers and Peripherals; and/or
CPU Boards and Power Supplies used with Class B Personal Computers

We: Epson America, Inc. Located at: 3840 Kilroy Airport Way

MS: 3-13

Long Beach, CA 90806

Tel: 562-981-3840

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed, is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR 2.909.

Trade Name: EPSON

Type of Product: Connection & Control box

Model: ELPCB03

FCC Compliance Statement For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification or Declaration of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Symbols Indicating the Device Meets the IEC60950-1 A2 Safety Standards

The following table lists the meaning of the safety symbols labeled on the equipment.

No.	Symbol mark	Approved standards	Meaning
0	ı	IEC60417 No.5007	"ON" (power) To indicate connection to the mains.
2	0	IEC60417 No.5008	"OFF" (power) To indicate disconnection from the mains.
3	Û	IEC60417 No.5009	Stand-by To identify the switch or switch position by means of which part of the equipment is switched on in order to bring it into the stand-by condition.
4	<u> </u>	ISO7000 No.0434B IEC3864-B3.1	Caution To identify general caution when using the product.
5		IEC60417 No.5957	For indoor use only To identify electrical equipment designed primarily for indoor use.
6	♦•• •	IEC60417 No.5926	Polarity of d.c. power connector To identify the positive and negative connections (the polarity) on a piece of equipment to which a d.c. power supply may be connected.
7		IEC60417 No.5019	Protective earth To identify any terminal which is intended for connection to an external conductor for protection against electric shock in case of a fault, or the terminal of a protective earth electrode.
8	<u></u>	IEC60417 No.5017	Earth Indicates a grounding port when No. 7 is not explicitly called for.

English

No.	Symbol mark	Approved standards	Meaning
9	>	IEC60417 No.5032	Alternating current To indicate on the rating plate that the equipment is suitable for alternating current only; to identify relevant terminals.
10	===	IEC60417 No.5031	Direct current To indicate on the rating plate that the equipment is suitable for direct current only; to identify relevant terminals.
1	0	ISO 3864	General prohibition To identify actions or operations that are prohibited.