

## Start Here

Follow the steps on this card to get started with your BrightLink projector:

- 1 Connecting your computer
- 2 Installing interactive software
- 3 Interacting with the screen
- 4 Using the built-in toolbar

## BrightLink Interaction

The BrightLink interactive pens turn any wall or table into an interactive area, with or without a computer.

The projector control toolbar lets you control the projector from the screen just as you would using the remote control.



## Easy Interactive Tools

With a computer, you can use Easy Interactive Tools. This software lets you use the interactive pens as a mouse to annotate, save, and interact with content from your computer.

Drawing toolbar




Command toolbar




## Built-in Toolbar


Without a computer, you can use the toolbar that is built into the projector (PC Free Annotation). This lets you annotate images from a document camera, tablet, DVD player, or other source connected to your projector.

Students and colleagues can connect their own laptops and annotate on the fly using the built-in toolbar, without installing software.




# 1 Connecting Your Computer





- 1 Turn on the projector by pressing the blue  power button on the remote control.
- 2 Connect an HDMI or VGA cable from the projector to your computer.



**Note:** You can also display media through a USB connection with the USB Display feature. See the online *BrightLink User's Guide* for more information.

- 3 Connect the USB cable from the projector's USB **TypeB** port directly to any available USB port on your computer.



- 4 The default language of the menu system is English. To select another language, press the **Menu** button on the remote control. Select **Extended** and press . Select **Language** and press . Select your language and press . Press the **Menu** button to exit the menu system.
- 5 Display an image from your computer. If the image doesn't appear, try one of the following:
  - On some Windows® laptops, you may need to hold down the **Fn** key on the keyboard and press **F7** or the function key that lets you display on an external monitor. It may have an icon such as , or it may be labelled **CRT/LCD**.
  - On Windows 7 or later, hold down the Windows key and press **P** at the same time, then click **Duplicate**.

- On a Mac, you may need to open **System Preferences** and select **Displays**. Click the **Arrangement** tab and select the **Mirror Displays** check box.
- Try pressing the **Source Search** button on the remote control.
- Press the **Home** button on the projector or remote control to verify the source input and settings.

## 2 Installing Interactive Software

You may already have interactive software on your computer, or you may need to install it. If you are using a Mac, you need Easy Interactive Driver and Easy Interactive Tools (or other interactive software). For Windows, you only need Easy Interactive Tools (or other interactive software).

Here's how to find out if the Easy Interactive Tools software is installed on your computer:

### If you are using a Mac:

Look for the Easy Interactive Driver and Easy Interactive Tools folders in the Application folder on your hard drive. If you see these folders, the Easy Interactive software is installed.

### If you are using Windows:

**Windows 10/Windows 8.x** — Navigate to the **Apps** screen or **All Apps** menu and select **Easy Interactive Tools**.

**All other versions** — Select  or **Start > All Programs** or **Programs > EPSON Projector > Easy Interactive Tools Ver. 4.2**.

If you see Easy Interactive Tools, the software is installed.

If the software is not installed, do one of the following to install it:

- Use the CD that came with the projector, labeled "EPSON Projector Software for Easy Interactive Function"
- Download the most up-to-date version from:  
**[www.epson.com/brightlinkdownloads](http://www.epson.com/brightlinkdownloads)** (U.S.)  
**[www.epson.ca/brightlinkdownloads](http://www.epson.ca/brightlinkdownloads)** (Canada)


For more information about Easy Interactive Tools, see the online Easy Interactive Tools tip sheet or the online *BrightLink User's Guide*.

# 3 Interacting With the Screen


## Interactive Pens

Your projector came with 2 pens, one orange (Interactive Pen A) and one blue (Interactive Pen B).

The pens have two different types of tips: a soft, felt tip and a hard tip. Make sure one AA battery is installed in each pen.



- To turn on the pen, pick it up. The blue light comes on briefly. If the battery is low, the light flashes.
- Hold the pen perpendicular to the board, as shown below.



- When you are finished using the pen, simply place it in an area away from the projection screen.

**Note:** The pens turn off automatically after about 15 seconds of inactivity. Pick the pen up to turn it back on.

## Using Your Pen as a Mouse

When you are in computer interactive mode, you can use the pen as a mouse to interact with your computer desktop.

| Mouse function | Pen action                      |
|----------------|---------------------------------|
| Left-click     | Tap on board                    |
| Double-click   | Tap twice                       |
| Right-click    | Press pen button                |
| Move cursor    | Hover over board                |
| Click and drag | Tap and hold on item, then drag |

See the online BrightLink *User's Guide* for more information.


## Having Trouble?




If the cursor does not match your pen location, follow the calibration instructions on the back of this card.

# 4 Using the Built-in Toolbar


The projector's built-in toolbar lets you annotate images from other devices that have been connected to the projector, such as a document camera, tablet, or other source. This is known as PC Free Annotation mode.

- 1 Press one of the source buttons on the remote control to select the source for the image you want to annotate.




- 2 To activate the toolbar, tap the board with the pen. If you don't see the  icon, tap the  icon and then tap the  icon.

**Note:** If you only see the  icon, you are already in PC Free Annotation mode.

- 3 To close the toolbar, tap the  icon at the bottom of the toolbar.


Two toolbars are available in PC Free Annotation mode, one for annotation mode and one for whiteboard mode. Many of the tools are the same as Easy Interactive Tools, but fewer functions are available.

- Annotation mode displays the built-in toolbar on whatever image is being projected.
- Whiteboard mode lets you project a white or black screen or background pattern, and use the pen to write or draw as you would on a chalkboard or dry erase board.



\* In annotation mode, the  select background tool does not appear.

# Using the Remote Control



For more information on using the remote control:

- See the online BrightLink *User's Guide*
- Watch a video or two at [www.epson.com/brightlinkvideos](http://www.epson.com/brightlinkvideos) (U.S.) or [www.epson.ca/brightlinkvideos](http://www.epson.ca/brightlinkvideos) (Canada)

# Choosing the Right Tool

If you already have annotation software, you can use it with your BrightLink projector. If you are using Microsoft® Office 2003 or later, you can also use the “inking tools” to add handwritten notes to your documents and PowerPoint® presentations.

Here are some tips on choosing from the tools that came with your BrightLink projector:





|  | Built-in<br>Toolbar | Easy<br>Interactive<br>Tools |
|--|---------------------|------------------------------|
| No computer?                                       | ✓                   |                              |
| Use pen as a mouse                                 |                     | ✓                            |
| Use the board to draw on computer content          | ✓                   |                              |
| Draw on board using the computer                   |                     | ✓                            |
| Save annotations as a JPEG                         | ✓                   |                              |
| Save annotations in image, PDF, or editable format |                     | ✓                            |

---

# Calibration

---

Calibration coordinates the position of the pen with the location of your cursor. If the pen position and cursor location don't match, you can perform auto calibration, or you can calibrate manually for even greater accuracy. You don't need a computer, and you won't need to calibrate again unless the projector or image is moved, or the image is resized.

- 1 To start pen calibration, press the **User** button on the remote control, or press the **Home** button on the remote control and select **Auto Calibration**.
- 2 When you see the Auto Calibration screen, do one of the following:
  - Press  to run auto calibration, then wait until calibration is complete.
  - Select **No**, then press  and follow the steps below to calibrate manually.
- 3 Select **Manual Calibration**, then press .
- 4 When you see the Manual Calibration screen, press  to select **Yes**.
- 5 Touch the center of the circles on the screen with your pen to perform manual calibration.

---

# Need Help?

---

## Telephone Support

The Epson® PrivateLine® service is for you!

All you have to do is call (800) 637-7661. This service is available for the duration of your warranty period.

You may also speak with a projector support specialist by dialing (562) 276-4394 (U.S.) or (905) 709-3839 (Canada).

Support hours are 6 AM to 8 PM, Pacific Time, Monday through Friday, and 7 AM to 4 PM, Pacific Time, Saturday. Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

## Online Support

To access the online *User's Guide*, get FAQs, and more, visit **[www.epson.com/brightlinkdownloads](http://www.epson.com/brightlinkdownloads)** (U.S.) or **[www.epson.ca/brightlinkdownloads](http://www.epson.ca/brightlinkdownloads)** (Canada) and select your product.



\*413106700\*

**EPSON®**  
EXCEED YOUR VISION

EPSON is a registered trademark and EPSON Exceed Your Vision is a registered logomark of Seiko Epson Corporation. BrightLink and PrivateLine are registered trademarks of Epson America, Inc.

Mac is a trademark of Apple Inc., registered in the U.S. and other countries.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.

© 2016 Epson America, Inc., 9/16

CPD-50682